
AIR FORCE INST OF TECH WRIGHT-PATTERSON AFB OH SCHOOF—ETC F/8 9/2 A UNIX BASED DEVICE DRIVER FOR THE VECTOR GENERAL 3404 GRAPHICS—ETC(U) MAR 82 B R STEWART NT AFTI/6CS/MA/81D=6 NL AD-A115 582 UNCLASSIFIED 1053 21556





DTIC ELECTER JUN 1 51982

E

DEPARTMENT OF THE AIR FORCE
AIR UNIVERSITY (ATC)

AIR FORCE INSTITUTE OF TECHNOLOGY

Wright-Patterson Air Force Base, Ohio

This document has been approved for public release and sale; its distribution is unlimited.

R2 06 14 173

THE FILE COP

A UNIX BASED DEVICE DRIVER FOR THE VECTOR GENERAL 3404 GRAPHICS DISPLAY SYSTEM

THESIS

AFIT/GCS/MA/81D-6 Bradley R. Stewart 2nd Lt USAF

Approved for public release; distribution unlimited

A UNIX BASED DEVICE DRIVER FOR THE VECTOR GENERAL 3404 GRAPHICS DISPLAY SYSTEM

THESIS

Presented to the Faculty of the School of Engineering
of the Air Force Institute of Technology
Air University
in Partial Fulfillment of the
Requirements for the Degree of

Master of Science

bу

Bradley R. Stewart, B.S.

2nd Lt

USAF

Graduate Computer Systems

March 1982

DTIC COPY INSPECTED

Accession For
NTIS GRA&I
DTIC TAB
Unannounced
Justification

Distribution/

Dist

Availability Codes
Avail and/or

Special

Approved for public release; distribution unlimited

Preface

The purpose of this study was to develop device driver software for Vector General 3404 Graphics Display System.

The device driver software was installed on a PDP11/60 computer running under the UNIX version seven operating system.

This report discusses all of the major components of the system. These include the UNIX peripheral device I/O processing routines, the hardware interface between the PDP11/60 and the display system, the Vector General 3404 Graphics display system, and the device driver routines. I believe this work will be very helpful to anyone working on peripheral device I/O processing under the UNIX operating system.

I would like to thank my advisor, Professor Charles W. Richard, Jr., for his constant support and encouragement during this study. Deep gratitude is also expressed to Dr. J. Lions of the University of New South Wales for his brilliant commentary on the UNIX operating system. And finally, I wish to acknowledge my gratitude to Mary Minnick for her effort in typing this thesis.

Bradley R. Stewart

																								Page
Prefa	ace			•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	11
List	of	Fig	ures	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	viii
List	of	Tab	les.	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	x
Absti	ract	· .		•	•	•	•	•	•	•	•	•	•	•	•	•	•		•	•	•	•	•	хi
I.	Iı	ntro	duct	Lor	ı.	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	1
		Ba Sc	ckgro	our and	nd i C	b.	jed	et:	iv	es		•	•		•			•					•	14
		Ap	proac	ch							•				•		•		•					5
		Co	nvent	tic	ons	s t	Jse	æd				•												6
		0v	proac nvent ervic	ew	of	: 1	the	e '	Th	esi	ls	•	•	•	•	•	•	•	•	•	•	•	•	8
II.	Pı	reli	mina	ry	Co	ono	ep	oti	S	•	•	•	•	•		•	•	•	•	•	•	•	•	11
		The	e UN	ΙX	Fi	16	e 5	Sy	st	em			•	•	•	•	•	•		•		•		11
			Oro	111	ıar	'nУ	F.3	LIC	es	•	•	•	٠	•	•	•	•	•	•	•	•	•	•	11
			Dia	rec	ctc	r	7 1	·l.	Te:	5.	•	•	•	•	•	•	•	•	•	•	٠	•	•	12
			Spe	ec:	Laj	L	נני	Le	S.	•	•		•	•	•	•	•	•	•	•	•	•	•	12
			F1	тe	Sy	751	ten	n :	Hl	era	r	ch	y .	•	•	٠	•	•	•	•	•	•	•	12
			F1:	le	Pa	iti	ı v	Vai	me:	s.	•	•	•	•	•	•	•	•	•	•	•	•	•	14
			F1:	le	Sy	rst	cen	n.	Im	ple	eme	ent	tat	tic	on	•	•	•	•	•	•	•	•	15
		The	e UNI Bas	IX	I/	0	S	7S	tei	n.	•	•	•	•	•	•	•	•	•	•	•	•	•	17
			Bas	sic	3]) S	3 y :	st	em	Ca	al.	ls	•	•	•	•		•	•	•	٠	•	17
			Der	V1(e	C.	Las	35	es				•					•		•	•			19
		_	De	vi(ce	Na	ame	S												• .				19
		Pr	oces	s I	1ar	nag	gen	nei	nt															20
			The	9 1	rc	OC	St	r	uc:	cui	re													20
			The	e (Jse	r	St	r	uc'	tur	·e	•	•		•	•		•		•	•	•	•	21
		Su	mmary	y .	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	22
III.	Pe	erip	hera:	1 1)ev	710	ce	I,	/0	•		•	•	•		•	•		•	•	•	•	•	23
		Fl	ow of	e (Cor	ıtı	co]	L	Du:	rir	ıg	I,	0	Pı	roc	es	ssi	ne.	ζ.					23
		Pr	oces	si	1g	Us	ser	•	Pro	ogi	ar	n :	[/(O I	Red	aue	est	ະຣັ						25
			The																				-	26
			The	e S	Sys	ste	em	T	ra	p N	le d	cha	an:	isr	n.	_	_	_	_	_	-	•	-	27
•			UN	ΙX	Tr	ar	o F	łai	nd.	ler	• 1	Roi	ıt:	ine	es		•		•			•		29
			Sys																			•		31
			I/O												Roi	it:								33
			•		ρę					•														33
					cio			-		•	•						•			•	•	•	•	35
								nd	W:	rit	ė	-		_			•			•	•		-	36
				5	Stt	y	ar	nd	G.	ttj	7.	•		-			•		•		•	•	•	37
			De											_					•		•	•	•	38
			Sur							•			•	•		•	•						•	42
		Pr	oces		-										Ír	ite	rr	ur	ts		_	•	•	42

		Page
	Peripheral Device Events	44
	The System Interrupt Mechanism	45
	The UNIX Interrupt Handler Routine	
	Summary	47
IV.	The Vector General 3404 Graphics Display System	48
	Overall Description	48
	Functional Description of Major Display	
	System Components	50
	Computer/Display System Interface	50
	Graphic Processor Unit	
	Refresh Buffer Unit	
	Display Control Unit	51
	Vector Generator Unit	52
	Font Generator Unit	52
	Monitor Control Unit	52
	Display Monitors	
	Display System Input Devices	52
	Ontdoor	72
	Options	53
	Display System Registers	53
	Data Tablet Registers	54
	Function Switch Box Registers	55
	Alphanumeric Keyboard Register	
	Summary	
٧.	The PDP11/VG3404 Hardware Interface	58
	Accessing the Interface Registers	59
	The Interface's Eight I/O Instructions	
	Channel Communication	65
	The DMA Channel	
	The Interrupt Channel	
	The Interrupt Channel	
	The Programmed Input/Output Channel	
	Summary	73
VI.	The VG Device Driver	74
	Requirements	74
	Original Requirements	74
	Requirements for AFIT's VG Device Driver .	77
•	Overall Design	78
	Tunlamantation	81
	Implementation	
	User Level Implementation	81
	The GPU Minor Device	82
	Open /dev/gpu	82
	Read /dev/gpu	82
	Write /dev/gpu	82
	Stty /dev/gpu	ŘΞ
	Gtty /dev/gpu	83 84

	Page
Close /dev/gpu	84
The Data Tablet Minor Device	85
Open /dev/dtb	85
Read /dev/dtb	85
Write /dev/dtb	88
	88
	89
Gtty /dev/dtb	
Close /dev/dtb	89
The Alphanumeric Keyboard Minor	0.0
Device	89
Open /dev/kbd	89
Read /dev/kbd	89
Write /dev/kbd	90
Stty and Gtty /dev/kbd	90
Close /dev/kbd	91
The Function Switch Box Minor	-
Device	91
Open /dev/fss	91
Read /dev/fss	91
	92
Write /dev/fss	92
Close /dev/fss	92
The Device Driver Routines	93
Include Files	93
Global Data Structures	93
The UNIX proc and u	
Structures	94
The vgunit Array	94
The VG Minor Device	
Switch Table	96
Common Procedures	97
PIN and POUT	97
gpwait and gpurestart	98
putc and getc	99
	100
passc	100
psignal	101
fuiword and suiword	101
Major Device Routines	102
vgopen	102
vgclose	103
vgread	103
vgwrite	103
vgioctl	103
vgint	104
Minor Device Routines	104
GPU Routines	105
gpopen	105
gpclose	106
nhnead	106

		Page
	gpwrite	107
	vgsgtty	107
	Data Tablet Routines	110
	dtopen	110
	dtclose	110
	dtread	111
	dtwrite	111
	fskbdtsgtty	111
	dtintr	112
	The Alphanumeric	
	Keyboard Routines	113
	kbopen	113
	kbclose	113
	kbread	113
	kbwrite	113
	kbintr	114
	The Function Switch	117
	Box Routines	114
	fsopen	114
	fsclose	114
	fsread	115
	fswrite	115
	fsintr	115
	Summary	116
VII.	Device Driver Updates	117
	Space Limitations	117
	Removal of Level One Graphics	
	Support	117
	Removal of Code for Timeouts	118
	Removal of Code for Light Pen	118
	Display System Differences	119
	Differences Between UNIX Versions	,
	Six and Seven	119
	Summary	121
	Deminary	757
VIII.	Installing the VG Device Driver	122
	Creating the Special Files	123
•	Relocating the Driver Source Files	126
	Producing and Archiving the Driver	
	Object File	127
	Editing the Character Device Switch	,
	Table	129
	Editing the Interrupt Vector File	131
	Producing the UNIX Object File /unix.vg	132
	Restoring the Changed UNIX Files	
		134
	Rebooting the System from /unix.vg	135
	Summary	135

																							Page
IX.	Sai	ftwai	re '	Tes	stir	ng		•	•	•	•	•	•	•	•	•	•	•		•	•	•	136
		GPU Data Keyl Fund Summ	a Ta ooa: cti	ab] rd on	let Tes Swi	Te sts Ltc	est s. ch	s Bo		Te	st		•	•	•	•	•	•	•	•	•	•	136 141 143 144 145
x.	Cor	nclus	sio	ns	and	1 F	Red	on	me	nd	at	io	ns	١.	•	•			•	•	•	•	146
Biblio	gra	aphy	•	• •		•		•	•	•	•	•	•		•	•	•	•	•	•	•	•	150
Append	lix	A:			ings /h/p												ı.	•	•	•	•	•	152
Append	lix	B:			lng /cor												•	•	•		•		161
Append	lix	C:			ing /cor											•	•	•		•	•	•	165
Append	lix	D:			lngs /h/v													•	•		•	•	170
Append	l1x	E:	Li	sti	ing	of	F	i.	le	/s	уs	/c	on	if/	'ma	ıke	efi	116	€.	•	•	•	191
Append	lix	F:			tior nics																•	•	195
Append	lix	G:	Ma	j oı	r Sj	st	en	n I	ir	ec	tc	ri	.es				•	•	•	•	•	•	196
Append	lix	Н:			otir Obj											•	•	•	•	•	•	•	197
Vita																							200

<u>List of Figures</u>

Figure Pigure		Page
1	Organization of Major System Components	. 9
2	File System Hierarchy	. 13
3	File System Data Structure	. 16
4	Flow of Control During I/O Processing	. 24
5	I/O Processing Routines and Control Transfer Mechanisms	. 25
6	System-Call Trap Vector	. 28
7	System-Call Switch Table	. 32
8	Routines For Processing an open(2) System Call	. 33
9	Routines For Processing a close(2) System Call	. 35
10	Routines For Processing the read(2) and write(2) System Calls	. 36
11	Routines For Processing the stty and gtty System Calls	. 38
12	Main Routines Called During Peripheral I/O Processing	. 43
13	Interrupt Processing Routines and Control Transfer Mechanism	. 44
14	Interrupt Vector for VG Display System	. 46
15	Display System Organization	. 49
16	Input Device Registers	. 55
• 17	Interface Communication Channels	. 59
18	Using a Dummy Structure to Access the Contents of the Interface Registers	. 63
19	Communication Channel Usage	. 66
20	McCallum's Two Levels of Graphics Support	. 75
21	Device Driver Design	. 79

<u>Figure</u>		Page
22	The vgunit Data Structure	95
23	Design of the vgsgtty Routine	108
24	Location of Relevent Files and Commands	124

<u>List</u> of Tables

Table	<u>P</u> .	age
I	Stty Special Functions	84
II	Data Tablet Interrupt IDs	86
TTT	Data Tablet Interrupt Masks	87

Abstract

A device driver for the Vector General 3404 Graphics
Display System was installed under the UNIX version seven
operating system on a PDP11/60 computer. This was accomplished by modifying an existing device driver which was designed to run under version six of the UNIX operating system.

The major topics addressed in this report are the C programming language, peripheral device I/O processing under UNIX, the hardware interface between the PDP11/60 and the graphics display system, the graphics display system itself, and the existing device driver software.

Structure charts were used to document the design of the UNIX peripheral device I/O processing software and the design of the device driver software. Modifications to the original device driver were easily accomplished due to the top-down modular design of the original software. UNIX provided a straight-forward interface for adding the device driver soft-ware to the system.

A UNIX BASED DEVICE DRIVER FOR THE VECTOR GENERAL 3404 GRAPHICS DISPLAY SYSTEM

I <u>Introduction</u>

The problem addressed in this thesis investigation was the development and installation of device driver software for a vector General 3404 Graphics Display System (hereafter referred to as the VG graphics device or the VG display system).

The software was installed under the UNIX version seven operating system running on a PDP11/60 computer. This effort was intended as a first step in the development of a high-level interactive graphics system for the PDP11/60 running under UNIX.

This chapter presents the background to the problem, scope and objectives, approach taken, conventions used, and finally an overview of the remainder of the thesis.

Background

In July, 1981 the RSX-11M operating system running on the PDP11/60 computer at the Air Force Institute of Technology (AFIT) was replaced by the Bell System's UNIX version seven operating system. This replacement was justified by a number of desirable UNIX features not offered by the RSX-11M operating system.

First of all, UNIX provides more software tools for education. It supports several different programming languages and provides excellent facilities for document

preparation.

UNIX also provides very powerful tools for program development. An example is the UNIX capability of creating a "pipe" for inter-process communication. In a pipe, as output is generated from one program it is immediately made available as input to the next program (Refs 2:2; and 13:8). Therefore, a pipe facilitates executing programs together as a complete system. That is, a large software system can be designed and developed in small pieces, then brought together and executed in a pipe.

The UNIX system is totally self supporting. All UNIX software is maintained on the system. With only 10,000 lines of code, the system can easily be understood and maintained by one person. Of the 10,000 lines of UNIX code, less than ten percent is written in assembly language. The remaining ninety percent is written in the general-purpose procedural language "C". This high level language enhances system understandability and maintainability.

Ritchie and Thompson list the following desirable UNIX features seldom found even in larger operating systems (Ref 13:1).

- A hierarchical file system incorporating demountable volumes.
 - Compatible file, device, and inter-process I/O.
 - The ability to initiate asynchronous processes.
- System command language selectable on a per
- user basis.
 - Over 100 subsystems, including a dozen languages.
 - High degree of portability.

These features make UNIX simple, elegant, and easy to use.

With the upgrade to UNIX, it became necessary to upgrade the graphics package on the PDP11/60. FGP34, a graphics package based on ACM/SIGGRAPH's Core System standard proposal (Ref 15), is the package that ran under the RSX-11M operating system. This package is not readily compatible with UNIX. In order to run FGP34 under UNIX, a new device driver would have to be written. This could be very difficult to impossible depending on how strongly the FGP34 software is dependent on the RSX-11M operating system. Another issue that must be considered is that FGP34 does not support complete device independence. That is, it only runs with the Vector General 3400 series display systems. Therefore, when other types of graphics devices are installed on the PDP11/60 in the future, the FGP34 will not support them.

As a result of these problems and limitations, it was decided to acquire a better graphics software system, e.g., one based on the Core System that is operating system independent and device independent. One good candidate that has been identified is GRAFLIB, a graphics software system developed by the Lawrence Livermore Laboratory (Ref 6).

No matter which high level graphics software system is finally implemented, a new low level device driver had to be installed under UNIX for the VG graphics device. When this investigation was begun, the author knew of no VG device drivers written to run under UNIX version seven. At the same time, it was known that two different VG device drivers did exist

for UNIX version six. One had been developed at The University of Kansas. Another had been developed at The University of Texas at Austin. In order not to "re-invent" the wheel, it was decided to modify one of these existing drivers to run under UNIX version seven.

The driver developed at the University of Texas at Austin was chosen because of its straight forward, top-down design and because the driver source code was easy to obtain. The driver was written by Douglas McCallum in support of his thesis on machine-independent interactive computer graphics (Ref 12). It was designed for the UNIX version six operating system running on a PDP11/34 computer.

Scope and Objectives

This thesis investigation was devoted to updating and installing McCallum's VG device driver on the PDP11/60 computer under the UNIX version seven operating system.

One main objective was to, as much as possible, use McCallum's device driver software "as is". Modifications were only made to make the driver compatible with UNIX version seven and to meet the space limitations of AFIT's PDP11/60 computer. Also, since McCallum's driver did not support the VG's data tablet input device, software was developed and incorporated to support AFIT's data tablet.

Another main objective was to document how the VG driver works. This included an explanation and description of the UNIX operating system, the hardware interface between the PDP11/60 and the VG graphics device, the VG graphics device

itself, and the driver routines.

Approach

This project required a working knowledge of the "C" programming language, the UNIX operating system (both versions six and seven), the PDP11/VG3404 hardware interface, the VG graphics device at the register level, McCallum's driver software, and driver installation procedures.

First, UNIX was studied from a user's point of view to learn how to use the system. The article "An Introduction to the UNIX Shell" and "UNIX for Beginners - Seventh Edition" served as tutorials for this step (Refs 2 and 9). The UNIX text editor was learned next by studying the article "A Tutorial Introduction to the UNIX Text Editor" (Ref 8).

Next, the "C" programming language was learned by writing and executing programs that illustrated the major features of the language. Kernighan and Ritchie's book entitled The C Programming Language was used as a tutorial during this step (Ref 7). This step was essential since both UNIX and the device driver are written in "C".

After learning the basics above, UNIX was studied from a systems point of view to learn how it deals with device drivers in general. J. Lions' commentary on the UNIX operating system, along with listings of UNIX source code, served as the main tutorial for this step (Refs 10 and 11). The differences between UNIX version six and UNIX version seven were also studied at this point.

Study of Vector General documentation provided an understanding of the PDP11/VG3404 hardware interface and the VG graphics device at the register level. The most important of these documents were the Programming Concepts Manual, the System Reference Manual, the PDP11 Interface Specification, and volume one of The Series 3400 Technical Manual (Refs 17-20).

The knowledge obtained from the above studies helped the author understand McCallum's driver software. Some help was also received through telephone conversations with Douglas McCallum. Once the driver was understood, it was updated to run under UNIX version seven. Next, the driver was installed on the system using the articles "Regenerating System Software" and "Setting Up UNIX" as a guide for installation procedures (Refs 4 and 5).

The final step was the development and incorporation of routines to handle the VG data tablet input device.

McCallum's routines for the VG function switches and keyboard input devices served as a guide for writing these routines.

Conventions Used

A few conventions are identified here that are used throughout the report.

All references to UNIX system commands are specified by the command name followed by a section number in parenthesis. The section number refers to the section of the UNIX Programmer's Manual (Ref 1) where the command is defined. For example, cp(1), refers to the copy system command which is found in section 1 of the UNIX Programmer's Manual. This system was adopted because the UNIX Programmer's Manual does not have page numbers.

Another convention that merits explanation is how computer code is cited in this report. Two types of code are cited in this report; a stream of UNIX system commands entered from a terminal and listings of "C" language statements taken from computer programs. The following UNIX system command stream illustrates how a stream of UNIX command statements

- 1. # cd /sys/conf
- 2. # cp /sys/dev/vg.c/sys/dev/vg
- 3. # mkdev i vg
- 4. cp ../h/param i.h ../h/param.h
- 5. a vg.o
- 6. # rm /sys/dev/vg
- 7. #

is cited in this report. First, the statements are numbered sequentially to provide a means of referencing each individual line. If only one statement is cited then it is not numbered. The symbol "#" is a prompt sign printed by the system. Following the prompt sign the user types a command statement followed by a carriage return. The system executes the command then prints another "#" to prompt the user for more input. Lines not beginning with the "#" prompt, as with lines four and five above, represent messages or text printed during the execution of a command.

The "#" prompt is also an indication that the user is logged in as the super-user. The super-user is granted

special access rights and priviledges that other users do not receive. These rights and priviledges allow the superuser to make any necessary changes to the system, such as install a new device driver.

The "C" language statement listing

```
1. dtclose()
2. { extern struct cdevsw vgdev[];
3.         POUT(dtb, 0);
4.         while (getc(&vgunit[1].io) >= 0);
5. }
```

is an example of how portions of computer programs are cited in the report. The statements are simply numbered sequentially so each individual line can be referenced easily.

Overview of the Thesis

The block diagram depicted in Figure 1 orients the reader to the system components and the communication paths between them. The main body of the thesis describes these components and communication paths in detail. The remainder of the report is outlined below.

In order to establish a common base to work from, some basic concepts of the UNIX operating system are presented in chapter two. This includes a description of the UNIX File.

System, the UNIX I/O System, and process management.

Chapter three describes in detail how UNIX processes user program requests for peripheral device I/O, how it deals with device drivers, and how it processes interrupts from peripheral devices.




Fig 1. Organization of Major System Components

The VG is described down to the register level in chapter four. This is necessary because the device driver deals mainly with reading and writing the VG's internal registers.

Chapter five is a description of the hardware interface between the PDP11/60 and the VG graphics device. All data and control communication between the PDP11/60 and the VG take place via this interface.

The device driver software is documented in chapter six.

This includes a specification of the overall requirements,
a description of the software design, an a detailed discussion
of implementation details. The discussion on driver implementation includes both user level implementation and documentation of the driver routines in their final state, e.g.,
after updating for UNIX version seven and trimming to meet
space limitations.

Chapter seven describes the changes made to McCallum's original driver to make it compatible with AFIT's system.

The procedure for installing the device driver is described in detail in chapter eight.

The software testing methodology is described in chapter nine. All of the tests performed on the driver software are also included.

Finally, conclusions and recommendations are given in chapter ten.

II Preliminary Concepts

A detailed knowledge of certain aspects of the UNIX operating system is required for developing and installing peripheral device driver software on the system. In order to gain this detailed knowledge, the basic concepts must first be understood.

This chapter presents a discussion of some basic UNIX concepts. Emphasis is placed on those concepts that will aid the reader in understanding the more detailed UNIX concepts presented in subsequent chapters. The main ideas covered here are the UNIX file system, the UNIX I/O system, and process management.

The UNIX File System

Ritchie and Thompson have stated, "the most important role of the system is to provide a file system" (Ref 13:2). UNIX supports a hierarchical disk based file system composed of three different kinds of files: ordinary, directory, and special. Each of these files is stored as a one dimensional array of bytes. Structure within these files is controlled by the programs that use them and not by the system.

Ordinary files, directory files, special files, file system hierarchy, file path names, and file system implementation are discussed in this section.

Ordinary Files. Ordinary files can be created by any user. They contain whatever the user puts in them, e.g., data, source programs, object (binary) programs, etc. Access per-

mission to ordinary files is controlled by the file owner and/or by the super-user, i.e., the person in charge of maintaining the entire system.

Directory Files. Directory files are maintained by the system. They can only be written by the system. A user program may not open a directory file for writing. Directories may contain names of ordinary files, special files, and other directory files. For each file name entry, the directory maintains a pointer, called the i-number (for index number), to the information actually describing the file. In other words, each directory entry provides a mapping between a file name and the actual file. The i-number will be described later in detail.

Special Files. A special file is a file that has been associated with an I/O device. By UNIX convention, these files all reside in directory /dev. User programs access I/O devices through references to the special files associated with the I/O devices. User programs may open, close, read, and write special files as if they were ordinary disk files. When special files are referenced from a user program, the system calls the appropriate device driver routine to activate the associated device (Ref 13:3). This is a key concept in this thesis because the VG graphics device has four of these special files associated with it for I/O purposes. These four special files are described in detail in chapter six.

File System Hierarchy. Directories are maintained by




Fig 2. File System Hierarchy

example of such a rooted tree is illustrated in Figure 2. In this figure, as with the UNIX file system, the root directory is denoted by a slash character, "/". The root directory contains the files alpha and sigma. Alpha is also a directory file containing files beta and delta. Beta is a directory file containing file gamma. All non-leaf files in the rooted tree are directory files. Files delta, gamma, and sigma could be either ordinary, special, or empty directory files.

Many of the higher level directories in the file system hierarchy are reserved for system use. They contain system commands, UNIX source and object files, utility programs, etc.

The super user adds directories to the file system for each user. These directories may be added to any level of the hierarchy. They are created for the user's own files. Users manage files within their respective "home" directories through the use of system calls. They may do such things as add and remove files from their own directories. They may also create and manage sub-directories attached to their original home directories.

<u>File Path Names</u>. A file may be specified to the system in terms of its path name. Ritchie and Thompson describe this concept well.

"When the name of a file is specified to the system, it may be in the form of a path name, which is a sequence of directory names separated by slashes, "/", and ending in a file name. If the sequence begins with a slash, the search begins in the root directory. The name /alpha/beta/gamma causes the system to search the root for directory alpha, then search alpha for beta, finally to find gamma in beta. Gamma may be an ordinary file, a directory, or a special file. As a limiting case, the name "/" refers to the root itself." (Ref 13:3)

If the path name does not start with a "/" then the system begins searching in the user's current directory. When a user logs onto the system, the user's assigned home directory becomes the current directory. The current directory may be changed through use of the change directory system call, cd(1).

<u>File System Implementation</u>. A detailed description of the implementation of the UNIX file system is given by Thompson and Ritchie (Ref 13:6-7 and 16:7-9). The main ideas are presented here.

The system maintains a list of file definitions called the "i-list". This list resides on secondary storage (usually on disk) and consists of one "i-node" for each file that exists in the file system. The integer offset of an i-node in the i-list is called the i-number. It is used for referencing the i-node and is stored in a directory along with the file name associated with the i-node.

Each i-node contains all the information needed to define a file, such as; the type of file, access permissions, the number of links to the file, etc. (Ref 13:6) For non-special files, the i-node contains information about where the file resides on disk (Refs 13:6 and 16:7). For special files, the i-node contains a device class and a device name. These are used by the system to invoke the appropriate device driver when a user program requests access to a special file.

Figure 3, adapted from Thompson (Ref 16:8), shows the data structures maintained by the system during file access. Each user process is allocated an open file table. This table contains pointers to entries in the system open file table.

As a user process is swapped in and out of core, its open file table is swapped along with it. The system open file table and the active i-node table are always resident in core. The i-list resides on disk.




Fig 3. File System Data Structure

To access an existing file, a user program must first "open" it via the open(2) system call. The file's pathname is specified as one of the input parameters for this call. The system uses the pathname to search the hierarchy of directories until the specified file name is found. Next, the i-number stored in the directory with the file name is The i-number is used to access the appropriate i-node. The system checks the file's access permissions (stored in the i-node) to verify that the requested access is legal. If it is, the system copies the disk version of the i-node into the active i-node table. A pointer to this active i-node table entry is entered in the system open rile table. A pointer to this system open file table entry is entered in the user's open file table. The integer offset of the entry just made in the user's open file table is called a file descriptor. It is passed back to the user program. The user program passes the file descriptor as an input parameter on all subsequent system calls requesting access to the open file.

The UNIX I/O System

This section begins with a description of basic I/O system calls. This is followed by a discussion of device classes and device names which are used during peripheral device I/O processing.

Basic I/O System Calls. A user program requests I/O through the use of the open(2), close(2), read(2), write(2), stty, and gtty system calls (see ioctl(2) for the stty and

gtty system calls). The open(2), close(2), read(2), and write(2) system calls may be used on both ordinary and special files, while the stty and gtty calls are only used on special files. The open(2) call opens a file for access while the close(2) call terminates access to a file. The open(2) call passes two parameters to the system; (1) the path name of a special file and (2) an access mode. If the access mode specified is 0 then the I/O request is for reading only. If the access mode equals 1 then the request is for writing only. If it equals 2 then the request if for both reading and writing. The open(2) call returns a file descriptor which must be used in subsequent I/O requests on the open file. The close(2) system call passes one parameter to the system; a file descriptor.

The read(2) and write(2) calls pass three parameters to the system; (1) the file descriptor obtained from the open(2) system call, (2) a pointer to a user buffer, and (3) the number of bytes requested. With the read(2) system call, up to the number of bytes requested are read into the user buffer. The system returns the number of bytes actually read. With the write(2) command, the number of bytes requested are written from the user buffer to the specified file. The number of bytes actually written is returned to the user program.

The stty and gtty commands are used to set and get characteristics of peripheral devices. These system calls each pass two input parameters to the sytem; (1) a file descriptor and (2) a pointer to a user buffer. The contents of the user buffer specify which device characteristics to set or get.

When a user program invokes one of these basic I/O system calls on a special file, the operating system activates the associated peripheral device via device driver routines. The device class, part of the device name, and the type of I/O system call determine which device driver routine is invoked. The appropriate device driver routine performs the requested I/O function on the peripheral device then returns control to the operating system which then returns control to the user program, passing back the appropriate data. Device classes and device names are now discussed.

Device Classes. Each I/O device falls into one of two categories; block oriented or character oriented. Block oriented devices are devices such as disk and tapes which deal with 512-byte blocks. All other devices are considered charater oriented. Therefore, the VG graphics device is a character oriented device.

Special files associated with block I/O devices are marked as block oriented, while those associated with character devices are marked as character oriented. This information is carried in each special file's i-node.

Device Names. The system assigns a device name to each special file. It is stored in the special file's i-node. The device name is made up of a major device number and a minor device number. These are stored in the i-node as a 16 bit computer word with the major number in the high order 8 bits and the minor number in the low order eight bits (Ref 14:1).

When a user program requests access to a special file, the file's device class, major device number, and the type of I/O request determine which device driver routine to invoke. The special file's minor device number is passed to the device driver routine as an argument (Ref 16:5).

Any meaning associated with the minor device number is assigned by the device driver routine itself. For example, if there are several identical I/O devices on a system, the minor device number could be used to indicate which one of the I/O devices to activate. Another example would be I/O devices composed of several sub-devices. In this case, the minor device number could be used to indicate which sub-device to activate.

Process Management

Ritchie and Thompson identify an "image" as a computer execution environment and a "process" as the execution of an image (Ref 13:8). Roughly speaking, a process may be defined as "a program in execution" (Ref 10:7-1).

UNIX allocates two data structures for each process on the system. They are the "proc" structure and the "user" structure. These structures make up part of the overall process image. A complete listing of each is included in Appendix A.

The Proc Structure. The proc structure for each process is permantly resident in core. This structure is defined in the UNIX source file /sys/h/proc.h. It contains information that must be accessible at any time, especially when the main part of the process image has been swapped out to disk. Lions

describes the information carried in the proc structure in his commentary on the UNIX operating system (Ref 10:7-2).

The User Structure. The user structure assigned to each process is swapped in and out of core with the swapable portion of the process image. At any given time, the only user structure in core is the one assigned to the process currently being executed. While in core the user structure is referenced as the "u" structure.

The u structure is defined in the UNIX source file /sys/h/user.h. It contains such information as user identification, parameters for I/O operations, file access control, system call parameters, and accounting information.

The u structure is accessed often during execution of a process. Each element of the u structure is accessed by stating the name of the structure, followed by the structure member operator '.', followed by the element name (Ref 7:120). For example,

u.u_base

is a reference to the element u_base of the u structure.

Both the UNIX operating system and the device driver routines access the u structure often while processing peripheral device I/O requests. The individual elements of the u structure needed for I/O processing are described throughout this report as needed.

Summary

Some basic concepts of the UNIX operating system were presented in this chapter. Emphasis was placed on those UNIX concepts that pertain to this thesis project. With these basic concepts as a foundation, the next chapter describes how UNIX processes user program requests for peripheral device I/O.

III Peripheral Device I/O

The UNIX operating system is the focal point for all peripheral device I/O processing. This chapter is a discussion of how UNIX processes user I/O requests and peripheral device interrupts. Emphasis is placed on character oriented peripheral devices. This will help the reader to understand how UNIX deals with the VG graphics device.

This chapter is divided into three sections. The first presents a high level discussion of the flow of control during I/O processing. This is intended to orient the reader to the overall role of the UNIX operating system in peripheral device I/O processing. The next section describes how user program I/O requests are processed. The last section describes how peripheral device interrupts are processed.

Flow of Control During I/O Processing

UNIX controls the processing of all user I/O requests and all peripheral device interrupts. The block diagram in Figure 4 illustrates the overall flow of control during I/O processing. When a user program requests I/O on a peripheral device, control is transferred to UNIX. First, UNIX executes the device independent routines needed for the I/O request, then it determines which device driver routine to invoke for the required device dependent processing. Next, the appropriate device driver routine is called. It performs the requested I/O function then returns control to UNIX. UNIX




Fig 4. Flow of Control During I/O Processing

finishes processing the I/O request then returns control to the user program. In terms of the components of Figure 4, the typical flow of control for processing a user I/O request is 1,2,3,2,1.

When a peripheral device signals an interrupt to the PDP11 processor, control is transfered to the interrupt vector in UNIX. The interrupt vector first transfers control to the UNIX assembly language interrupt handler which performs device independent interrupt processing. Next, the device dependent interrupt handler, which is part of the device driver software, is invoked. The device dependent interrupt handler processes the interrupt then returns control to UNIX. UNIX returns con-




Fig 5. I/O Processing Routines and Control Transfer Mechanisms

trol to whoever had it at the time the interrupt occurred. In terms of Figure 4, the flow of control for processing a peripheral device interrupt is 4,2,3,2.

Processing User Program I/O Requests

The portion of Figure 4 dealing strictly with processing user I/O requests is expanded in Figure 5 to show more detail. This figure illustrates the groups of routines called to process an I/O request and identifies the mechanisms used to transfer control between each group of routines. Control is transfered from the I/O system call to the UNIX trap handler routines via the system trap mechanism; from the UNIX trap handler routines to the UNIX I/O system call handler routines

via the system-call switch table; and from the UNIX I/O system call handler routines to the device driver routines via the device switch tables. The remainder of this section describes each group of routines and each switch mechanism starting with the user program and ending with the device switch tables. Much of this information is found in Lions' commentary on version six of the UNIX operating system (Ref 10:Chapters 9, 10, 11, 12, 15, 18, and 19). However, due to differences between UNIX versions six and seven some of the information presented here was obtained directly from the UNIX version seven source code. When this is the case, the appropriate UNIX version seven source file is referenced.

The device driver routines are not described in detail here. Chapter six is devoted to a detailed description of the VG device driver routines.

The <u>User Program and I/O System Calls</u>. A user program requests peripheral device I/O via the I/O system calls open(2), close(2), read(2), write(2), stty, and gtty (see ioct1(2) for stty and gtty). These I/O system calls each compile to a trap instruction followed by the call's input parameters listed in the order that they were specified in the call. For example, the system call

read(fildes, buffer, mode)

compiles to

trap 3
fildes
buffer
mode

The low order byte of the trap instruction is an integer system-call identifier which uniquely identifies which system call caused the trap (Ref 10:10-2). In the example above, the number 3 represents the system call identifier for a "read" system call. Later, the system call identifier is used as an index into the system-call switch table to fetch the address of the appropriate system-call handler routine.

The System Trap Mechanism. Traps occur as the result of events internal to the CPU (Ref 10:9-3). Several different classes of system events cause the CPU to trap. Some of the different classes are bus errors, illegal instructions, power failure, execution of a system call trap instruction, etc. (Ref 10:9-3). A trap vector exists for each different class of events. All of the trap vectors are defined in the source file /sys/conf/l.s. The version of this file used when the VG graphics device is configured on the system, /sys/conf/l.s.vg, is listed in Appendix B.

When a system event causes a trap to occur, the CPU immediately transfers control to the associated trap vector. This is the first step for processing the trap. The trap vector associated with system calls is illustrated in




Fig 6. System-Call Trap Vector

Figure 6. This trap vector begins at location 34 (octal) of low core (Ref 10:10-3). Initially, location 34 contains the assembly language "start" routine (see line 31, Appendix B). This is used when booting up the system, then location 34 is overlayed with the address of the assembly language trap routine. Location 36 contains the new processor status (PS) value to be used while handling the trap.

When the CPU executes a system call trap instruction, it immediately loads the program counter (PC) and the processor status (PS) word with new values taken from vector locations 34 and 36 respectively (Ref 10:10-3). The old PC and PS are automatically saved on top of the system stack.

The old PC value is pointing at the first word after the trap instruction, i.e., the first system call input parameter. Control is now transferred to the new address held in the PC, i.e., the address of the UNIX assembly language trap routine (Ref 10:10-3).

<u>UNIX Trap Handler Routines</u>. The UNIX trap handler routines consist of the assembly language trap routine located in source file /sys/conf/mch_i.s and the C language trap routine located in source file /sys/sys/trap.c.

When the assembler trap routine gets control, it first saves the new PS on top of the system stack. Lions states, "it is important to save the PS as soon as possible, before it can be changed, since it contains information defining the type of trap that occurred" (Ref 10:10-3). Next, the assembler trap routine saves important system registers on top of the stack so that they may be restored after the trap is processed. Finally, the C language trap routine is called.

First, the C language trap routine processes the parameters specified in the I/O system call. These parameters are fetched from the user program string in the following ways (Ref 10:12-2):

- 1. via the special register r0;
- 2. as a set of words embedded in the program string following the "trap" instruction;
- 3. as a set of words in the program's data area.

The open(2) system call parameters are passed from the user program using method 2 above. That is, the two parameters specified in the open(2) call are picked up from the

program string following the trap instruction. This is accomplished using the old PC value (fetched from the system stack) which is pointing at the parameter list. The parameters for the other five I/O calls are passed using a combination of methods 1 and 2 above. The first parameter of these five calls is placed in special register rO when the trap instruction is executed. The remaining parameters are picked up from the program string following the trap instruction.

The C language trap routine fetches all the system call input parameters by first fetching the unique identifier for the system call from the low order byte of the trap instruction (Ref 10:12-2). This integer identifier is used as an index into the system-call switch table (described later) to retrieve two pieces of information; the total number of parameters required for the system call and the number of those parameters that were passed through special registers.

After fetching all the parameters, the C language trap routine places them in the argument array, u.u_arg[], so that they may be retrieved later by the UNIX I/O system call handler routines. Depending on which I/O system call is made, u.u_arg[] contains one of the following sets of system call parameters.

- 1. For the open(2) system call:
 u.u_arg[0] = file pathname;
 u.u_arg[1] = access mode
- 3. For the read(2) and write(2) system calls:
 u.u_arg[0] = file descriptor;
 u.u_arg[1] = pointer to a user buffer;
 u.u_arg[2] = number of bytes to be read
 or written
- 4. For the stty and gtty system calls:
 u.u_arg[0] = file descriptor;
 u.u_arg[1] = pointer to a user buffer.

After the system call parameters are placed in the u.u_arg[] array, the C language trap handler calls the appropriate
UNIX I/O system call handler routine via the system-call
switch table.

System-Call Switch Table. The system-call switch table is defined in file /sys/h/sysent.h as an array of structures. The array is initialized in file /sys/sys/sysent.c. The following C code declares the array but does not dimension or initialize it.

Lines 1-4 define a structure named sysent which consists of three elements. The first element, sy_narg, is used to specify the total number of arguments needed for a particular system call. The element named sy_nrarg is used to specify the number of arguments passed through special registers such

Sysent Table			
index	sy_narg	sy_rarg	(*sy_call)()
•	•	•	•
•	•	•	•
•	<u> </u>	•	<u> </u>
3	3	1	read
4	3	1	write
5	2	0	open
6	1	1	close
•	•	•	· ·
•	•	•	•
<u> </u>	<u> </u>	<u> </u>	<u> </u>
31	2	1	stty
32	2	1	gtty
•	T	•	T
•			•
•			

Fig 7. System-Call Switch Table

as ro. The last element, (*sy_call)(), is a pointer to a function that returns an integer value (Ref 7:114-116).

Line five declares an undimensioned array of sysent structures. The array is also named sysent, which may cause some confusion. The sysent array is initialized in file /sys/sys/sysent.c to logically appear as a table with one row for each system call existing on the system. Figure 7 shows the table entries for the I/O system calls. Notice that the three elements of the sysent structure map directly onto each row of the table, thereby providing a means of retrieving data from the table. The table is indexed by the system call identifier obtained from the low order byte of the system call




Fig 8. Routines for Processing an open(2) System Call

trap instruction. The first two columns of the table were used by the C language trap routine to determine how many parameters to fetch and how many of them were passed in special registers. The third column of the table, which contains the addresses of the I/O system call handlers, is used by the C language trap handler to call the appropriate I/O system call handler.

I/O System-Call Handler Routines. The I/O system calls open(2), close(2), read(2), write(2), stty, and gtty cause the C language trap handler to invoke the I/O system-call handler routines open, close, read, write, stty, and gtty. Each of these system-call handler routines is described later.

Open. Figure 8 illustrates the system-call handler

routines invoked to process the open(2) system call. open routine, located in source file /sys/sys/sys2.c, first calls the "namei" routine (located in /sys/sys/nami.c) to convert the file pathname (system call parameter 1 retrieved from u.u arg[0]) into a pointer to an i-node. If the file has not been previously opened then namei makes a copy of the file's disk i-node in the active i-node table (Ref 10:18-3). This is accomplished via a call to the "iget" routine (Ref 10:18-3). Namei returns a pointer to the active i-node table entry. Next, open calls the "open!" routine passing it the pointer to the active i-node. Openl, located in source file /sys/sys/sys2.c, first checks file access permissions. it makes the appropriate entries in the system open file table and the user open file table. Finally, open1 calls the "openi" routine. Openi, located in source file /sys/sys/fio.c, retrieves the special file's device class and device name. The device class indicates whether to call the driver open routine via the character device switch table or via the block device switch table. The major device number, taken from the high order byte of the device name, determines which device driver open routine to invoke via the device switch table. The appropriate device driver open routine is called with the minor device number (taken from the low order byte of the device name) passed as an argument.




Fig 9. Routines for Processing a close(2) System Call

Close. Figure 9 illustrates the routines invoked to process a close system call. As stated by Lions, "the 'close' system call is used to sever explicity the connection between a user program and a file and thus can be regarded as the inverse of 'open'" (Ref 10:18-3).

The Close routine, located in source file /sys/sys/sys2.c, zeros out the appropriate entry in the open file table, i.u_ofile[], by fetching the file descriptor parameter from u.u_arg[0] and using it as an index into the open file table (Ref 10:18-4). Next, the close routine calls the "closef" routine. Closef, located in source file /sys/sys/fio.c, decrements the reference count to the file. If there are no




Fig 10. Routines for Processing the read(2) and write(2) System Calls

more references to the file then the system open file table entry is eliminated and the active i-node table entry is copied back to the i-list stored on disk. This is accomplished via a call to the "iput" routine (Ref 10:18-4). Finally, the closef routine invokes the device driver close routine via the appropriate device switch table. The minor device number is passed as an argument.

Read and Write. The read and write system call handlers are discussed together because they execute some common code.

Figure 10 illustrates the routines invoked to process the read(2) and write(2) system calls. The read and write routines, located in source file /sys/sys/sys2.c, simply call the

"rdwr" routine, passing a flag to indicate which routine made the call (Ref 10:18-4).

The rdwr routine, located in source file /sys/sys/rdwr.c, first checks the special file's access permissions to see if the read or write system call is permitted on that file. is accomplished by using the file descriptor input parameter to check the special file's access permissions stored in the special file's active i-node. Next, the rdwr routine loads u.u base with the address of the user buffer which was specified as the second input parameter of the system call. Next, u.u count is loaded with the number of bytes to be transfered, i.e., the third input parameter of the system call. Next, rdwr sets up the offset into the user buffer by loading u.u offset with the offset value obtained from the special file's active i-node. Finally, rdwr switches out to either readi or writei. These two routines are located in source file /sys/sys/rdwri.c. For character oriented special files, readi and writei simply switch out to the appropriate device driver read or write routines via the character device switch table.

Stty and Gtty. Figure 11 illustrates the routines called to process a stty or a gtty system call. The stty and gtty routines, located in source file /sys/dev/tty.c, each alter the u.u_arg[] array then call the "ioctl" routine. The u.u_arg[] array is altered because the ioctl routine expects a flag in u.u_arg[1] indicating whether the stty routine or the gtty routine made the call. Both stty and gtty alter the




Fig 11. Routines for Processing the stty and gtty System Calls

u.u_arg[] array in the same way. The data in u.u_arg[1] is moved to u.u_arg[2], then the appropriate identification flag is placed in u.u_arg[1]. After this has been accomplished, the ioctl routine is invoked. This routine is located in source file /sys/dev/tty.c.

For character oriented special files, ioctl simply calls the appropriate device driver ioctl routine via the character device switch table, passing both the minor device number and the identification flag retrieved from u.u_arg[1]. The identification flag lets the device driver ioctl routine know whether the call is a stty or gtty call.

Device Switch Tables. The UNIX I/O handler routines call

device driver routines via the system's device switch tables. Two such tables exist; the block device switch table (bdevsw) for block oriented devices and the character device switch table (cdevsw) for character oriented devices. In principle, the two tables are used in the same way. The cdevsw table is describe here.

The cdevsw table is declared in system source file /sys/h/conf.h and initialized in file /sys/conf/c.c. The following C code declares the table but does not dimension or initialize it.

Lines 1-8 define a structure named cdevsw. The structure consists of seven elements (lines 2-8). Each of the first six elements is a pointer to a function that returns an integer value (Ref 7:114-116). The last element is a pointer to a tty structure.

Line 9 declares an undimensioned array of cdevsw structures (Ref 7:124). The array is named cdevsw, which may cause some confusion because each of the structures making up the array is also named cdevsw. Since the array is not dimensioned, no storage is allocated at this point.

The initialization of array cdevsw is defined in file

/sys/conf/c.c. The version of this file used when the VG graphics device is configured on the system, /sys/conf/c.c.vg, is included as Appendix C. The array is initialized to logically look like a table with 23 rows (0-22) of seven elements each (see lines 53-79, Appendix C). Each row in the table is reserved for a different character oriented peripheral device. The first six elements in each row are the names of the device driver routines for a particular device, while the seventh element is a pointer to a tty structure associated with that particular device.

The seven elements of the cdevsw structure map directly onto the seven elements of each row of the cdevsw table. In this way each row element may be referenced by specifying the corresponding name from the cdevsw structure. For example, the code

cdevsw[22].d open

is a reference to the first element of row 22 in the character device switch table.

It has already been pointed out that the i-node for each special file contains a device class and device name. It has also been pointed out that the device class and major device number are used to determine which device driver routine to call. This concept is explained in detail here. The device class is either character or block. This indicates which switch table to use. The major device number is used as a row index into the appropriate table. For example, the i-node for

a special file associated with the VG graphics device contains a device class "c" (for character oriented) and a major device number 22. This information tells the system that the names of the VG driver routines are found in row 22 of the cdevsw table. Row 22 contains the entries vgopen, vgclose, vgread, vgwrite, vgioctl, nulldev, and 0 (see line 77, Appendix C). Nulldev indicates that there is no driver routine for the d_stop function, while the zero entry indicates that no tty structure is needed for the VG graphics device.

The following C language statement is a general example of how the UNIX I/O handler routines call device driver routines via the cdevsw table.

(*cdevsw[maj].d close)(dev);

In this example, assume "maj" contains the major device number and "dev" contains the minor device number obtained from a special file's active i-node. The statement evaluates to a function call on the device driver routine whose address resides in the d_close element of row maj in the cdevsw table. The minor device number in dev is passed as an argument.

The contents of the first set of parenthesis, *cdevsw

[maj].d_close, evaluates to the address of a device driver routine

The "*" is the C language indirection operator (Ref 7:89) and

the "." is the structure member operator (Ref 7:120). Logically,

*cdevsw[maj].d_close means get the value stored in the

d_close element of row maj of the cdevsw table. For maj = 22,

the code would return the address of the vg_close routine.


Once this address is fetched from cdevsw table, the vg_close routine is called with input parameter dev.

Summary. This section began with a very high level flow chart of how a user program I/O request is processed. Throughout this section the flow chart was expanded to show more detail. All of the routines discussed in this section are brought together in the form of a structure chart displayed in Figure 12. This chart represents all the main routines called to process user I/O system calls. Levels zero and one represent user level routines, levels two and three the trap handler routines, levels four through six the I/O system call handler routines, and level seven the generic device driver routines. The next section describes how peripheral device interrupts are processed by UNIX.

Processing Peripheral Device Interrupts

The high level flow chart for processing interrupts is expanded in Figure 13 to show more detail. This figure illustrates the types of routines called to process an interrupt and identifies the mechanism used to transfer control between each group of routines. An interrupt generated by the occurrence of an event on a periperal device causes a transfer of control to the UNIX interrupt handler routine via the device's interrupt vector. Control is transfered from the UNIX interrupt handler to the appropriate driver interrupt handler via the same interrupt vector.

The remainder of this section describes the peripheral



The second secon

The second secon

Main Routines Called During Peripheral I/O Processing F1g 12.

建设的




Fig 13. Interrupt Processing Routines and Control Transfer Mechanism

device events, the device interrupt vector, and the UNIX interrupt handler routine. The VG's device driver interrupt handler, vgint, is described in detail in chapter six.

Peripheral Device Events. As opposed to system traps, interrupts result from events external to the CPU. External peripheral device events generate interrupts to get the attention of the CPU. The CPU is deverted from whatever it was doing and redirected to execute another program to process the event that caused the interrupt (Ref 10:9-1).

A number of different events occurring on a peripheral device may generate an interrupt. Some typical ones are input, output, device errors, etc. The types of events that generate

interrupts are dependent on the type of peripheral device. Some peripheral devices may not have interrupt generating capability, while others may only support a few types of interrupts. Some devices support a wide range of interrupt generating events and even allow the user to "turn on" and "turn off" the interrupts for selected events (Ref 17:2-82 to 2-85).

The System Interrupt Mechanism. The system interrupt mechanism allows external devices to interrupt the CPU. Each device has an interrupt vector associated with it which is used to transfer control during interrupt processing.

Peripheral device interrupts are assigned a priority level 4, 5, 6, or 7. This priority is determined by the hard-ware (Ref 10:9-2). The processor also has a priority level associated with it from 0 to 7. This priority is carried in the current processor status (PS) word, bits 7 to 5 (Ref 10:9-2).

When a peripheral device generates an interrupt, the interrupt is inhibited as long as the processor priority is greater than or equal to the interrupt priority (Ref 10:9-2). When the processor priority becomes less than the interrupt priority, the interrupt is recognized. The processor then goes to the appropriate interrupt vector location to fetch new PS and PC values.

Different peripheral devices may have different interrupt vector locations. The location for a particular device is determined by hard wiring (Ref 10:9-2). The interrupt vectors on the PDP11/60 are located in low core and are defined in




Fig 14. Interrupt Vector for VG Display System

the source file /sys/conf/l.s. A complete listing of the version of this file used for the VG graphics device, /sys/conf/l.s.vg, is given in Appendix B. For the VG graphics device, the new PC and PS values are loaded from octal locations 374 and 376 respectively (see lines 60-61, Appendix B).

and Conti

The flow chart depicted in Figure 14 shows the transfer of control during interrupt processing. The VG graphic device's interrupt vector is used as an example. The processor loads new PC and PS values from the hard-wired vector location 374 and the word following that location, 376. After this step, the PC is pointing at a pair of interrupt handler calls (see line 84, Appendix B). The first is executed calling the UNIX

device independent interrupt handler. When this routine is finished, the device dependent interrupt handler, vgint, which is part of the device driver software, is invoked.

The UNIX Interrupt Handler Routine. The UNIX interrupt handler consists of some of the same assembly language code executed to process system traps. This code is located in file /sys/conf/mch_i.s. For processing traps, the entry point to the code is label "trap". For processing interrupts, the entry point is label "call" (Ref 10:9-3). As with traps, the assembly language code first saves appropriate information on the system stack to be restored later. The device driver interrupt handler is then called to process the device dependent aspects of the interrupt.

Summary

This chapter described how the UNIX version seven operating system processes both user program requests for peripheral device I/O and peripheral device interrupts. This information is useful when developing driver software that runs under UNIX version seven.

Now that peripheral device I/O has been described, the next chapter discusses the VG 3404 peripheral device.

IV The Vector General 3404 Graphics Display System

Overall Description


The Vector General 3404 graphics device is a sophisticated graphics display system made up of the following major functional components (Ref 17:1-1).

- 1. Computer Interface
- 2. Graphic Processor Unit (GPU)
- 3. Refresh Buffer Unit (RBU)
- 4. Display Control Unit (DCU)
- 5. Vector Generator Unit (VGU)
- 6. Font Generator Unit (FGU)
- 7. Monitor Control Unit (MCU)
- 8. Display Monitor(s)
- Display Input Device(s)
- 10. Options

Figure 15, derived from the Programming Concepts Manual (Ref 17:1-3), is a block diagram depicting the organization of the major functional components.

A user program builds a display list in the host computer's memory. This list is made up of instructions to be executed by the display system's Graphic Processor Unit (GPU). A complete list of the GPU instruction set is given in the System Reference Manual (Ref 18:3-7). The manual also provides a detailed description of each instruction (Ref 18:3-8 through 3-56).

After the display list has been built, the user program signals the GPU to start a one-time transfer of the display list from computer memory to the GPU via the computer interface. The GPU interprets the instructions in the display list and outputs a new list of elementary instructions called a



the second of th

かんしょう こうしゅん かんかん おおから はんかん かんしゅん

Fig 15. Display System Organization

PRINT OF THE PERSON

refresh list. The refresh list is stored in the display system's Refresh Buffer Unit (RBU). The refresh list is repeatedly sent from the RBU to the Display Control Unit (DCU). The DCU interprets the refresh list instructions and causes the Vector Generator Unit (VGU) to draw lines, the Font Generator Unit (FGU) to draw characters, and the Monitor Control Unit (MCU) to control the CRT (Ref 17:1-1).

The remainder of this chapter is divided into two sections. The first section is a brief description of each of the display system's major functional components. This is followed by a discussion of the display system registers accessable for command, control, and communication purposes. Emphasis is placed on a description of the registers dealing with the display system input devices.

<u>Functional Description of Major Display System Components</u>

The display system's major functional components are described in both the Programming Concepts Manual and the System Reference Manual (Refs 17:1-2 to 1-7 and 18:2-2 to 2-5). Each major component is briefly described here.

Computer/Display System Interface. All communication between the host computer and the display system takes place via a hardware interface. The next chapter is devoted to a detailed description of the hardware interface between the PDP11 and the VG display system.

Graphic Processor Unit. The GPU is a high-speed specialpurpose processor designed to handle complex algorithms such as transformations and other image manipulations. The GPU's instruction set consists of 47 basic instructions. User programs build display lists which consist of instructions from the GPU's instruction set along with any necessary data. The GPU fetches the user display list and associated data from the host computer's memory via a direct memory access (DMA) channel provided by the host computer/VG3404 hardware interface. The GPU processes the display list and outputs a refresh list to the RBU. Interaction between the GPU and RBU permits element selection and picking (Refs 17:1-2 and 18:2-2). All communication to and from the GPU takes place over the VG's Graphic Processor (GP) bus.

Refresh Buffer Unit. The RBU is made up of random access memory (RAM) and the control logic needed for reading and writing the RBU. The RBU may be continuously updated by the GPU over the GP bus.

The DCU accesses the RBU to update the displayed picture on the CRT screen. This takes place during each refresh cycle and does not interfere with the GPU updates to the RBU.

The RBU contains the necessary control logic to operate in double buffer mode. In double buffer mode, data may be moved from one buffer to the next when reorganizing the display refresh list for editing purposes.

Display Control Unit. The DCU fetches the refresh list from the RBU via the VG's MD bus. It processes the refresh list instructions and sends the appropriate refresh data to the VGU, FGU, and MCU. It also generates the control signals

that cause the VGU, FGU, and MCU to display the refresh data.

All of the communication between the DCU and the VGU, FGU,

and MCU takes place over the DCU bus.

Vector Generator Unit. As stated in the Programming Concepts manual, "the VGU is a high speed vector generator which provides the deflection signals required to draw a line from one point to another on the face of the CRT" (Ref 17:1-5). The VGU operates on the x-y coordinate data it receives from the DCU via the DCU bus. It has the capability of generating curved lines on the display using a smoothing technique. It also performs the spacing between character positions as the FGU displays text.

Font Generator Unit. The FGU receives character codes, scaling, font, and rotation parameters from the DCU via the DCU bus. The character codes used are from the set of 96 ASCII characters.

The FGU uses a programmed ROM in conjunction with "stroke" character draws to display the characters on the screen (Ref 18:2-4).

Monitor Control Unit. The MCU selects the desired CRT for display and provides the required unblanking and intensity signals for the monitor video channel.

Display Monitors. The VG 3404 will support up to six CRT monitors per MCU. Optionally, up to eight CRTs can be supported (REf 17:1-6). AFIT only has one monitor at present.

<u>Display System Input Devices</u>. At present, AFIT's VG display system does not support the joystick, control dials,

nor light pen input devices. Nor does it have any remote input devices. The basic local input devices supported on AFIT's system are the alphanumeric keyboard, function switch box, and data tablet. These input devices all generate interrupts to the host CPU when they require service.

Options. The options available on the VG 3404 are listed in the Programming Concepts Manual (Ref 17:1-7). They include such things as additional input devices, additional RBU/DCU sets, pick facility, color monitors, etc. Aside from the input devices already mentioned, AFIT's display system has no other options.

Display System Registers

The VG contains many registers that can be read and written by the device driver and user programs to control display processing and to pass data and status information back and forth between the host computer and the display system. Each of these registers has a unique address in the display system. Each register is associated with one of the VG's major functional units. The registers are divided into two categories; (1) GPU registers and (2) hardware and device registers. A complete list of GPU registers, along with a description of each, is given in the System Reference Manual (Ref 18:3-57 through 3-70). The hardware and device registers are listed and described in both the System Reference Manual and Volume one of the Technical Manual (Refs 18:5-1 through 5-20 and 20:2-1 through 2-23). The purpose here is not to

describe all of these registers. Users can learn the use of each register by studying the manuals. At this point, it suffices to say that the UNIX operating system and device driver software provide the capability for user programs to read and write any of the display system registers via the stty and gtty system calls. This capability is described in detail in chapter six.

The device driver software accesses some VG registers without being requested to do so by a user program. In particular, the device driver interrupt handler accesses the registers associated with the VG's input devices during interrupt processing. These registers are described in the Programming Concepts Manual (Ref 17:2-82 to 2-85). Only the input devices on AFIT's system are described here.

Data Tablet Registers. Three registers are associated with the data tablet. They are illustrated in Figure 16a. The display system addresses for these three registers are 1600-1602 (Ref 18:Appendix C).

The first two registers, DTX and DTY, hold the X and Y stylus positions respectively. These values are stored in the form of signed twos complement integers in the leftmost ten bits of the registers. These values are updated constantly as the stylus is moved around the data tablet.

The third register, DTS, holds control and status information. The XOS and YOS bits indicate that the stylus is out of bounds on the data tablet surface in the X and/or Y directions respectively. The PNN bit indicates the stylus




Fig 16. Input Device Registers

is within the "near" zone above the tablet. The PRS bit indicates the stylus switch is depressed. The IEN bit is set to enable interrupts generated by a change in the XOS, YOS, PNN, or PSS bits. It is set by the device driver program when a user program requests use of the VG data tablet.

Function Switch Box Registers. Three registers are associated with the function switch box. They are depicted in Figure 16b. Their addresses are 1604-1606 (Ref 18:Appendix C).

The sixteen bits of the first register (FSLO) correspond to the function switches S00-S15 and their respective lamps, L00-L15. The sixteen bits of the second register (FSL1) correspond to function switches S16-S31 and their respective lamps, L16-L31. The meaning of these two registers depends on whether they are being read or written by the device driver software. When reading, these two registers provide input data from the 32 function switches S00-S31. Every function switch depressed before the read causes the corresponding register bit to be set (Ref 17:2-83). When writing to these registers, all bits set to one turn the corresponding lamps (L00-L31) on.

The third register, FSKC, is for control and status. The IEO and IEl bits enable interrupts from the two switch groupings, S00-S15 and S16-S31 respectively. These bits are set by the device oftware when a program requests use of the function switches. SDO and SD1 are sense bits which indicate a switch is latched in the S00-S15 and S16-S31 groups respectively. The LDO and LD1 bits can be set to cause latching of all switches depressed in the S00-S15 and S16-S31 groups respectively. The latched data is cleared from FSLO and FSL1 registers each time they are read by the device driver.

Alphanumeric Keyboard Register. One register is associated with the alphanumeric keyboard input device. It is illustrated in Figure 16c. The display system address for this register is 1607 (Ref 18:Appendix C).

The eight bit DATA field holds the ASCII code of the key

depressed. The KIE bit enables interrupts for the keyboard. This bit is set by the device driver when a user program requests use of the keyboard. The KDV bit is set by the display system each time a key stroke has been latched in the data field. Reading the data field clears the KDV bit and allows another keystroke entry (Ref 17:2-84).

Summary

This chapter presented a functional description of the major components of the display system (except for the computer/VG3404 hardware interface component). A detailed description of the display system registers associated with AFIT's VG input devices was also given. The next chapter describes the PDP11/VG3404 hardware interface in detail.

V The PDP11/VG3404 Hardware Interface

Communication between the PDP11/60 computer and the Vector General 3404 graphics display system is established via the DE41 hardware interface (Ref 19). As stated in the DE41 reference manual, "this unit interfaces between the Unibus of any PDP11/60 computer and the General Purpose IO Bus of the NPL display controller" (Ref 19:3).

The interface provides four sixteen bit registers that can be directly addressed by the VG device driver running in the host computer. These are the Status, Control, Data, and Base Address registers. Using these four registers, the interface recognizes four input instructions and four output instructions. These eight interface I/O instructions, together with the four addressable interface registers, establish three channels of communication between the host computer and the VG display system. These three channels are the direct memory access channel (DMA), the interrupt channel (INT), and the programmed I/O channel (PIO). These three channels are illustrated in Figure 17 taken from the Programming Concepts Manual (Ref 17:2-2).

First, a detailed description of how to access the four interface registers from the device driver program in the host computer will be given. This is followed by an explanation of the use of the interface's eight I/O instructions.

Finally, communication on the DMA, INT, and PIO channels is described.




Fig 17. Interface Communication Channels

Accessing the Interface Registers

The interface's Status, Control, Data, and Base Address registers can be directly addressed by the VG device driver software executing in the host computer. These special registers are assigned physical addresses 0763400, 0763402, 0763404, and 0763406 from the highest page of the host computer's core memory. This is done because the highest page of core memory (addresses 0760000 to 0777777) is reserved for special registers associated with the processor and the peripheral devices (Ref 10:2-5).

Addresses from the highest page of the virtual address space (0160000 to 0177777) are mapped directly to the

addresses of the highest page of the physical address space (Ref 10:2-5). Therefore, the interface's Status, Control, Data, and Base Address registers have virtual addresses 0163400, 0163402, 0163404, and 0163406 respectively. These virtual addresses are used in the device driver software to access the interface registers. The system takes care of mapping these sixteen bit virtual addresses to their eighteen bit physical addresses by adding in a base address obtained from the appropriate page register. Address mapping is described in detail in the section on the DMA channel.

The interface registers can be easily accessed from the device driver software. First, it is helpfull to associate meaningful names with the register addresses. This is accomplished in the C language with the "#define" macro substitution (Ref 7:86). The following C code was placed at the beginning of the device driver to associate names with the interface register addresses.

- 1. #define VG STAT 0163400
- 2. #define VG_CONT 0163402
- 3. #define VG_DATA 0163404
- 4. #define VG BAR 0163406

These statements tell the macro preprocessor, which is not part of the compiler proper, to replace all subsequent occurrences of the names VG_STAT, VG_CONT, VG_DATA, and VG_BAR with character strings 0163400, 0163402, 0163404, and 0163406 respectively.

VG_STAT, VG_CONT, VG_DATA, and VG_BAR are simply pointer

values to the interface's Status, Control, Data and Base
Address registers. In order to access the contents of the
interface registers, the pointer values to the registers must
be dereferenced (Ref 10:5-5). That is, the contents of the
referenced location are desired instead of the reference
itself. This is accomplished in the C programming language
by creating a dummy structure consisting of one element,
named "reg" (abbreviation for register), which is declared
as type integer. The code

struct { int reg; };

is used in the device driver program (see line 99, Appendix D) to describe the dummy structure. This code does not cause storage to be allocated, it simply describes a template or the shape of a structure (Ref 17:120). A reference to the "reg" element of this template can be made using the structure pointer operator "->" (Ref 7:122).

The contents of the interface registers are accessed by specifying the appropriate pointer value (VG_STAT, VG_CONT, VG_DATA, or VG_BAR) connected to the "reg" element of the dummy structure by the "->" operator. To the C compiler, the code "VG_STAT->reg" means that 0163400 is the beginning address of an occurrence of the dummy structure. Since "reg" is the first and only element of the structure, its address is also 0163400. Therefore, the code "VG_STAT->reg" simply stands for the contents of address 0163400, i.e., the contents of the interface's Status register. The codes

"VG_STAT->reg", "VG_CONT->reg", "VG_DATA->reg", and
"VG_BAR->reg" cause four separate occurrences of the dummy
structure template to be overlayed on virtual memory at virtual addresses 0163400, 0163402, 0163404, and 0163406. The
result of this code is represented pictorially in Figure 18.

The four interface registers are all read and written in the same way. For example, the C code statement

VG_DATA->reg = expression;

is used to load the interface's Data register. The word
"expression" on the right side of the assignment operator
can be a constant, variable name, function call, or any other
legal C language expression. To read the same register the
code

data = VG_DATA->reg;

is used; where "data" stands for some variable name.

The Interface's Eight I/O Instructions

Using the four addressable registers described above, the interface recognizes four input instructions and four output instructions (Ref 19:5). These are Status In and Status Out, Control In and Control Out, Programmed In and Programmed Out, and BAR In and BAR Out. The device driver executes these instructions by reading and writing the four addressable interface registers. All of the commands are executed over the interface's PIO channel. However, many of




Fig 18. Using a Dummy Structure to Access the Contents of the Interface Registers

these instructions affect communication on the DMA and INT channels.

At this point it is worthwhile to mention that the four input instructions send input from the interface to the device driver, while the four output instructions send output to the interface from the device driver. In other words, the interface sends input to the device driver program and receives output from the device driver program.

A detailed description of the interface's eight I/O instructions can be found in the DE41 reference manual (Ref 19:5-7). A brief description of the purpose of each of the eight instructions is given here.

The Status In instruction (Ref 19:5) is used to obtain the ID of the last unit (within the VG display system) that interrupted the PDP11 processor. The Status Out instruction is used to restore the contents of the interface's Input Buffer Register (INR) after an interrupt has been processed.

Depending on which bits are set, the Control In and Control Out instructions (Ref 19:6) accomplish different tasks. Control In can be used to test whether the interface power is on, whether an input operation requested by the device driver program has been completed, or whether an output operation initiated by the device program has been completed. The Control Out instruction can be used to initialize the interface, enable new interrupt requests from the VG display system, acknowledge interrupts received from the VG display system, specify the address of a VG register so

that it may be read or written, or request input from a VG register.


The Programmed In instruction (Ref 19:7) reads the contents of the interface's Input Buffer Register (INR). Programmed Out writes data to the VG register whose address was specified by the last Control Out instruction with the Register Change (RC) bit set.

The BAR In instruction (Ref 19:7) is used to read the interface's Base Address Register. BAR Out (Ref 19:7) is used to load the interface's Base Address Register. The function of the interface's Base Address Register is described in detail in the section on the DMA Channel.

Channel Communication

As mentioned earlier, the eight interface I/O instructions, together with the four addressable interface registers, are used to establish three channels of communication (DMA, INT, and PIO) between the host computer and the VG graphics device. The block diagram in Figure 19 illustrates which system components use each of the three channels. Communication may occur concurrently on all three of these channels (Ref 17:2-2). The purpose of this section is to describe what type of information flows over each channel, and how that flow of information is controlled.

The DMA Channel. The DMA channel is described in the Programming Concepts Manual (Ref 17:2-3). Primarily, the channel is used to pass the user defined display list from



Communication Channel Usage

の知代の本本なる。

the host computer to the GPU in the display system. As the GPU processes the display list, it may fetch and/or store data in the host computer memory as required by the display list instructions. This data transfer also takes place over the DMA channel (Ref 17:2-3).

Memory addresses for DMA transfer are formed in the hardware interface by mapping 16 bit virtual addresses to 18 bit physical addresses. This is accomplished by adding the contents of the interface's Memory Address Register (MAR) to its Base Address Register (BAR). This address mapping is described in detail in the DE41 interface manual (Ref 19:13).

Before address mapping can take place, the BAR must be loaded with the proper base address. This address is obtained from a segmentation register in the host computer. The segmentation register used depends on whether the UNIX operating system has assigned the user program a sharable text segment or not.

If the user program has not been assigned a sharable text segment then the space allocated for the program to run is guaranteed to be mapped into contiguous memory and to begin at the zeroth page of the user's virtual address space. In this case the value loaded into the BAR is taken from the first User Instruction Space Address Register (UISA) located at virtual address 0177640 on the PDP11/60 (Ref 11:3).

If the user program has been assigned a sharable text segment, then the user space might not be mapped onto contiguous memory. In this case, the pointer to the user's

text segment, u.u_procp->textp (see line 452, Appendix D), is used to calculate which segmentation register to use for loading the interface's BAR.

The VG device driver program checks for the two cases described above, then loads the BAR from the appropriate segmentation register with the BAR Out instruction. The code that accomplishes this task is discussed in the next chapter.

Once the BAR has been loaded, memory reads and writes can take place over the DMA channel. The following sequence of steps occur during a memory read (Ref 19:9).

- 1. The GPU requests use of the GP bus for a delayed data transfer.
- 2. Once the request is granted, the GPU sends a virtual memory address over the GP bus to the hardware interface's MAR.
- 3. The interface maps the 16 bit virtual address stored in the MAR to an 18 bit physical address. The base address stored in the interface's BAR is used during address mapping.
- 4. The hardware interface uses the 18 bit physical address to access PDP11 memory (via the UNIBUS) for the requested data. The retrieved data is placed in the interface's Input Buffer Register (INR).
- 5. Next, the interface requests the GP bus for a second data transfer. When the request is granted, the data is transferred from the interface's INR to the GPU.

Steps 1, 2, and 3 are the same for a memory write operation. Steps 4 and 5 are changed. The changes are listed below.

- 4. The interface reads the data from the requesting unit and places it in its INR. This is a separate GP bus transfer.
- 5. The interface uses the 18 bit physical address formed in step 3 to write the data from its INR to PDP11 memory (via the PDP11 UNIBUS).

Information flow on the DMA channel is controlled by interface I/O commands executed on the PIO channel, the content of the user defined display list, and the occurence of events within the display system. Commands sent over the PIO Channel may start and stop the transfer of the user defined display list from computer memory to the GPU. Instructions within the display list may alter the normal sequential processing from computer memory. The occurrence of a display system event, such as an interrupt from a display system input device, temporarily halts display list processing (Ref 17:2-3).

The Interrupt Channel. The Interrupt (INT) channel is described in the Programming Concepts Manual (Ref 17:2-3 to 2-4). The channel is used to signal interrupts to the PDP11 processor from the VG display system. A number of different events on the display system may generate interrupts. For example, keyboard, function switch, and data tablet inputs are all display system events that generate interrupts to the PDP11 processor. An interrupt is processed by the following steps (Ref 19:10-11).

1. A sub-unit of the VG display system signals an interrupt to the interface.

- 2. In accordance with priorities, the interface grants the GP bus to the requesting unit.
- 3. The requesting unit transfers a 6-bit interrupt identification to the interface's interrupt Identification Register (IDR). Subsequent interrupt requests are not honored by the interface until the current one is acknowledged by the device driver software.
- 4. The interface raises a priority level four interrupt request to the PDP11 Central Processor Unit (CPU).
- 5. In accordance with priorities, the CPU invokes the interrupt handler which is part of the device driver software.
- 6. First, the device driver interrupt handler, vgint, disables interrupts. Next it reads the interrupt ID from the interface's IDR to determine which VG sub-unit generated the interrupt.
- 7. As soon as the interrupt handler has acquired the interrupt ID from the IDR, it issues a Control Out instruction to set the interrupt acknowledge (ACK) bit in the interface's Control register. This acknowledges the interrupt and permits IDR to be changed by subsequent interrupts.
- 8. The interrupt handler performs the function required for the sub-unit that generated the interrupt then enables interrupts and returns.

The Programmed Input/Output Channel. The PIO channel is described in the Programming Concepts Manual (Ref 17:2-4 to 2-7). This channel is a bi-directional data path between the device driver software and the display system. The input path is from the display system to the device driver. The device driver controls the channel in both directions through the eight interface I/O instructions. The Programming Concepts Manual lists the following uses of the PIO channel (Ref 17:2-4).

- 1. Acquire status information.
- 2. Initialize the interface.
- 3. Read and write display system registers.
- 4. Start transfer of the user display list.
- 5. Control, categorize and acknowledge interrupts

The remainder of this section describes each of these capabilities.

Status information can be obtained about both the interface and the display system over the PIO channel. The interface's Control In instruction can be used to check for power on. Other status information about the display system is obtained by reading the appropriate display system registers.

The interface is initialized by executing a Control Out with the initialize (INIT) bit set (Ref 19:6). This is one of the first things done by the device driver.

Display system registers can be read and written over the PIO channel with the Programmed Input (PIN) and Programmed Output (POUT) routines. These routines are not to be confused with the Programmed In and Programmed Out instructions. PIN and POUT are invoked by the device driver to read and write display system registers, while Programmed In and Programmed Out are used by the device driver to read and write interface registers.

The PIN routine performs the following sequence of events (Ref 19:8)

1. Issue a Control Out setting the Control register's Request Input (RQI) bit equal to one, its Register Change (RC) bit equal to one, and its Register Number (RN) field equal to the address of a display system register. This causes the interface to

request data from the specified register. The data is transfered over the display system's GP bus. As long as the interface is still searching for the data, the Input In Process (IIP) bit is equal to one.

- 2. When the IIP bit equals zero, the requested data has been loaded into the interface's INR.
- 3. The data is read from INR with a Programmed In instruction.

The POUT routine consists of the following sequence of events.

- 1. Issue a Control Out setting the Control register's RC bit and loading its RN field with the address of the desired display system register.
- 2. The output data is loaded into the interface's Data register with a Programmed Out instruction.
- 3. Wait for the output process to complete by sensing the Output In Progress (OIP) bit of the interface's Control register. When it changes to zero the output process has been completed.

The PIO channel is used to start transfer of the user display list. First, a Programmed Out instruction is executed to load the interface's Base Address Register. Next, the POUT routine is used to load the GPU's Directory (DIR) and Picture Base Object (PBO) registers. Finally, the POUT routine is used to load the GPU's Command (CMD) register with the commands that cause the GPU to fetch the display list from computer memory (Ref 18:4-3).

A very important function of the PIO channel is the control, categorization and acknowledgement of interrupts (Ref 17:2-5). General interrupt handling can be enabled and disabled with the Control Out instruction. The POUT routine can be used to enable and disable particular types of

interrupts by writing the appropriate value to the appropriate display system register. Interrupts are categorized by first obtaining the interrupt ID over the PIO channel using the Status In instruction. Interrupts are acknowledged over the PIO channel by invoking the Control Out instruction to set the Interrupt Acknowledge (ACK) bit in the interface's Control register.

Summary

This chapter described the hardware interface's four addressable registers, eight I/O instructions, and three communication channels.

Now that peripheral device I/O, the VG display system, and the PDP11/VG3404 hardware interface have been described, the device driver routines can be explained. This is accomplished in the next chapter.

VI The VG Device Driver

This chapter specifies the requirements for the VG device driver, describes the overall driver design, and documents the implementation of the driver.

Requirements

The VG device driver obtained from the University of

Texas at Austin met certain requirements. This section iden
tifies the original requirements then specifies the require
ments adopted for AFIT's version of the device driver.

Original Requirements. The VG device driver obtained from the University of Texas was required to support two different levels of graphics. These two levels are depicted in Figure 20 (Ref 12:31).

With the level two graphics, the user display list consists of powerful GPU instructions. The GPU takes the instructions from the user display list and transforms them into a set of more fundamental instructions to be used by the DCU for display generation. The GPU performs the required two and three dimensional rotation, translation, windowing, clipping, curve generation, scaling, and sub-object definition management.

With level one graphics, the GPU is bypassed and the user display list is written directly into the RBU. This means that the user display list must consist only of the fundamental instructions understood by the DCU. This implies that the user program is responsible for performing all trans-




Fig 20. McCallum's Two Levels of Graphics Support

formations before building the display list. In order to support the level one graphics, a special DCU/RBU driver was installed. This driver provided the capability of reading and writing the RBU directly.

Another main requirement for the original driver was compatibility with the UNIX version six operating system. This included utilization of the standard UNIX interface for character oriented devices and support of the standard UNIX I/O system calls; open(2), close(2), read(2), write(2), stty, and gtty.

The original driver was also required to support the input devices available on the VG display system at the University of Texas. These consisted of a function switch box, an alphanumeric keyboard, and a light pen. Even though the original driver only incorporated the routines required for handling the available input devices, it was designed so that other input device handlers could be easily added.

The original driver provided most user programs the capability of reading and writing any addressable display system register. This capability is very important because the user program has to be able to load command and control information into display system registers. The user program must also be able to fetch display system status information and other data from display system registers. In conjunction with reading and writing display system registers, the original driver also allowed user programs to set and get certain device characteristics.

Requirements for AFIT'S VG Device Driver. Since a major objective of this thesis was to use as much of the original driver as possible, most of the original driver requirements were adopted for AFIT's version of the driver. Any changes that were made to the original requirements were mostly due to differences in the configuration of AFIT's system.

It was decided to not support the original requirement for a level one graphics capability. The main reason for this decision was that the original driver would not fit on AFIT's PDP11/60 due to limited space on the system. The level one graphics capability was selected for elimination because it did not use the display system's most powerful asset, the GPU. Elimination of the level one graphics did not degrade the system's capabilities, whereas elimination of the level two graphics would have limited the system's capabilities severely.

Another main requirement for AFIT's VG driver was compatibility with version seven of the UNIX operating system. To meet this requirement, some changes had to be made to the original driver. These changes are described in the next chapter.

AFIT's device driver was required to support the input devices available on AFIT's VG display system. These include the function switch box and alphanumeric keyboard supported by the original driver, plus the data tablet available on AFIT's system. Since the light pen was not available on AFIT's system, its interrupt handler was removed from the driver to conserve space. The ability to easily add new in-

put devices to the system was maintained with AFIT's device driver.

The same UNIX I/O system calls that were supported by the original driver are also supported by AFIT's version of the driver. Although, the routines supporting the stty and gtty system calls had to be completely rewritten due to changes in the way UNIX version seven handles these calls.

Overall Design

The driver was designed in a top-down structured approach to facilitate programming and maintenance. It was designed for easy addition of more VG input devices such as the joy-stick and control dials.

The driver was designed around four sub-devices (also called minor devices) of AFIT's display system; the GPU, data tablet, alphanumeric keyboard, and function switch box. These minor devices were assigned minor device numbers 0, 1, 2, and 3 respectively. The structure chart in Figure 21 illustrates the routines needed to process user program I/O requests on the four minor devices and the routines needed to process interrupts generated by the four minor devices.

The UNIX routines represented by level zero of the structure chart were described in chapter three. The routines in level one of the structure chart are the major device routines called by UNIX. The major device routines call the minor device routines in level two of the structure chart.

The open(2), close(2), read(2), and write(2) system calls cause UNIX to call major device routines vgopen,




Fig 21. Device Driver Design

THE STREET

vgclose, vgread, and vgwrite respectively. The stty and gtty system calls cause UNIX to invoke the vgioctl major device routine. All of these major device routines are passed a minor device number which determines which minor device routines to call. For example, the I/O system call

open("/dev/gpu", mode);

causes UNIX to invoke the major device routine vgopen,
passing it minor device number zero (for the GPU minor device).
This minor device number causes vgopen to call minor device
routine gpopen.

Display system interrupts cause UNIX to invoke the vgint routine. This routine determines which minor device generated the interrupt, then calls the appropriate minor device interrupt handler.

A new minor device can be added to the system by simply adding the new minor device routines to level two of the structure chart. For instance, if a joy stick input device is added to the sytem then minor device routines jsopen, jsclose, jsread, jswrite, and jsintr could be easily added to appropriate places in level two of the structure chart. A new character oriented special file, "/dev/jst", would be created with minor device number equal to 4.

With the overall design in mind, the implementation details are now presented.

<u>Implementation</u>

This section first describes the user level implementation details. This is followed by a complete description of the driver routines.

User Level Implementation. A character oriented special file was created for each of the VG minor devices (see Chapter VIII for details on creation of these special files). These files were named gpu, dtb, kbd, and fss for the GPU, data tablet, alphanumeric keyboard, and function switch box respectively. These four special files were created with major device number 22 which is the major device number associated with the VG display system. Minor device numbers 0, 1, 2, and 3 were assigned to the gpu, dtb, kbd, and fss special files respectively.

The four special files were all attached to the /dev directory. Therefore, they have pathnames /dev/gpu, /dev/dtb, /dev/kbd, and /dev/fss. A user program requests I/O on a VG minor device by first specifying the pathname of the associated special file as an input parameter to the open(2) system call. This opens the specified VG minor device for access. The open(2) system call returns a file descriptor to the user program to be passed as an input parameter on all subsequent I/O requests on the special file associated with the minor device. When finished with the minor device, the user program closes the associated special file by passing the file descriptor as an input parameter to the close(2) system call. The specific details of user program I/O on

each of the four minor devices is presented next. All examples are given in the C programming language.

The GPU Minor Device. The GPU minor device is accessed via the special file /dev/gpu. User program I/O requests performed on this file are described here.

Open /dev/gpu. The /dev/gpu special file is opened for I/O access via a C language statement of the form

gpufd = open("/dev/gpu",2);

where gpufd (gpu file descriptor) represents a variable of type integer. The open(2) system call returns a file descriptor which is placed in variable gpufd. This file descriptor is used with all subsequent I/O requests on file /dev/gpu.

 $\frac{\text{Read }/\text{dev/gpu}}{\text{dev/gpu}}. \quad \text{The }/\text{dev/gpu} \text{ special file is}$ read by a C language statement of the form below. The statement

m = read(gpufd,addr,n);

requests that n bytes be read from the VG display system's RBU and placed in a user buffer that has starting address addr. The number of bytes actually read is placed in integer variable m.

Write /dev/gpu. The write(2) system call is not supported on the GPU minor device. Therefore, an I/O error is flagged if a user program invokes the write(2) system call on special file /dev/gpu.

Stty /dev/gpu. When invoked on special file /dev/gpu, the stty system call is used to either write to a display system register addressed by the user or invoke one of five special functions. The form of the call is

```
stty(gpufd,info);
```

where gpufd is an integer variable containing the file descriptor that was returned when the GPU minor device was opened and info is the beginning address of an integer array of length three (int info[3]).

To write to a display system register, info[0] is loaded with the register address and info[1] is loaded with the data to be written. Next, the stty system call is invoked. The following statements illustrate how the call is invoked.

```
info[0] = display system register address;
info[1] = data;
stty(gpufd,info);
```

Five special functions may also be invoked with the stty system call. The following statements illustrate how a special function is invoked.

```
info[0] = function identifier;
info[1] = data (if required);
info[2] = data (if required);
```

Table I summarizes the five special functions available.

AIR FORCE INST OF TECH WRIGHT-PATTERSON AFB OH SCHOO--ETC F/0 9/2 A UNIX BASED DEVICE DRIVER FOR THE VECTOR GENERAL 3404 GRAPHICS--ETC(U) MAR 82 B R STEWART NL STEFFCES/MA/81D-6 NL AD-A115 582 UNCLASSIFIED 2-3

Table I. Stty Special Functions

info[0]	info[1]	info[2]			
Function Identifier	Data	Data	Function Performed		
-1	RBU Address	Value	Store value at RBU Address		
-2	-	-	Perform RBU reset		
-3	-	-	Suspend GPU processing of user's display list		
-4	.=	-	Restart GPU processing of user's display list		
- 5	Integer value from 0-15	1	Set the data tablet inter- rupt mask to the specified value		

Gtty /dev/gpu. When invoked on special file /dev/gpu, the gtty system call is used to read display system registers. The following statements illustrate how a display system register is read via the gtty system call. In this example, info is a variable of type integer.

info = address of a display system register;
gtty(gpufd,info);

In the above example, the data read from the specified display system register is returned in the integer variable named info.

Close /dev/gpu. A user program closes the /dev/gpu special file with the following statement:

close(gpufd);

where integer variable gpufd contains the file descriptor returned when the file was opened.

The Data Tablet Minor Device. The data tablet minor device is accessed via the special file /dev/dtb. User program I/O requests performed on this file are described here.

Open /dev/dtb. The /dev/dtb special file is opened by a statement of the following form.

dtbfd = open("/dev/dtb",2);

This statement places a file descriptor in integer variable dtbfd (data tablet file descriptor).

Read /dev/dtb. The data tablet input device is read by a C-language statement of the following form.

n = read(dtbfd, &buf, m);

In this statement, m is the number of x-y coordinate pairs requested, buf is an integer array that must be at least 3m in length, dtbfd is an integer variable containing the data tablet file descriptor, and n is an integer variable which is assigned the actual number of x-y coordinate pairs read. For each x-y coordinate pair read, three pieces of data are returned; (1) an x coordinate value, (2) a y coordinate value, and (3) a data tablet interrupt ID which indicates which type of data tablet interrupt generated the x-y coordinate pair. During a read, these data "triples" are placed in the buf array. This is why the buf array must be at least 3m in length.

Table II. Data Tablet Interrupt IDs

Data Tablet Interrupt Type	Interrupt ID Returned To User Program			
PRS	1			
PNN	2			
YOS	4			
xos	8			

Four different types of interrupts may be generated by the data tablet input device; (1) the pressure switch on the data tablet stylus is depressed (PRS), (2) the data tablet stylus is within the "near" zone above the data tablet (PNN), (3) the data tablet stylus is moved off scale (i.e., out of bounds) in the y direction (YOS), or (4) the data tablet stylus is moved off scale (i.e., out of bounds) in the x direction (XOS) (Ref 17:2-83). Table II contains the ID number for each type of data tablet interrupt.

A user program is allowed to specify which data tablet interrupts it will recognize. This is accomplished by invoking a special function via the stty system call. The following code illustrates how the special function is invoked.

info[0] = -5;
info[1] = data tablet interrupt mask value;
stty(gpufd,info);

This special function was already presented in the section entitled Stty /dev/gpu. Table III contains all the data

Table III. Data Tablet Interrupt Masks

Interrupt Mask	Interrupts		Recognized	
Value	xos	YOS	PNN	PRS
0				х
1 2 3 4 5 6			X X	•
3]		Х	Х
4]	X X X X		х
1 6		X	х	^
7		Х	Х	Х
8 9	X			
10	X		χ	Х
11	X		X X	x
12	X X X X	X		.,
13 14	X	X X X	х	X
15 (default Value)	X	X	X	х

tablet interrupt mask values along with the respective data tablet interrupts recognized. Notice that with the default interrupt mask value (15) the user program recognizes all four types of data tablet interrupts.

The following C-language code is an example of a user program that reads one x-y coordinate pair from the data tablet input device. The x-y coordinate pair returned must be generated by a PRS interrupt from the data tablet stylus.

```
1. main()
2. {int gpufd, dtbfd, n, buf[3];
3. gpufd = open("/dev/gpu",2);
4. dtbfd = open("/dev/dtb",2);
5. buf[0]=-5;
6. buf[1]=01;
7. stty(gpufd,buf);
8. n=o;
9. while (n<1) n=read(dtbfd,&buf,1);
10.
11. close(dtbfd);</pre>
```

12. close(gpufd);
13. }

In this program the data tablet interrupt mask is set to 1 (lines 5-7). This ensures that only x-y coordinate pairs generated by a PRS interrupt will be returned to the user program.

A "while" control statement is used to execute the read(2) system call (line 9). This is done because the read(2) system call returns a -1 if no input data is available. The while statement continues to invoke the read(2) system call until input data is read. The while statement is necessary because the device driver software does not support a "time-out" on a read. That is, the device driver software does not wait for input if no input data is readily available when the read is invoked.

After data is read, buf[0] contains the x coordinate, buf[1] contains the y coordinate, and buf[2] contains the data tablet interrupt ID (which will be 1 in the example program above.)

Write /dev/dtb. The data tablet is a read only device. Therefore, an I/O error is flagged by UNIX if a user program attempts to write to the data tablet.

 $\frac{\text{Stty /dev/dtb.}}{\text{Input device can be changed by a user program via the stty}}.$

stty(dtbfd, x);

where x is an integer variable containing a status value for the data tablet and dtbfd is an integer variable containing the file descriptor for file /dev/dtb.

Gtty /dev/dtb. A user program fetches the status of the data tablet input device via the gtty system call. The form of the call is given below.

gtty(dtbfd, x);

This call places the status of the data tablet in the integer variable x.

<u>Close /dev/dtb</u>. The data tablet minor device is closed by a user program with the following statement.

close(dtbfd);

The integer variable dtbfd contains the file description for file /dev/dtb.

The Alphanumeric Keyboard Minor Device. The alphanumeric keyboard input device is accessed via the special file /dev/kbd. User program I/O requests performed on this file are described here.

Open /dev/kbd. The /dev/kbd special file is opened by a statement of the following form

kbdfd = open("/dev/kbd",2);

This statement places a file descriptor in integer variable kbdfd (keyboard file descriptor).

Read /dev/kbd. The alphanumeric keyboard is

read with a statement of the following form,

n = read(kbdfd, &buf, m);

In this statement, m is the number of characters requested, buf is an integer array of length m (into which the input characters will be read), kbdfd is an integer variable containing the file descriptor, and n is an integer variable which is assigned the actual number of characters read (or -1 if no input characters are available at the time of the read). The ASCII representation of the input character is the value returned to the user program.

Here again, a while statement may be used to wait for input to become available. For example, the C-language statements

n=0; while (n<1) n=read(kbdfd,&buf,1);

continue invoking the read(2) system call until one character is read from the VG's alphanumeric keyboard input device.

<u>Write /dev/kbd</u>. The VG's alphanumeric keyboard is a read only device. If a user program attempts to write to it then UNIX flags an I/O error condition.

Stty and Gtty /dev/kbd. The stty and gtty system calls allow a user program to set and get the status of the alphanumeric keyboard input device. The forms of the calls are given below.

stty(kbdfd,x);
gtty(kbdfd,x);

These calls function just like the calls described under Stty /dev/dtb and Gtty /dev/dtb.

Close /dev/kbd. A user program closes the alphanumeric keyboard with the following system call.

close(kbdfd);

The Function Switch Box Minor Device. The function switch box input device is accessed via the special file /dev/fss. User program I/O requests performed on this file are described here.

Open /dev/fss. The /dev/fss special file is opened by a statement of the following form.

fssfd = open("/dev/fss",2);

This statement opens the function switch box input device and places a file descriptor in the integer variable fssfd (function switches file descriptor).

 $\underline{\text{Read}}$ /dev/fss. The function switches are read with a statement of the following form.

n = read(fssfd,&buf,m);

In this statement, m is the number of values requested, buf is an integer array of length m (into which the input values will be read), fssfd is an integer variable containing the file descriptor, and n is an integer variable which is assigned the actual number of characters read (or -1 if no input values are available at the time of the read).

Once again, a while statement may be used to wait for input to become available. For example, the C-language statements

À.

n=o;
while (n<1) n=read(fssfd,&buf,1);</pre>

continue invoking the read(2) system call until one value is read from the VG's function switch box input device.

Write /dev/fss. The VG's function switch box is a read only device. If a user program attempts to write to it, then UNIX flags an I/O error condition.

Stty and Gtty /dev/fss. The stty and gtty system calls allow a user program to set and get the status of the function switch box input device. The forms of the calls are given below.

stty(fssfd,x);
gtty(fssfd,x);

These calls function just like the calls described under Stty /dev/dtb and Gtty /dev/dtb.

Close /dev/fss. A user program closes the function switch box input device with the following call

close(fssfd);

In this statement, fssfd is an integer variable containing the file descriptor for file /dev/fss.

This ends the section on user level documentation. The next section documents the device driver routines.

The Device Driver Routines. A complete listing of the VG device driver routines is included as Appendix D. The description of these routines is divided into the following five sections.

- 1. Include Files
- 2. Global Data Structures
- 3. Common Procedures
- 4. Major Device Routines
- 5. Minor Device Routines

Include Files. Several "header" files containing global declarations are included as part of the device driver software. These files are included via the C programming language file inclusion operator, #include (Refs 7:86 and 10:1-3). The following eight header files are included in the device driver software (see lines 72-79, Appendix D).

- 1. param.h
- 2. buf.h
- 3. conf.h
- 4. dir.h
- 5. user.h
- 6. tty.h
- 7. proc.h
- 8. vg.h

These files are all located in the /sys/h directory.

The first seven files contain global declarations for UNIX constants and structures, while the eighth file, vg.h, contains global declarations for display system constants. These files are referenced as needed throughout the remaining discussion of the device driver routines.

Global Data Structures. This section describes the global data structures used by the device driver software.

They are the UNIX proc and u structures, the vgunit array, and the VG minor device switch table (vgdev).

The UNIX proc and u Structures. The UNIX proc and u structures are used to pass data and control information back and forth between UNIX and the device driver software. The specific elements of these two structures referenced by the device driver software will be explained as they are encountered.

The vgunit Array. The vgunit array was created to keep track of activity on the four VG minor devices. This structure is defined below (also see lines 86-90, Appendix D).

- 1. struct vgstruc {
- 2. struct clist io;
- int status;int *vg_procp;
- 5. } vgunit[4];

Lines 1-4 define a VG data structure, vgstruc, consisting of three elements; io, status, and vg_procp. Line five declares an array, named vgunit, consisting of four occurrences of the VG data structure; one for each of the four VG minor devices. Figure 22a illustrates the data structure created by this code. The minor device numbers are used as indices into the vgunit array. Therefore, vgunit[0] is associated with the 'GPU minor device, vgunit[1] with the data tablet minor device, etc. The purpose for the io, status, and vg_procp elements is now explained.

Each minor device has a first-in first-out (FIFO) queue associated with it for I/O purposes. The io element of each




Fig 22. The vgunit Data Structure

minor device data structure is a header for the appropriate FIFO queue. For example, vgunit[1].io is a reference to the header of the data tablet's I/O queue while vgunit[2].io is a reference to the header of the alphanumeric keyboard's I/O queue.

Each io element is further broken down into three fields; c_cc, c_cf, and c_cl. The c_cc field contains the total number of elements in the FIFO queue, while the c_cf and c_cl fields contain pointers to the first and last elements of the FIFO queue respectively. Figure 22b illustrates the three fields of each io element.

The status element of each minor device data structure indicates whether the corresponding minor device is opened or closed. In the case of the GPU minor device it may also indicate whether the GPU is "running", "waiting", or "sleeping".

The vg_procp element of the minor device data structure is an indirect pointer to the proc structure of the user process that opened the minor device. It is an indirect pointer because it actually points at the u.u_procp element of the u structure which in turn points at the appropriate proc structure.

Use of the vgunit array will be explained more as the .device driver routines are described.

The VG Minor Device Switch Table. The device driver software uses the UNIX idea of a device switch table for calling minor device routines. This table, named vgdev, is declared and initialized on lines 538-543 of Appendix D.

The table is declared as a cdeysw structure. This structure is defined in UNIX source file /sys/h/conf.h. The vgdev table is used exactly like UNIX's cdevsw table. That is, each row of the vgdev table contains the addresses of the open, close, read, write, and I/O control routines associated with a particular VG minor device. Row zero contains the routines for the GPU minor device, row one for the data tablet, row two for the alphanumeric keyboard, and row three for the function switches.

The minor device number passed to the major device routines by UNIX is used as an index into the vgdev table to select the appropriate set of minor device routines. The type of I/O system call determines which routine within the set is invoked.

<u>Common Procedures</u>. The following procedures are called from several different places in the driver software.

- 1. PIN
- 2. POUT
- 3. gpwait
- gpurestart
- 5. putc
- 6. geto
- 7. passc
- 8. sleep
- 9. wakeup
- 10. psignal
- 11. fuiword
- 12. suiword

Routines 1-4 are defined in the device driver program while routines 5-12 are part of the UNIX source code. A brief description of each routine is given here.

PIN and POUT. The PIN and POUT procedures

represent the implementation of the Programmed INput and Programmed OUTput functions described in the Programming Concepts Manual and the PDP11 Interface Specification (Refs 17:2-5 and 19:8).

The PIN procedure is used to read the contents of display system registers. The address of the register to be read is passed to PIN as an input parameter. First, PIN performs a Control Out instruction to load the register address into the Register Number (RN) field of the interface's Control Register. The Register Change (RC) bit, Request Input (RQI) bit, and Interrupt Enable (IE) bit of the interface's Control register are also set by the Control Out instruction. This causes the interface to request the desired data. PIN waits for completion of the input request then reads the data from the interface's Input Buffer Register (INR) with a Programmed In instruction. PIN returns this data to the routine that made the call.

The POUT procedure is used to write display system registers. The address of a display system register and the data to be written are passed to POUT as input parameters. First POUT performs a Control Out instruction to load the register address into the RN field of the interface's Control register and to set the RC and IE bits. Next, the data is written to the specified display system register via a Programmed Out instruction. Finally, POUT waits for the output operation to terminate then returns.

gpwait and gpurestart. The gpwait and

gpurestart procedures are used to stop and start GPU processing. The routines are called by the GPU, data tablet, alphanumeric keyboard, and function switch box interrupt handlers (gpint, dtint, kbintr, and fsintr).

The gpwait procedure is called to halt GPU processing temporarily. This ensures that the GP bus is free for processing an interrupt. The gpurestart procedure is called to restart the GPU processor.

putc and getc. The putc and getc routines are UNIX procedures written in PDP11 assembly language. The source code for these two routines is found in file /sys/conf/mch_i.s. The procedures are used to manage FIFO queues of 8-bit bytes.

The putc routine is used to add a character to a FIFO queue of characters. The procedure accepts two input arguments; (1) the address of a queue header, i.e., an io element within the vgunit array, and (2) the character to be added to the queue. Lion's describes in detail how the FIFO queue is set up and maintained (Ref 10:23-1 to 23-2). Here it suffices to say that putc takes care of allocating more space to the queue, adding the character to the queue, adjusting the queue pointers (c_cf and c_cl) stored in the queue header, and updating the queue count (c_cc).

The getc procedure is used to fetch characters from a FIFO queue of characters. The procedure is called with the address of a queue header as an input argument. The getc procedure takes care of all the overhead required to fetch

a character from the specified queue. It fetches the next character from the queue, returns freed space to the available list, and adjusts the queue pointers and queue count stored in the queue header (Ref 10:23-2). If the queue is empty then getc returns a minus one, otherwise it returns the character fetched from the queue.

passe. The passe routine is a UNIX procedure which passes back a byte of information to the user program (Ref 11:65). The data is placed in the location referenced by the contents of u.u_base. The procedure updates u.u_base, u.u_count, and u.u_offset. If u.u_count goes to zero, signaling the last byte of the user's read, then the procedure returns a minus one. Otherwise, it returns a zero.

sleep and wakeup. The sleep and wakeup procedures are described in detail by Lions (Ref 10:8-3). They are UNIX routines used to suspend and reactivate user processes.

The sleep routine is used to suspend the process that is currently running. The procedure accepts two input parameters; (1) the reason for "sleeping" and (2) the priority with which the process will run upon being "awakened".

The wakeup procedure is invoked to reactivate a "sleeping" process. The procedure is passed the reason for sleeping as an input parameter. As stated by Lions, the procedure "simply searches the set of all processes, looking for any processes which are "sleeping" for a specified reason, and reactivates these individually" (Ref(10:8-3). The

"awakened" processes enter the scheduling queue at the priority specified when the process was put to sleep (Ref 11:20).

psignal. The psignal procedure is a UNIX procedure which signals a software interrupt to the system. A detailed description of software interrupts is given by Lions (Ref 10:13-1 to 13-6).

The psignal procedure accepts two input parameters; (1) a pointer to a proc structure and (2) an interrupt signal.

UNIX recognizes 15 different software interrupt signals. They are defined in UNIX source file /sys/h/param.h. Psignal stores the specified interrupt signal in the p_sig element of the specified proc structure. The system checks p_sig periodically to determine if a software interrupt signal is pending. If there is, then it is processed. Only one software interrupt can be pending for a process at any given time (Ref 10: 13-1).

fuiword and suiword. The fuiword and suiword procedures are UNIX procedures written in PDP11 assembly language. These procedures are used to fetch and store 16-bit data words in the user address space.

The fulword procedure (Refs 10:10-1 and 11:8) is passed a user space virtual address as an input argument. The procedure fetches and returns the contents of the location addressed by the input argument. If an error occurs in this process, the procedure returns a minus one.

The suiword procedure (Ref 11:8) is passed a user space virtual address and a data word as input arguments. The pro-

cedure stores the 16-bit data word in the specified location of the user address space.

Major Device Routines. The generic or major device routines for the VG display system are vgopen, vgclose, vgread, vgwrite, vgioctl, and vgint. These are the routines invoked by UNIX to process the device dependent portion of display system I/O. Each major device routine performs the functions that are common to all of their subordinate minor device routines, then calls the appropriate minor device routine. The vgopen, vgclose, vgread, vgwrite, and vgioctl routines use the minor device number passed from UNIX to call the minor device routines via the minor device switch table, vgdev. The vgint interrupt handler uses a case statement keyed on the interrupt ID to call the appropriate minor device interrupt handler routine. Each of the major device routines are now described.

Appendix D) is called by UNIX to process the device dependent portion of an open(2) system call. The routine is passed a minor device number as an input argument. The minor device number is used as an index into the vgunit array to check the status of the corresponding minor device. If the minor device has already been opened then an I/O error code is placed in u.u_error and a return is made to UNIX. Otherwise, the proc structure pointer, vgunit[mdev].vg_procp, is initialized to reference the proc structure of the process opening the minor device. Next, the appropriate minor device open routine is

called via the vgdev table. After the minor device routine returns, display system interrupts are enabled. This is accomplished by performing a Programmed Out to set the Interrupt Enable (IE) bit of the interface's Control Register. Finally, the status of the minor device is set to OPEN then the routine returns control to UNIX.

vgclose. The vgclose routine (lines 584-590, Appendix D) is called to process the device dependent portion of a close(2) system call. UNIX passes a minor device number as an input parameter. The routine uses the minor device number to call the appropriate minor device close routine via the vgdev table, enables display system interrupts, and sets the status of the appropriate minor device to zero indicating that the minor device is now closed.

vgread. The vgread routine (lines 562-568, Appendix D) is called to process the device dependent portion of a read(2) system call. The minor device number passed as an input parameter is used to call the appropriate minor device read routine via the vgdev table, then display system interrupts are enabled.

vgwrite. The vgwrite routine (lines 573-579, Appendix D) is invoked as the result of a write(2) system call. The minor device number passed as an input argument is used to call the appropriate minor device write routine via the vgdev table, then display system interrupts are enabled.

vgioctl. The vgioctl routine (lines 628-632,Appendix D) is invoked as the result of a stty or gtty system

call (see ioct1(2)). UNIX passes a minor device number and a flag as input arguments. The minor device number is used to call the appropriate minor device I/O control routine via the vgdev table. The flag indicates whether the call is a stty or a gtty call. This flag is passed on to the minor device I/O control routine.

Appendix D) is the major device interrupt handler for the VG display system. It is called by UNIX when a display system event interrupts the PDP11 processor. First, the interrupt ID is obtained by performing a Programmed In on the interface's Status Register. Next, the processor priority is set to level seven, the highest possible priority, to prevent all other interrupts from interfering with processing of the current interrupt.

Next, a case statement, keyed on the interrupt ID, is used to call the appropriate minor device interrupt handler. A Programmed Out is performed to set the interrupt acknowledge (AKC) and Interrupt Enable (IE) bits of the interfaces Control Register. Finally, the processor priority level is set low and control is returned to UNIX.

Unrecognized interrupts are processed by the case 'statement's default condition. An error message is printed and the interface is reinitialized.

This concludes the description of the major device routines. The minor device routines are now described.

Minor Device Routines. The routines associated

with the GPU, data tablet, alphanumeric keyboard, and function switch box minor devices are described in this section.

The routines are presented by minor device.

GPU Routines. The GPU minor device routines handle the GPU portion of the VG display system. The routines include gpopen, gpclose, rbread, gpwrite, and vgsgtty.

gpopen. The gpopen routine (lines 441-460, Appendix D) is called by vgopen. The routine locks the user process in core, initializes the interface, and loads the interface's Base Address Register (BAR).

The user process is locked into core to prevent process swapping during display system access. This is accomplished by ORing the SSYS and SLOCK flags (defined in /sys/h/param.h) into the p_flag element of the process's proc structure (Ref 11:3).

The interface is initialized by issuing a Programmed Out instruction to set the Initialize (INIT) bit of the interface's Control Register.

The interface's BAR is loaded from the appropriate PDP11 user space segmentation register. If the user process does not share a text segment then the base address is taken from the first User Instruction Space Address Register (UISA) located at virtual address 0177640. This register is called APR in the driver software (line 33, Appendix D). It contains the address of the zeroth page of the user address space.

If the user process does share a text segment with

another process then the zeroth page of the user address space may not be contiguous with the rest of the user process. In this case, the address of the first page of the contiguous portion of the user's address space is calculated and loaded into the interface's BAR.

gpclose. The gpclose routine (lines 487-492, Appendix D) is called by vgclose. The routine clears the GPU command register (display system address 07), stops the transfer of the refresh list from the RBU to the DCU, and unlocks the user process from core.

The GPU command register is cleared by writing zeroes to it via a Programmed Output (POUT). Transfer of the refresh list is inhibited by writing a 010 to the START/STOP field of the DCU control register (display system address 0400) (Ref 20:2-6). The user process is unlocked from core by removing the SSYS and SLOCK flags from the appropriate proc structure's p flag element.

rbread. The rbread routine (lines 463-475, Appendix D) is called by vgread to process a read request on the GPU minor device. However, this routine really has nothing to do with the GPU. Instead, it allows a user program to read the contents of the RBU, i.e., read the refresh list. This capability was provided so that the refresh list could be read out, converted to raster form, and displayed on a raster scan device.

The routine uses u.u_count, u.u_base, and u.u_offset which contain the number of words to be read, the address of

a user buffer, and current offset in the file. If u.u_count and u.u_base do not start on a word boundary then they are rounded down to the next word boundary. The routine reads u.u_count words from the RBU starting at u.u_offset. The data read is placed in the user buffer addressed by u.u_base. This is accomplished with the passe routine described earlier.

The POUT procedure is used to load the RBU's memory address register (rbumar) with the address from u.u_offset. This causes the contents of the addressed RBU word to be loaded into the RBU's data Register (rbudat). The PIN procedure is used to read the contents of rbudat. The data read is placed in the user's buffer with the passe routine. This entire process is repeated until u.u_count words have been read from the RBU.

gpwrite. The gpwrite routine (lines 479-482, Appendix D) is called by major device routine vgwrite. Since the GPU minor device cannot be written, the routine simply loads u.u_error with the I/O error flag, EIO, and returns.

vgsgtty. The vgsgtty routine (lines 100-147, Appendix D) is called by major device routine vgioctl to process the device dependent portion of the stty and gtty system calls. The stty and gtty system calls are handled differently by UNIX version seven than by UNIX version six. Therefore, vgsgtty had to be completely rewritten.

The structure chart in Figure 23 illustrates the functions carried out by the vgsgtty routine. First, vgsgtty




Fig 23. Design of the vgsgtty Routine

retrieves the address of the user's data array from u.u_arg[2]. Next, the routine uses a case statement keyed on the flag input argument to control whether a gtty, stty, or unknown command is processed.

register are read and passed back to the user. This is accomplished by fetching the address of the display system register from the first location of the user's data array. This is done with the UNIX fuiword function. Next, the specified display system register is read with the PIN routine. Finally, the data is passed back to the first location of the user's data array via a call to the UNIX suiword function.

For the stty case, all three words of the user data array are fetched via three calls to the fuiword function. A case statement keyed on the value retrieved from the first location of the user's data array determines what to do next. If the case value is -1, -2, -3, -4, or -5, then the associated special function is executed; otherwise, a display system register is written.

With the -1 case, the data retrieved from the third word of the user's data array is written to the RBU location addressed by the value retrieved from the second word of the user's data array. This is accomplished with the POUT function.

For the -2 case, a call is made to the RBU reset procedure, RBURSET. This function resets the RBU by clearing both of the RBU's buffers. It also initializes the RBU's

status and control registers (Ref 20:3-6).

The -3 and -4 cases invoke the gpwait and gpurestart routines respectively. These routines were described in the section on common procedures.

With the -5 case, the data retrieved from the second word of the user buffer is loaded into the data tablet's interrupt enable mask, dtintmask.

Any number of special functions can be added to the system by simply adding more cases to the software.

If the case value is not -1, -2, -3, -4, or -5 then it is interpreted as the address of a display system register. In this case, the data retrieved from the second location of the user's data array is written to the display system register addressed by the value retrieved from the first location of the user's data array.

<u>Data Tablet Routines</u>. The data tablet minor device routines handle the data tablet input device. They are dtopen, dtclose, dtread, dtwrite, fskbdtsgtty, and dtintr.

dtopen. The dtopen routine (lines 213-217, Appendix D) is called by vgopen to enable interrupts from the data tablet input device. This is accomplished by using a POUT to set the interrupt enable (IEN) bit of the data tablet's status (DTS) register (Ref 17:2-82).

dtclose. The dtclose routine (lines 221-225, Appendix D) is called by vgclose to disable interrupts from the data tablet and to flush the data tablet interrupt report queue. Interrupts are disabled by invoking

the POUT function to clear the IEN bit of the DTS register.

The interrupt report queue is emptied by invoking the getc

routine on the queue until it is completely empty.

dtread. The dtread routine (lines 236-247, Appendix D) is called by vgread. The u.u_count variable contains the number of x-y coordinate pairs requested by the read(2) system call.

The dtread routine fetches an x-y coordinate pair and the associated interrupt identifier from the data tablet interrupt report queue and passes them back to the user buffer via calls to the UNIX passc procedure. This continues until u.u_count goes to zero or until the interrupt report queue is empty, whichever occurs first.

dtwrite. The dtwrite routine (lines 232-233, Appendix D) is called by vgwrite. Since the data tablet is a read only device, the routine simply loads u.u_error with the I/O error flag, EIO, and returns.

fskbdtsgtty. The fskbdtsgtty routine (lines 151-170, Appendix D) is called by vgioctl to process the device dependent portion of the stty and gtty system calls with respect to the function switch box, alphanumeric keyboard, and data tablet minor devices. As with the vgsgtty routine, the fskbdtsgtty routine had to be completely rewritten due to differences between UNIX versions six and seven.

The routine is passed a minor device number and a flag as input arguments. The flag is either TIOCGETP for a gtty

call or TIOCSETP for a stty call. The minor device number is either 1, 2, or 3 for the data tablet, alphanumeric keyboard, or function switch box minor devices.

First, the routine retrieves the address of the user's data array that was specified in the system call. This address is retrieved from u.u_arg[2]. Next, a case statement keyed on the flag input argument is used to process either a stty or a gtty.

In the gtty case (flag=TIOCGETP), the status of the specified minor device is passed back to the first location of the user's data array via a call to suiword.

In the stty case (flag=TIOCSETP), the status of the specified minor device is set to the value retrieved from the first word of the user's data array.

dtintr. The dtintr routine (lines 250-264, Appendix D) is called by vgint to process interrupts generated by the data tablet input device. The data tablet's status register is read with a PIN to obtain the interrupt identifier. The interrupt identifier is ANDed with the data tablet interrupt mask, dtintmask, to see if the interrupt is recognized by the user program. If it is, then the data tablet's x and y data registers are read. The x-y coordinates and the interrupt identifier are then placed on the data tablet's interrupt report queue via calls to the UNIX putc routine. Before returning, the routine enables data tablet interrupts by setting the IEN bit of the data tablet's status register.

The Alphanumeric Keyboard Routines. The alphanumeric keyboard minor device routines handle the alphanumeric keyboard input device. They are kbopen, kbclose, kbread, kbwrite, fskbdtsgtty, and kbintr. The fskbdtsgtty routine was described under the data tablet routines. Therefore, it is not included here.

kbopen. The kbopen routine (lines 269-271, Appendix D) is called by vgopen to enable interrupts from the alphanumeric keyboard input device. This is accomplished by setting the KIE bit of the keyboard register (Ref 17:2-84).

kbclose. The kbclose routine (lines 276-280, Appendix D) is called by vgclose to disable interrupts from the alphanumeric keyboard and to flush the keyboard's interrupt report queue. Interrupts are disabled by clearing the KIE bit with a call to POUT. The interrupt report queue is emptied by repeatedly invoking the getc routine on the queue.

kbread. The kbread routine (lines 298-315, Appendix D) is called by vgread. The routine fetches a character from the keyboard's interrupt report queue and passes it to the user program via a call to the UNIX passc routine. This continues until u.u_count goes to zero or until the interrupt report queue is emptied, whichever occurs first. The routine will also terminate if the character read is a carriage return ('/n') or a control D ('/004').

kbwrite. The kbwrite routine (lines

294-297, Appendix D) is called by vgwrite. Since the alphanumeric keyboard is a read only device, the routine simply loads u.u error with the I/O error flag, EIO, and returns.

kbintr. The kbintr routine (lines 320-326, Appendix D) is called by vgint to process interrupts generated by the alphanumeric keyboard input device. The routine uses the PIN function to read a character from the low order byte of the keyboard register. Next, the routine uses the putc function to place the character on the keyboard's interrupt report queue. Before returning, interrupts are enabled for the keyboard.

The Function Switch Box Routines. The minor device routines associated with the function switch box input device are fsopen, fsclose, fsread, fswrite, fsintr, and fskbdtsgtty. Once again, fskbdtsgtty has already been described under the data tablet routines.

fsopen. The fsopen routine (lines 337-340) is called by vgopen to enable interrupts from the function switch box input device. This is accomplished by setting the IEO and IEI bits of the Function Switch Control Register (FSKC) (Ref 20:2-22).

fsclose. The fsclose routine (lines 344-348) is called by vgclose to disable interrupts from the function switch box input device and to flush the function switch box interrupt report queue. Interrupts are disabled by using a POUT to clear the IEO and IE1 bits of the FSKC register. The interrupt report queue is emptied by succes-

sive calls to the getc function.

fsread. The fsread routine (lines 364-392) is called by vgread to transfer u.u_count function switch readings to the user program. The routine first fetches a flag and a function switch value from the function switch box interrupt report queue. The function switch value is converted to an integer between 1 and 16. The flag indicates whether the function switch value came from the S00-S1 group or from the S16-S31 group. If the function switch value came from the S16-S31 group, then the value plus 16 is returned to the user program; otherwise, the value itself is returned. This continues until 1.u._count goes to zero or the function switch box interrupt report queue is emptied, whichever occurs first.

fswrite. The fswrite routine (lines 359-362) is called by vgwrite. Since the function switch box is a read only device, the routine simply loads u.u_error with the I/O error flag, EIO, and returns.

fsintr. The fsintr routine (lines 397-412, Appendix D) is called by vgint to process interrupts generated by the function switch box input device. The routine determines whether the function switch depressed is in the S00-S15 pr the S16-S31 group. If in the S00-S15 group, the FSL0 register is read, else the FSL1 register is read. The contents of the register are placed on the function switch box interrupt report queue with a flag indicating which register the data came from. The routine enables

interrupts from the function switch box before returning.

Summary

This chapter presented the device driver requirements, device driver design, user level documentation, and documentation of the device driver code itself. The next chapter deals with the modifications made to McCallum's original software so that it would run on AFIT's system.

VII <u>Device Driver Updates</u>

Some changes were made to the original device driver obtained from the University of Texas so that it would run on AFIT's system. These changes fall into three categories; (1) changes due to space limitations on AFIT's PDP11/60, (2) changes due to display system differences, and (3) changes due to differences between UNIX versions six and seven. These three categories are discussed in this chapter.

Space Limitations

The original VG device driver would not fit under AFIT's current PDP11/60 system configuration. Therefore, the driver had to be trimmed downed in size. The following three features were removed from the original driver to make it smaller; (1) the level one graphics support, (2) the code intended to enable timeouts to occur during input device reads, and (3) the code supporting the VG light pen device.

Removal of Level One Graphics Support. In the search for ways to trim down the size of the device driver, it was decided to eliminate McCallum's level one graphics support. This level did not use the GPU and therefore did not exercise the full potential of the display system.

In the level one graphics support, the RBU was treated as minor device number 1 with rbopen, rbread, rbwrite, rbclose, rbsgtty, and rbintr as the minor device routines. The rbopen, rbclose, and rbwrite routines were removed from the driver software. Since the rbread and rbsgtty routines were shared

with the GPU minor device, they were not removed. After removal of the RBU minor device, the name rbsgtty no longer had meaning. Therefore it was changed to vgsgtty.

The special function named staticopy was removed from the system. This routine was used to copy the static segment of the RBU from one RBU buffer to the other when the RBU was in double buffer mode. This was a rough attempt to allow static segments to run better for the level one graphics routines.

Removal of Code for Timeouts. The original driver contained code intended to allow a read invoked on a VG input device to timeout if no input was received within a specified period of time. The author of the original driver never got this feature to work. Therefore, it was removed to reduce the size of the driver software. The timeout code removed included the vgwait function, the tmoutdev function, the time and dtime elements from the vgunit structure, the constant GPU_timeout, and the code within the kbread and fsread routines intended for implementation of the timeout feature.

Removal of Code for the Light Pen. Since AFIT's VG display system does not have a light pen device, the code in the original driver supporting the light pen was removed to decrease the size of the driver. The following code was removed: the rbint routine which processed light pen interrupts; the cursup function and global variables vg_x, vg_y, vg_hitaddr, and vg_incr which were used to update the cursor after a light pen hit; and three special functions in the rbsgtty routine (subsequently changed to vgsgtty) for enabling

light pen hits, disabling light pen hits, and loading vg_x and vg y.

Display System Differences

AFIT's VG display system has a data tablet input device, but does not have a light pen device. The code added for the data tablet was described in the last chapter. The data tablet was assigned minor device number 1, which became available when the RBU minor device was removed from the system.

Differences Between UNIX Versions Six and Seven

Many differences exist between UNIX version six and UNIX version seven. These differences are transparent to users but not necessarily transparent to all device drivers. Several changes were required to make the original VG driver run under UNIX version seven. The differences between version six and version seven affecting the VG device driver are described here.

UNIX version six provided the following structure for accessing the low byte and high byte of a 16 bit computer word.

struct{char lobyte; char hibyte;};

This structure was defined in the version six source file param.h. The version seven source file param.h does not contain the structure. Since the VG device driver references the structure often, it was added to the beginning of the driver software (see line 93, Appendix D).

UNIX version six also provided the structure

struct {char d_minor; char d_major;};

for accessing the major and minor numbers of a device name. This structure was declared in the version six source file conf.h. Version seven does not support this data structure. Instead it uses functions major(x) and minor(x) (declared in the version seven file param.h) for fetching the major and minor device numbers from the high order and low order bytes of the device name. In order to reduce the number of changes made to the original driver, the d_minor/d_major structure was added to the beginning of the driver software (see line 96. Appendix D).

Another difference between UNIX versions six and seven is the byte offset, u.u_offset. Thirty two bits are required to keep track of the byte offset in a file for I/O purposes. Since UNIX version six does not directly support "long" integers (i.e., 32 bit integer variables), it uses two sixteen bit words to keep track of the byte offset in a file. These two words are u.u_offset[0] and u.u_offset[1]. UNIX version seven does support long integers. Therefore, under version seven, u.u_offset is one variable declared as type long. As a result, all occurences of u.u_offset[0] and u.u_offset[1] in the original driver were changed to u.u_offset for compatability with UNIX version seven (see lines 469 and 473, Appendix D).

Two changes were made to the UNIX version six cdevsw

structure; (1) a new element, d_stop, was added to the structure and (2) the d_sgtty element was changed to d_ioctl.

These two changes affected the device driver software because the driver's vgdev table is declared as a cdevsw structure (see line 538, Appendix D). Since the d_stop element is not utilized by the driver a zero was placed in its position as a place holder in the vgdev table (see lines 539-542, Appendix D). The driver's only reference to the d_sgtty element of the vgdev table was changed to reference d_ioctl instead (see line 631, Appendix D).

Summary

Installation of a new version of UNIX which has an overlay capability is planned for AFIT's PDP11/60. This will relieve the limited space problem somewhat. At that time the level one graphics could be added back to the driver. The ability to support more systems software will allow for future expansion of the driver software to support other input devices such as the light pen, joy stick, and control dials.

The differences betwen UNIX versions six and seven did not cause any major changes to the original driver software.

Nevertheless, a lot of research was required in order to understand the differences that affected the driver software.

Once the driver source code was updated, it was compiled and installed on the system. The next chapter describes the installation procedures in detail.

VIII Installing the VG Device Driver

The document entitled "Regenerating System Software" provides a general guideline for installing device drivers under the UNIX version seven operating system (Ref 4:6-9). The instructions in the document, together with a few modifications and additions, were used to install the VG device driver on AFIT's PDP11/60 computer.

Before the VG device driver could be installed, the system configuration had to be changed to make room. existing system configuration at AFIT includes device drivers for the RK07 disk drives, the system console, and the time sharing terminals. This is the minimum configuration needed to support a multi-user, time shared environment. Unfortunately, this minimum configuration approaches the maximum size allowed for the UNIX operating system object file. The maximum allowable size is specified as 49,152 bytes (see line 57, Appendix E). In order to install the VG driver and remain within the size limit, something had to be removed from the current configuration. Since the RK07 disk drives and the system console are indespensable, the only thing that could be removed was the dhll driver for the time sharing terminals. This means that in order to use the VG graphics device, the system must be degraded from multi-user to single user mode. This undesirable situation will be remedied in the near future with the installation of a new version of UNIX that provides an "overlay" capability. This capability will allow a larger

UNIX object file which, among other things, will support more device drivers.

The VG device driver was installed under UNIX version seven by performing the following eight steps.

- 1. Create the special files.
- 2. Relocate the driver source files.
- 3. Produce and archive the driver object file.
- 4. Edit the character device switch table.
- 5. Edit the interrupt vector file.
- Produce the UNIX object file /unix.vg.
- 7. Restore the changed UNIX files.
- 8. Reboot the system from /unix.vg.

The remainder of this chapter is devoted to a detailed description of these eight steps. Figure 24 includes all the files and commands used during driver installation and identifies their location in the root file system. Use of these files and commands will be explained as the eight installation steps are described. A description of what was done to remove the dhll driver for the time sharing terminals will also be given.

Creating the Special Files

Character oriented special files for the four VG minor devices were created via the system command mknod(1). The following system commands were executed to create the four special files.

- 1. # cd /dev
- 2. # /etc/mknod gpu c 22 0
- 3. # /etc/mknod dtb c 22 1
- 4. # /etc/mknod kbd c 22 2
- 5. # /etc/mknod fss c 22 3




Fig 24. Location of Relevent Files and Commands

The system expects all character oriented special files to reside in the directory /dev. Therefore, the first command executed changed the current directory to /dev. Next, on lines 2-5, the four special files were created with the mknod command, which resides in the /etc directory.

The mknod command accepts four input parameters. The first parameter specifies the name of the special file to be created. The second parameter indicates that the file is character oriented as opposed to block oriented. The third and fourth parameters specify the file's major and minor device numbers respectively.

The mknod command uses the first input parameter to create a directory entry in /dev for the special file. Next, the mknod command creates an "inode" entry for the special file and stores it in the disk inode table (Ref 10:18-2). The file type (character in this case), major device number, and minor device number represent the file's characteristics. These characteristics are stored in the file's disk inode entry for later reference.

Appendix F contains a listing of directory /dev before execution of the mknod commands, a listing of the mknod commands, and a listing of /dev after execution of the mknod commands. The latter listing verifies the creation of the four special files.

The complete path names for the four special files are /dev/gpu, /dev/dtb, /dev/kbd, and /dev/fss. These complete pathnames are cited in user programs when referencing the VG

graphics processing unit, data tablet, keyboard, and function switches respectively.

After creating the special files, their access modes were updated with the chmod(1) system command to allow all user programs to read and/or write them (Ref 5:13-14). The following list of commands were executed to accomplish this task.

- 1. # chmod +rw /dev/gpu
- 2. # chmod +r /dev/dtb
- 3. # chmod +r /dev/kbd
- 4. # chmod +r /dev/fss
- 5. #

The special file associated with the VG graphics processing unit was given both read and write permissions, while the special files associated with the VG input devices were only given read permission.

Relocating the Driver Source Files

As stated by Haley and Ritchie, "the source and object programs for UNIX are kept in four subdirectories of /sys" (Ref 4:6). These four subdirectories are h, dev, conf, and sys. A complete listing of the contents of these subdirectories is given in Appendix G.

The subdirectory h contains header files which are picked up (via '#include ...') as required by each system module (Ref 4:7). These header files all end in '.h'. They contain global declarations needed by system modules (Ref 10:1-3). The VG device driver program obtained from the University of

Texas included a header file named initl1.h. To maintain UNIX system standards, this file was renamed vg.h and was moved to subdirectory h. The resulting pathname for the file was /sys/h/vg.h.

The dev subdirectory consists mostly of device driver source files that all end in '.c'. The VG device driver source file, vg.c, was moved to the dev subdirectory. The resulting path name for the file was /sys/dev/vg.c.

Subdirectory conf is concerned with device configuration and will be described later in detail. Subdirectory sys contains the rest of the system and has nothing to do with device driver installation.

Producing and Archiving the Driver Object File

The directory /sys/dev contains two libraries, LIB2_i and LIB2_id, which contain all the device driver object files. LIB2_id is used with separate instruction and data (I and D) space CPUs while LIB2_i is used with non-separate I and D space CPUs, such as AFIT's PDP11/60. An object file for the VG driver was produced and archived in LIB2_i.

Before altering LIB2_i, an original copy of it was placed in LIB2_i.save. This guaranteed that LIB2_i could always be restored to its original state from LIB2_i.save.

In order to make room for the VG driver in the final UNIX object file, /unix.vg, the dhll driver object file had to be removed from LIB2_i. This was accomplished with the archive system command, ar(1). The command line

ar d LIB2_1 dh.o

deleted the dhll driver object file from library LIB2_i.

Next, a shell procedure (i.e. an executable file containing system commands) named mkdev_i was invoked to compile the VG driver source file and archive the resulting object file in LIB2_i. The following listing of mkdev_i reveals the commands executed by the UNIX shell program when mkdev_i is invoked.

```
# cat /sys/conf/mkdev i
     echo cp ../h/param_i.h ../h/param.h
2.
     cp ../h/param i.h ../h/param.h
     cd ../dev
     touch junk.o
 6.
     rm *.0
 7.
     cc -c -o $1.c
     cc -c -o $2.c
     cc -c -o $3.c
9.
10.
     cc -c -o $4.c
     cc -c -o $5.c
11.
12.
     cc -c -o $6.c
     ar rv LIB2 i *.o
13.
14.
     rm *.o
15.
```

Line four changes the current directory to /sys/dev where all the driver source files reside. Lines seven through thirteen allow mkdev_i to compile and archive up to six device driver source modules at once (Ref 4:8). The '.c' extension required by the C compiler is automatically appended to the input files.

The following command stream was invoked to compile and archive the VG device driver in library LIB2_1.

1. # cd /sys/conf
2. # cp /sys/dev/vg.c /sys/dev/vg
3. # mkdev_i vg
4. cp ../h/param_i.h ../h/param.h
5. a - vg.o
6. # rm /sys/dev/vg
7. # cp /sys/dev/LIB2_i /sys/dev/LIB2_i.vg

The first command changed the current directory to /sys/conf where mkdev_i resides. On line two a copy of the VG driver source file was made in /sys/dev/vg. This was done because mkdev_i expects no '.c' extension on its input parameters. Mkdev_i was invoked on line three with file /sys/dev/vg as the input parameter. Line five is a message indicating that the VG driver object file, vg.o, was successfully added to LIB2_i. On line seven a copy of the updated LIB2 i was saved in LIB2_i.vg.

Editing the Character Device Switch Table

The system's character device switch table (cdevsw) is contained in the file c.c which resides in the device configuration directory /sys/conf. A complete listing of file c.c is given in Appendix C.

Each row in the cdevsw table is reserved for a particular character type device driver. The ordinal position of the row in the table implies the device's major device number, starting from 0 (Ref 4:9).

A row in the cdevsw table gives all the information the system needs to know about a particular device driver.

As stated by Haley and Ritchie,

"For character devices, each line in the table specifies a routine for open, close, read, and write, and one which sets and returns device-specific status If there is no open or close routine, 'nulldev' may be given; if there is no read, write, or status routine, 'nodev' may be given. Nodev sets an error flag and returns." (Ref 4:9)

The system expects the name for the open routine to be in column one, the close routine in column two, the read routine in column three, the write routine in column four, and the status routine in column five.

Before altering the file /sys/conf/c.c, a copy of it was made in the file /sys/conf/c.c.save. This was done so that the original /sys/conf/c.c could always be restored to its original content from /sys/conf/c.c.save.

The names of the VG device handler routines (vgopen, vgclose, vgread, vgwrite, and vgioctl) were added as row 22 at the end of the existing cdevsw table (see line 77, Appendix C). Thus, the number 22 became the major device number for the VG graphics device. This explains why the number 22 was specified as the major device number when creating the special files associated with the four VG minor devices.

The code

int vgopen(), vgclose(), vgread(), vgwrite(), vgioctl();
was added to file /sys/conf/c.c tc declare the VG driver

routines to be of type integer (see line 51, Appendix C). Comments were added to the beginning of the file to indicate that the VG device handler had been added (see lines 1-11, Appendix C).

The routines for the dhll driver were removed from the cdevsw table. These entries were replaced with 'nodev' and 'nulldev' as needed (see line 59, Appendix C). Also, the line declaring the type of the dhll driver routines was deleted. A copy of the updated file /sys/conf/c.c was saved in /sys/conf/c.c.vg.

Editing the Interrupt Vector File

The file 1.s, which resides in the /sys/conf directory, contains the system's device interrupt vectors. A complete listing of the file 1.s is given in Appendix B. The interrupt vector for the VG device was added to this file.

Before altering the file l.s, a copy of it was made in the file /sys/conf/l.s.good. This guaranteed that l.s could be restored to its original state from l.s.good.

The interrupt vector for the VG device begins at location 374 (octal). When the VG interrupts the PDP11 CPU, the program counter (PC) is loaded with the value stored at location 374, while the processor status (PS) word is loaded with the value stored at location 376. The assembly language code

.= ZERO+374
vgint; br7

was added to the file 1.s to store the appropriate values at locations 374 and 376 (see lines 60-61, Appendix B).

The assembly language code

.global _vgint
vgint: jsr r0, call; jmp _vgint

was added to file 1.s to provide the capability of calling the VG device interrupt handler routine (lines 83-84, Appendix B).

The interrupt vectors for the dhll and dmll drivers were removed from the file l.s. The dmll driver is used for modem devices and is directly coupled to the dhll driver.

After removing the dhll driver, the dmll interrupt vector was no longer needed. A copy of the updated file /sys/conf/l.s was saved in /sys/conf/l.s.vg.

Producing the UNIX Object File /unix.vg

A new object file for the UNIX operating system was created with the make(1) system command. This command can be used to recompile the entire system from scratch or to recompile individual source modules and install them in the correct libraries (Ref 4:7, and 5:11). The latter method was used for installing the VG device driver software.

The form of the command used was "make unix60". The input parameter unix60 indicates that only certain source modules were to be recompiled and that the CPU type was 60 (for the PDP11/60).

The make(1) command looks within the current directory for a file named "makefile". This file is used as input

to the make(1) command. The file /sys/conf/makefile is the input file needed for regenerating the system (Ref 5:11).

A complete listing of this file is given in Appendix E.

The following command stream was used to execute "make unix60" and copy the resulting UNIX object file to /unix.vg.

```
# cd /sys/conf
          1.
          2.
               # make unix60
              convert l.s l i.s
          4.
              cp l.s l i.s
              done converting l_i.s
          6.
              as -o l i.o l i.s
          7.
              as -o mch i.o mch0.s mch i.s
          8.
              cp ../h/param i.h ../h/param.h
          9.
              cc -c -o c.c
         10.
              mv c.o c i.o
         11.
         12.
              The output file will be named unix i !!!!!
         13.
         14.
              ld -o unix_i -x l i.o mch i.o c i.o ../sys/LIBl_i .
/dev/LIB2 i
         Ī5.
              if size of unix_i > 49152 bytes, UNIX IS TOO
         16.
BIG !!!!!
         17.
              Size of unix_i is tEXT+DATA+BSS = TOTAL
         18.
         19.
         20.
              Size unix i
               33638+1918+13312 = 48868b = 0137344b
         21.
         22.
              rm *.o
         23.
              # cp unix_i /unix.vg
         24.
```

First, the current directory was changed to /sys/conf so that the appropriate "makefile" would be used. Next, "make unix60" was invoked on line two. Lines 3-22 are messages printed during successful execution of the command.

The messages indicate what the command was doing.

Basically, the files /sys/conf/l.s, /sys/conf/mch0.s, and

/sys/conf/mch_i.s were assembled; the file /sys/conf/c.c was

compiled; then all the resulting object files were loaded (along with /sys/sys/LIBl_i and /sys/dev/LIB2_i) into an output object file name /sys/conf/unix_i. Next, the size of the object file /sys/conf/unix_i was computed to see if it exceeded 49,152 bytes (the maximum size allowed for a UNIX object file). Finally, on line 22, all the files in the directory /sys/conf that ended in '.o' were removed. This was a cleanup step which removed all intermediate object files created during execution of "make unix60".

On line 23 the UNIX object file /sys/conf/unix_i was copied to the root directory and given the name unix.vg.

Restoring the Changed UNIX Files

The original contents of UNIX files /sys/conf/l.s, /sys/conf/c.c, and /sys/dev/LIB2_i were changed in order to create the new UNIX object file, /unix.vg. A shell procedure, or script file, named /sys/conf/vg_conf.unload was created to restore the original contents of these files after creating the new UNIX object file, /unix.vg.

The script file was created by first using the editor to build a file of system commands, then flagging the file as an executable shell program with the chmod(1) system command (Ref 2:5).

A complete listing of /sys/conf/vg_conf.unload is given here.

- 1. # cat /sys/conf/vg_conf.unload
- 2. echo cp /sys/conf/c.c.save /sys/conf/c.c
 - . cp /sys/conf/c.c.save /sys/conf/c.c
- 4. echo
- 5. echo cp /sys/conf/l.s.good /sys/conf/l.s

- 6. cp /sys/conf/l.s.good /sys/conf/l.s
- 7. echo
- 8. echo cp /sys/conf/unix_i.save /sys/conf/unix_i
- 9. cp /sys/conf/unix i.save /sys/conf/unix i
- 10. echo
- 11. echo cp /sys/dev/LIB2 i.save /sys/dev/LIB2 i
- 12. cp /sys/dev/LIB2 i.save /sys/dev/LIB2 i
- 13. echo
- 14. echo Finished unloading the configuration for the VG3404 !!!
 - 15. #

This script is executed by typing its file name, /sys/conf/
vg_conf.unload, at the system prompt. It restores the original
contents of the UNIX files by copying from the appropriate
save files.

Rebooting the System from /unix.vg

To use the VG Graphics Display System, the PDP11/60 must be rebooted using the /unix.vg object file. A complete list of commands needed to reboot the system is given in Appendix H. These commands must be executed from the system console. When using this command stream it is assumed that the system is in multi-user mode and that the system console is logged in as the "root" executing a function that monitors system usage. First, the system is taken down from multi-user time sharing mode, then it is rebooted from /unix.vg.

Summary

This chapter presented a complete description of how to install the VG device driver software on the PDP11/60 under UNIX version seven. The device driver software testing methodology is described in the next chapter. All of the test programs and results are included.

IX Software Testing

A few short C-language programs were written to test some of the features of the system. This testing was by no means comprehensive.

The testing methodology used was a combination of program path analysis and "black box" testing. The test programs were written to exercise most of the major program paths of the device driver software. These paths were taken directly from the structure chart in Figure 21 (see page 79 Chapter VI). When the test programs were executed, data was input to the system for which a known output was expected. The actual output was checked against the desired output to verify that the driver software worked properly. With this testing approach, the driver software was treated as a "black box". In other words, the inner workings of the driver software were not observed directly.

The major program paths were tested by writing test programs for each of the VG minor devices. The remainder of this chapter is devoted to a description of the tests performed and their results.

GPU Tests

The open(2), close(2), stty, and gtty system calls were tested on the gpu minor device. The objective was to verify that VG registers could be read and written by a user program and that the GPU could fetch and execute a user display list from the host computer.

The first test performed was to open the GPU minor device, write a value to a VG register, read the same register, print the value read, then close the GPU minor device. The code for the test routine and the execution of the test are listed below.

```
# cat gputestl.c
 2.
     main(
     { int fdgpu, buf[3];
 4.
       fdgpu = open("/dev/gpu",2);
       buf[0] = 012;
       buf[1] = 045;
 6.
       stty(fdgpu,buf);
8.
       gtty(fdgpu,buf);
       printf("%o\n", buf[0]);
9.
10.
       close(fdgpu);
11.
12.
13.
     #cc gputestl.c
14.
     #a.out
15.
     45
16.
```

Lines 2 through 11 are a listing of the test routine.

The routine was compiled on line 13 and executed on line 14.

The output was printed on line 15.

In this test the value 45 was written into the VG's picture base object (PBO) register (see lines 5-7), then the PBO register was read to verify that it contained the value 45. The output on line 15 verified that the test was successful. When the PBO register was written (line 7), buf[0] contained the PBO register's address. When the PBO register was read (line 8), buf[0] got changed to the value read.

The same test was performed on the VG's directory (DIR) register. The value 45 was first written to the DIR register, then the DIR register was read. The result was 44 instead

of the expected 45. Later, it was discovered that this was not a device driver software error. The VG's DIR register contains logic that converts all odd values to even values. This is done because the directory address stored in the DIR register must begin on a word boundary instead of a byte boundary in computer memory. When even values are written to the DIR register the same values are returned when the register is read.

The next test performed was to verify that the GPU could fetch and execute a user display list stored in the host computer. The display list used was taken from the VG System Reference Manual (Ref 18:4-3). This particular display list contains the instructions needed to draw an equilateral triangle (Ref 18:4-2). The code for the test routine and execution of the test are listed below.

```
# cat tri.c
 1.
 2.
     main()
     {int fdgpu, directry[10], object[50];
 3.
 4.
      int stack[200], buf[3];
      directry[0] = 01;
directry[1] = object;
 5.
 6.
      object[0]
                    = 01;
 7.
 8.
      object[1]
                    = 0140150;
      object[2]
 9.
                    = 0140000;
      object[3]
                    = 0140000;
10.
      object[4]
                    = 0040000;
11.
      object[5] object[6]
                    = 0140000;
12.
                    = 0;
13.
                    = 0040000;
14.
      object[7]
                    = 0140000;
15.
      object[8]
16.
      object[9]
                    = 0140001;
17.
      object[10] = 0010000;
18.
      fdgpu = open ("/dev/gpu", 2);
      buf[0] = 01;
19.
20.
      buf[1] = stack;
21.
      stty(fdgpu,buf);
22.
      buf[0] = 02;
```

```
buf[1] = stack+63;
23.
      stty(fdgpu,buf);
24.
      buf[0] = 0;
25.
26.
      buf[1] = directry;
27.
       stty(fdgpu,buf);
       buf[0] = 012;
28.
29.
       buf[1] = 01;
      stty(fdgpu,buf);
buf[0] = 010;
30.
31.
       buf[1] = 0401;
32.
      stty(fdgpu,buf);
buf[0] = 07;
33.
34.
       buf[1] = 0160134;
35.
36.
       stty(fdgpu,buf);
37.
       close(fdgpu);
38.
39.
      # cc tri.c
40.
      # a.out
41.
     GPU interrupt [12] - 130022 73257
42.
```

Lines 2 through 38 are the code for the test routine.

Lines 5 and 6 set up the directory required for the display
list, while lines 7-17 set up the display list itself. Lines
19-21 store the beginning stack address in the VG's stack
base address (STB) register. Lines 22-24 store the ending
stack address in the VG's stack limit address (SLM) register.

Lines 25-27 store the directory address in the VG's directory
address (DIR) register. Lines 28-30 store the object number
of the base picture in the VG's picture base object (PBO)
register. Lines 31-33 load the VG's control (CTL) register,
while lines 34-36 load the VG's command (CMD) register.

Once the CMD register is loaded, the GPU is directed to fetch
and execute the display list stored in the array named "object".

The test routine "tri.c" was compiled and executed on lines 39-41. The result was an interrupt generated by the GPU with state code 12 (see line 41). State code 12 means that

an invalid picture base object or directory structure caused the interrupt (Ref 18: Appendix B2). One probable cause of this error is an invalid base address stored in the Hardware Interface's Base Address Register (BAR). This would cause all virtual addresses to be mapped to incorrect physical addresses. If this was the problem, then the GPU used an erroneous physical address to fetch the user's directory information and found an invalid directory structure stored there.

The way to discover if the Interface's BAR is being loaded with the correct address is to write a user program that performs the same address mapping that the Interface performs (Ref 19:13). When performing the address mapping, use the same base address that the driver software loads into the Interface's BAR. The program should first store some predetermined value in a known location. Next the program maps the known location's virtual address to a physical address using the same base address and address mapping algorithm used by the Hardware Interface. Finally, the program fetches the contents of the calculated physical address to see if it is the predetermined value that was stored there in the beginning. If it is, then the error occuring in the driver software was probably not caused by the Hardware Interface's address mapping. On the other hand, if the value fetched is not the same as the value stored then the base address used during the address mapping was erroneous. If this is the case, then the User Instruction Space Address (UISA) Registers have

probably been changed between UNIX versions six and seven.

In that case, the driver software would have to be changed
to load the Interface's BAR from the correct UISA register.

Data Tablet Tests

The open(2), read(2), and close(2) system calls were tested on the data tablet minor device. The objective was to verify that a user program could read the VG's data tablet registers and that a user program could select which of the four types of data tablet interrupts it would recognize.

The first test performed was to open the data tablet minor device, mask out all data tablet interrupts except those generated by the pressure switch on the data tablet stylus, read the data tablet minor device, then close it. The code for the test routine and the execution of the test are listed below.

```
1.
      # cat dtb.c
 2.
     main()
     int fdgpu, fddtb, n, buf[50];
     fdgpu = open("/dev/gpu",2);
fddtb = open("/dev/dtb",2);
 6.
     buf[0] = -5;
     buf[1] = 01;
 8.
 9.
     stty(fdgpu,buf);
10.
     n = 0;
     while (n<1) n=read(fddtb, &buf, 1);
11.
     printf("Flag = %0, X = %d, Y = %d\n", buf[1], buf[2]);
12.
13.
     close(fddtb);
14.
     close(fdgpu);
15.
16.
17.
18.
     # cc dtb.c
19.
     # a.out
20.
     Flag = 1, X = 3, Y = 41
21.
     # a.out
```

22. Flag = 1, X = -377, Y = 441

23. # a.out

24. Flag = 1, X = -408, Y = -319

25. # a.out

26. Flag = 1, X = 369, Y = -318

27. #

Lines 5 and 6 open the GPU and data tablet minor devices. Lines 7 through 9 select the pressure switch interrupt (PRS) only. Lines 11 and 12 read and print one X-Y coordinate pair from the data tablet and the type of interrupt that generated the pair. Lines 13 and 14 close the data tablet and gpu minor devices.

Lines 19 through 26 contain the results of four different executions of the test routine. For each test, the author used the data tablet stylus to generate all the different types of interrupts available on the data tablet, i.e., XOS, YOS, PNN, and PRS (Ref 17:2-83). The phrase "Flag = 1" on each line of the output (lines 20, 22, 24, and 26) verifies that only the X-Y coordinate pairs generated by the PRS interrupt were passed to the test program.

For the next test, lines 7-9 of the data tablet test program were omitted. This meant that X-Y coordinate pairs generated by any of the four data tablet interrupts could be read by the test program. Four different executions of this .test program and the resulting output are listed below.

- 1. # cc dtb.c
- 2. # a.out
- 3. Flag = 2, X=11, Y=75
- 4. # a.out
- 5. Flag = 1, X=413, Y=474
- 6. # a.out

```
7. Flag = 4, X=125, Y=512
8. # a.out
9. Flag = 8, X=512, Y=-305
10. #
```

In the first execution (lines 2-3), "Flag = 2" indicates that the X-Y coordinate pair was generated by a PNN interrupt. For the second, third, and fourth executions, the X-Y coordinate pairs were generated by the PRS, YOS, and XOS interrupts respectively.

For all of the above data tablet tests the device driver software performed correctly. Therefore, the objective of the data tablet tests was met.

Keyboard Tests

The open(2), read(2), and close(2) system calls were tested on the VG's alphanumeric keyboard minor device. The objective was to verify that a user program could read data from the VG's alphanumeric keyboard input device.

A short test program was written to read and print out fourteen characters from the VG's alphanumeric keyboard. The test program and three different executions of the test are listed below.

```
# cat kbd.c
 1.
 2.
     main()
      { int i, fdgpu, fdkbd, n, buf[50];
        fdgpu = open("/dev/gpu",2);
fdkbd = open("/dev/kbd",2);
 4.
 5.
 6.
        for (i=1; i<=14; i++) {
           while (n<1) n=read(fdkbd,&buf,1);
 8.
           printf("%c",buf[0]);
 9.
10.
11.
        printf("\n");
```

```
close(fdkbd);
12.
13.
         close(fdgpu);
14.
15.
     # cc kbd.c
16.
     # a.out
17.
     this is a test
18.
     # a.out
19.
     This is a TEST
20.
     # a.out
21.
     123456789{! ? < >
22.
```

Lines 2-14 are the test program while lines 16-21 are three different executions of the test program. The first and second executions (lines 16-19) verified that both upper and lower case letters were read successfully. The third execution (lines 20-21) verified that numeric and other special characters were read successfully. Therefore, the objective of this test was met.

Function Switch Box Tests

The open(2), read(2), and close(2) system calls were tested on the VG's function switch box minor device. The objective was to verify that a user program could read values from the VG's function switch box input device.

A test program was written to read one value from the function switch box. The test program and four executions of the test are listed below.

```
1. # cat fss.c
2. main()
3. {
4. int fdgpu, fdfss, n, buf;
5. fdgpu = open("/dev/gpu",2);
6. fdfss = open("/dev/fss",2);
7. n = 0;
8. while (n<1) n=read(fdfss, &buf, 1);</pre>
```

```
printf("function switch = %d\n", buf);
9.
     close(fdfss);
10.
11.
     close(fdgpu);
12.
13.
     # cc fss.c
14.
     # a.out
     function switch = 1
16.
     # a.out
17.
     function switch = 15
18.
     # a.out
     function switch = 25
19.
20.
     # a.out
21.
     function switch = 31
22.
```

Line 2-12 are a listing of the test program. Lines 14-21 contain four different executions of the test program. For each execution of the test program the author verified that the value printed was the number of the function switch that was depressed. Therefore the objective of the function switch box tests was met.

Summary

Most of the major features of the system were tested.

Except for the direct memory access test performed on the GPU minor device, all tests performed on the device driver software were successful. This testing concluded the author's research. Conclusions and recommendations are presented in the next chapter.

X Conclusions and Recommendations

The UNIX operating system provides a straight-forward interface to peripheral device driver software. This interface allows for the addition of any number of peripheral devices to the system. The limiting factor is the amount of memory available for the operating system. This was a major problem with AFIT's PDP 11/60. Space was so limited that the VG graphics display system could only be used while the PDP 11/60 was in single user mode. This unacceptable situation can be remedied with the newer version of UNIX which has a memory overlay capability. This capability will allow the operating system to support more device drivers.

The differences between UNIX versions six and seven were transparent to the common user but not to the systems programmer. Therefore, a computer installation that upgrades to a later version of UNIX may have to convert some of their device driver software. Many changes had to be made to McCallum's original driver before it would run under UNIX version seven.

The fact that UNIX is written in a High Order Language (HOL) such as "C" is a real asset. This aids the systems programmer immensely in understanding and maintaining the system. It is also very convenient to be able to write the device driver software in the same HOL. The C programming language has many features which lend to systems programming, e.g., pointers and structures.

McCallum's design for the VG device driver was straightforward and easy to understand. He used a top down modular
approach which allows for easy expansion of the driver software. This was shown by the easy addition of the data tablet
minor device to the driver software.

The apparent problem with direct memory access must be solved before the system is useful. First, the cause of the problem must be identified, then corrected. A probable cause of the problem and a possible solution were identified in Chapter IX.

Many worthwhile projects could stem from the research in this thesis. One project would be to implement a time-out capability when reading from the VG input devices. In other words, if no input data is available when a user program reads a VG input device then the user program should be put to "sleep" for a short time to wait for data to be input from the device.

The author attempted to implement the time-out feature using the alarm(2), pause(2), and signal(2) system calls. The attempt was aborted when it was discovered that the header file required by the signal(2) system call (signal.h) was not available on AFIT's system. The following three lines of code show how the time-out would have worked using the three system calls.

^{1.} alarm(n);

^{3. (*}signal(SIGALRM,SIG_IGN))();

The author intended to have the device driver execute this code if no data was available when a user program attempted to read a VG input device. Line 1 tells UNIX to send an alarm signal to this process after n seconds have elapsed. Line 2 causes the driver to stop execution to wait for a signal. Line 3 catches the alarm signal sent by UNIX after the n seconds have elapsed. After the alarm signal is caught the device driver resumes execution. This would have been an easy way to implement the time-out feature. Since the file /sys/h/signal.h was not present on the system, the time-out feature could not be done with the alarm(2), pause(2), and signal(2) system calls. Nevertheless, a time-out feature could be programmed in other ways.

Another possible project would be to enhance the input capabilities of the VG's alphanumeric keyboard input device. Currently the device driver only supports the "raw" mode of input from the keyboard. That is, no special meaning is assigned to any input character received from the VG's keyboard. The device driver could be changed to support "cooked" input from the VG keyboard. That is, control characters input from the VG's keyboard could be detected by the device driver and handled in a special way. Another project in this area would be to echo the keyboard characters to the VG's display.

Perhaps the most worthwhile project is the implementation of a high level device independent graphics software package on the system. McCallum's level two graphics software (Ref 12) is readily available. It may have to be modi-

fied a little to be compatible with UNIX version seven's version of device driver software.

Another graphics software system such as Lawrence Livermore's Grafcore/Graflib (Ref 6) could also be implemented. In this case a BASELIB would have to be generated to define the UNIX/Graflib interface. Next a filter would have to be written to convert the device independent display list that Graflib produces into a display list that can be processed by the VG display system.

Many more worthwhile thesis projects could be undertaken to develop AFIT's computer graphics capabilities. The field is wide open and the options are virtually limitless.

Bibliography

- 1. Bell Telephone Laboratories. UNIX Time-Sharing System:
 UNIX Programmer's Manual, 1. Murray Hill: Bell Telephone Laboratories, Inc., January 1979.
- 2. Bourne, S. R. "An Introduction to the UNIX Shell,"

 <u>UNIX Programmer's Manual</u>, <u>2A</u>. Murray Hill: Bell Telephone Laboratories, Inc., January 1979.
- 3. Bourne, S. R. "The UNIX Shell," The Bell System Technical Journal, 57 (6): 1971-1990 (July-August 1978).
- 4. Haley, Charles B. and Dennis M. Ritchie. "Regenerating System Software," <u>UNIX Programmer's Manual</u>, <u>2A</u>.

 Murray Hill: Bell Telephone Laboratories, Inc.,
 January 1979.
- 5. Haley, Charles B. and Dennis M. Ritchie. "Setting Up UNIX Seventh Edition," UNIX Programmer's Manual, 2A. Murray Hill: Bell Telephone Laboratories, Inc., January 1979.
- 6. Keller, Pete, et al. GRAFLIB Reference Manual. Liver-more: Lawrence Livermore Laboratory, October 1980.
- 7. Kernighan, Brian W. and Dennis M. Ritchie. The C Programming Language. Englewood Cliffs: Prentice-Hall, Inc., 1978.
- 8. Kernighan, Brian W. "A Tutorial Introduction to the UNIX Text Editor," UNIX Programmer's Manual, 2A: 54-64.
 Murray Hill: Bell Telephone Laboratories, Inc.,
 January 1979.
- 9. Kernighan, Brian W. "UNIX for Beginners Seventh Edition," <u>UNIX Programmer's Manual</u>, <u>2A</u>: Murray Hill: Bell Telephone Laboratories, Inc., January 1979.
- 10. Lions, J. A Commentary on the UNIX Operating System. Kensington: Department of Computer Science, The University of New South Wales, June 1977.
- 11. Lions, J. <u>UNIX Operating System Source Code</u>, <u>Level Six</u>. Kensington: Department of Computer Science, The University of New South Wales, June 1977.
- 12. McCallum, Douglas Roland. A Machine-Independent Interactive Computer Graphics System. MA thesis. Austin, Texas: The University of Texas at Austin, May 1980.

- 13. Ritchie, D. M. and K. Thompson. "The UNIX Time-Sharing System," UNIX Programmer's Manual, 2A: 23-38. Murray Hill: Bell Telephone Laboratories, Inc., January 1979.
- 14. Ritchie, Dennis M. "The UNIX I/O System," <u>UNIX Programmer's Manual</u>, <u>2A</u>. Murry Hill: Bell Telephone Laboratories, Inc., January 1979.
- 15. SIGGRAPH. "Status Report of the Graphic Standards Planning Committee," Computer Graphics, A Quarterly Report of SIGGRAPH-ACM, 13 (3). (August 1979).
- 16. Thompson, K. "UNIX Implementation," <u>UNIX Programmer's</u>

 <u>Manual, 2A.</u> Murray Hill: Bell Telephone Laboratories,
 Inc., January 1979.
- 17. Vector General. <u>Graphics Display System Model 3404</u>
 Programming Concepts Manual. Publication number 113489.
 Woodland Hills: Vector General Inc., July 1978.
- 18. Vector General. Graphics Display System Model 3404
 System Reference Manual. Publication number M110700REF.
 Woodland Hills: Vector General Inc., August 1978.
- 19. Vector General. PDP11 Interface Specifications. DE41 reference manual. Woodland Hills: Vector General Inc.
- 20. Vector General. Series 3400 Technical Manual, Volume 1. Publication number M110700. Woodland Hills: Vector General Inc., March 1978.

Appendix A: Listings of UNIX Source Files /sys/h/proc.h and /sys/h/user.h

The two UNIX Source Files contained in this appendix were printed on the PDP11/60 system. The following two command lines were invoked to print the files on a teletype terminal.

printit </sys/h/proc.h
 # printit </sys/h/user.h

The program "printit" was written to print the input file with line numbers added. The source code for this program is listed below.

```
printit <printit.c</pre>
      #include "/sys/h/stdio.h"
 01
      #define MAXLINE 133
 02
 03
      main()
 04
               register int i;
               char *temp[133];
 05
 06
               for (i=1;fgets(temp,MAXLINE,stdin);
 07
               1++) {
                        fprintf(stdout, "%5.5d
                                                  ",i);
 80
                        fputs(temp,stdout);
 09
010
011
       }
```

The prinit program was used to print all of the source file listings in Appendices A-E.

· • Page 1

Listing of Source File /sys/h/user.h

8 14:46 1981

Dec

IO flag: O:user D; l:system; 2:user I */

return error code */

*

u_segflg; u_error; u_uid;

char

026 027 028 029 030

effective user id *,

* *

pointer to proc structure */

proc *u_procp;

struct

031

1 n t

*u_ap;

u_g1d; u_ru1d; u_rg1d;

short short short short

effective group id */ real user id */

real group id */

pointer to arglist */

156

The state of the s

8 14:46 1981

Dec

```
20
                                                                                                                                                                                   26
                                                                                                                                                                                                  28
                                                                                                                                                                                                         59
                                                                                                                                   19
error codes
                                                        ENOEXEC
                                                                                                        ENOTBLK
                                                                                                                                           ENOTDIR
                                                                                                                                                                                    ETXTBSY
              ENOENT
                                                                     ECHILD
                                                                             EAGAIN
                                                                                   ENOMEM
                                                                                          EACCES
                                                                                                 EFAULT
                                                                                                                      EFXIST
                                                                                                                                   ENODEV
                                                                                                                                                  EISDIR
                                                                                                                                                         EINVAL
                                                                                                                                                              ENFILE
                                                                                                                                                                      EMFILE
                                                                                                                                                                             ENOTTY
                                                                                                                                                                                                  ENOSPC
                                                                                                                                                                                                         ESPIPE
      define EPERM
                                                                                                               EBUSY
                                                                                                                                                                                           FFBIG
                                         ENXIO
                                                E2BIG
                                                               EBADF
                     ESRCH
                            EINTR
                                                                                                                             EXDEV
              #define
                     #define
                                   #define
                                                                                                                      define
                                                                                                                             #define
                                                                                                                                                                define
                                                 #define
                                                        #define
                                                               define
                                                                      define
                                                                             define
                                                                                           define
                                                                                                 define
                                                                                                        define
                                                                                                                                    define
                                                                                                                                           define
                                                                                                                                                  #define
                                                                                                                                                         #define
                                                                                                                                                                      fdefine
                                                                                                                                                                              define
                                                                                                                                                                                    define
                                                                                                                                                                                           #define
                                                                                                                                                                                                         define
                             *define
                                          define
                                                                                    #define
                                                                                                                define
                                                                                                                                                                                                  define
                                                                                                0115
      0102
             0103
                           0105
                                  0106
                                                0108
                                                       0109
                                                              0110
                                                                           0112
                                                                                   0113
                                                                                         0114
                                                                                                                      0118
                                                                                                                            0119
                                                                                                                                   0120
                                                                                                                                                 0122
                                                                                                                                                        0123
                                                                                                                                                                            0126
                                                                                                                                                                                           0128
                    0104
                                         0107
                                                                                                              0117
                                                                                                                                          0121
                                                                                                                                                               0124
                                                                                                                                                                     0125
                                                                                                                                                                                   0127
                                                                                                                                                                                                  0129
                                                                                                                                                                                                                      0132
1010
                                                                     0111
```

吃油

Dec 8 14:46 1981

0133 0134 0135 Appendix B: Listing of UNIX Source File /sys/conf/l.s.vg

The UNIX source file /sys/conf/l.s.vg contains the system call trap vector (line 31) and the VG's interrupt vector (lines 60-61 and 83-84).

ļ

Page 1

Dec

Dec

```
/ Vector General interrupt vector
                                                                                                                                                 segmentation violation
                                                                                                                                                                                                    programmed interrupt
                                                                                                                                                                                            floating point
                                                                                           / 11/70 parity
       start
                                                                                           trap: br7+10.
              dunp
                                                                                                                                         br7+8.
                                                                                                                                   br7+7.
                                                                                                                                               br7+9.
 dunp
                                                                                                                                                             floating vectors
                                                                                                                                                                                vgint; br7
                                                                  kwlp: br6
kwlp: br6
                                        br4
                                              br4
                                                                                                               hkio: *r5
 start,
                                                                                                                                                trap:
                                        klin:
                                                                                                                                   trap;
                                              klou;
                                                                                                                                          trap;
                                                           ZER0+100
                                                                                     ZER0+114
                                                                                                         ZER0+210
                                                                                                                            - ZERO+240
                                                                                                                                                                          - ZERO+374
       Jap
Jap
                                 - ZER0+60
.81obl
                                                                                                           ,
             036
                          038
                                 039
                                       040
                                                           043
                                                                 044
                                                                              940
                                                                                           048
                                                                                                        050
                                                                                                                                                                   059
                                                                                                                                                                          090
                                                                                                                                                                                061
                                                                                                                                                                                             063
                                                    042
                                                                       045
                                                                                    047
                                                                                                                            053
                                                                                                                                         055
                                                                                                                                                                                       062
                   037
                                              041
                                                                                                                     052
                                                                                                                                  054
                                                                                                                                                     057
                                                                                                                                                             ○
```

	jmp klrint	ı	rO,call; jmp _clock	rO,call; jmp_hkintr	jmp_vgint
d e	r0, call;		r0,call;	r0,call;	r0,call; jmp_vgf
call, trap	צע	klxint jsr	clock jsr	hkintr jsr	vgint jsr
.text .globl	.globl klin:	.globl klou:	.globl kwlp:	.globl hkio:	.globl vgint:
067 068 069	070	072 073 074	075 076 077	078 079 080 081	082 083 084

Appendix C: Listing of UNIX Source File /sys/conf/c.c.vg

The UNIX source file /sys/conf/c.c.vg contains the system character device switch table (cdevsw). The cdevsw table contains the addresses of the VG major device routines (line 77).

Dec

and the second second

Page

```
*
                                                                     *
                                                                                                   * Edited to include the Vector General 3404 Graphics Device.
                                                                                        Vector General Graphics Device while in single user mode.
                      It has been added to the cdevsw table as major device 22
                                                      The Vector General 3404 device driver would not fit in
                                                                  the system, so the device driver dh = 4 was removed to
                                                                             make room. This means that you can only use the
                                                                                                                                                                                                                                                                                                                                                                  /
* 0
                                                                                                                                                                                                                                                                                                                                                                   ı
                                                                                                                                                                                                                                                                                                                                                                   ൂ
                                                                                                                                                                                                                                                                                                                                                                  nodev, nodev, nodev, 0, /*
                                                                                                                                                                                                                                                                                                                                            bdevsw[]
                                                                                                                                                           ../h/systm.h"
                                                                                                                                                ../h/param.h"
                                                                                                                                                                                                                                                               ../h/1node.h"
                                                                                                                                                                                            ../h/conf.h"
                                                                                                                                                                                                       ../h/proc.h"
                                                                                                                                                                                                                                                   ../h/file.h"
                                                                                                                                                                                                                  ../h/text.h"
                                                                                                                                                                                                                                        ../h/user.h"
                                                                                                                                                                                                                                                                        "../h/acct.h"
                                                                                                                                                                                                                                                                                                                                 hktab:
                                                                                                                                                                                "../h/tty.h"
                                                                                                                                                                       ../h/buf.h"
                                                                                                                                                                                                                              ../h/dir.h"
                                                                                                                                                                                                                                                                                                                      hkstrategy():
                                                                                                                                                                                                                                                                                               nulldev().
                                                                                                                                                                                                                                                                                                          nodev();
                                                                                                                                                                                                                                                                                                                                            hdevsw
                                                                                                                                                                                                                                                                                                                                 huf
                                                                                                                                                                                                                                                                         #include
                                                                                                                                                 #1nclude
                                                                                                                                                           #include
                                                                                                                                                                       #include
                                                                                                                                                                                  #include
                                                                                                                                                                                             #include
                                                                                                                                                                                                         /include
                                                                                                                                                                                                                   #include
                                                                                                                                                                                                                              #Include
                                                                                                                                                                                                                                         #include
                                                                                                                                                                                                                                                    #include
                                                                                                                                                                                                                                                               #include
                                                                                                                                                                                                                                                                                                                                 struct
                                                                                                                                                                                                                                                                                                                                           struct
                                                                                                                                                                                                                                                                                                                      1nt
                                                                                                                                                                                                                                                                                               int
                                                                                                                                                                                                                                                                                                           int
                                                      *
                                                                  *
                    03
                                04
                                          0.5
                                                                07
                                                                                      60
                                                                                                   010
                                                                                                                        012
                                                                                                                                    013
                                                                                                                                               014
                                                                                                                                                          015
                                                                                                                                                                    910
                                                                                                                                                                                           018
                                                                                                                                                                                                      019
                                                                                                                                                                                                                 020
                                                                                                                                                                                                                           021
                                                                                                                                                                                                                                       022
                                                                                                                                                                                                                                                  023
                                                                                                                                                                                                                                                             024
                                                                                                                                                                                                                                                                        025
                                                                                                                                                                                                                                                                                  026
                                                                                                                                                                                                                                                                                                                    029
                                                                                                                                                                                                                                                                                                                               030
                                                                                                             011
                                                                                                                                                                               017
                                                                                                                                                                                                                                                                                             027
                                                                                                                                                                                                                                                                                                         028
```

~

Page

Listing of Source File /sys/conf/c.c.vg

14:36 1981

œ

Dec

The second secon

*

では、100mmの

*

Dec 8 14:36 1981

Page 4

Appendix D: Listings of Driver Source Files /sys/h.vg.h and /sys/dev/vg.c

The VG device driver source code is located in two files; /sys/h/vg.h and /sys/dev/vg.c. These files contain the final version of the device driver software.

the second secon

010000 01406 040 004 000 000 000 interrupt vectors 0007 intenable RBU UNIT GPU UNIT GP BUS DATABLET KEYBOARD FUNCTION intack rbumar rbudat stat cmd define define define #define define define #define #define #define #define #define #define 034 035 036 037 038 039 041 042 043 044 970 048 049 050 047

051

053 054 055

056 057 058 059

090

062

064 065 066

```
This handler must take several minor devices into consideration/
 Page 3
                                                                                                                                                                                                       /* An array handling all minor device information */
 Driver Source File /sys/dev/vg.c
                              Handler for Vector General Processor
                                                                                                                                                                                                                                                                                                                              char d_major;
                                                                                                                                                                                                                                                                                                 char hibyte;
                                                                                                                                                                                                                                                                                                                              char d_minor;
                                                                                                                                                                                                                                     struct clist io;
                                                                                                                                                                                                                                                                                                char lobyte;
                                                                                ../h/param.h"
                                                  8p, dt, kb, fs
                                                                                                                                                                                                                                                         int *vg_procp;
} vgunit[4];
                                                                                                                                           ../h/proc.h"
                                                                                                    ../h/conf.h"
                                                                                                                        ../h/user.h"
                                                                                         ../h/buf.h"
                                                                                                             ../h/d1r.h"
                                                                                                                                  ../h/tty.h"
                                                                                                                                                     ../h/vg.h"
                                                                                                                                                                                                                                                                                                                                                            int reg;
                                                                                                                                                                                                                                                int status;
                                                                                                                                                                                                                            struct vgstruc {
                                                                                                                                                                          int dtintmask;
Dec 20 02:37 1981
                                                                                          finclude
                                                                                                    finclude
                                                                                                                                                      finclude
                                                                                finclude
                                                                                                              finclude
                                                                                                                        Include
                                                                                                                                  Include
                                                                                                                                            finclude
                                                                                                                                                                                                                                                                                                 struct (
                                                                                                                                                                                                                                                                                                                                                             struct {
                                                                                                                                                                                                                                                                                                                              struct
                                                 690
                                                          070
                                                                                                                                                              080
                                                                                                                                                                                            083
                                                                                                                                                                                                       084
                                                                                                                                                                                                                085
                                                                                                                                                                                                                                              088
                                       068
                                                                              072
                                                                                                  074
                                                                                                            075
                                                                                                                       910
                                                                                                                                          078
                                                                                                                                                   079
                                                                                                                                                                                  082
                                                                                                                                                                                                                                    087
                                                                                                                                                                                                                                                                  090
                                                                                                                                                                                                                                                                                     092
                                                                                                                                                                                                                                                                                               093
                                                                                                                                                                                                                                                                                                         094
                                                                                                                                                                                                                                                                                                                   095
                                                                                                                                                                                                                                                                                                                            960
                                                                                                                                077
```

Page 5

```
* POUT and PIN perform the function POUT or PIN described in VG manual
                                                                                                                                                                                                                                                                                                                                                                                                      VG_CONT->reg = (REGISTER & 01777) | r_change | vg_rqi | intenable; while (VG_CONT->reg & vg_iip) /* wait_for done */; return VG_DATA->reg; /* PIN */
                                                                                                                                                                                                                                                                           VG_CONT->reg = (REGISTER & 01777) | r_change | intenable; VG_DATA->reg = VALUE;
                                                                                                                                                                                                                                                                                                        while (VG CONT->reg & vg_o1p) /* wait until done */;
                                                                                                                                                                  commonly used routines
                                                                                                                                                                                                                                                  POUT(REGISTER, VALUE)
                                                                                                                                                                                                                                                                int REGISTER, VALUE;
              return;
                          break;
                                                                                                                                                                                                                                                                                                                                                                              PIN(REGISTER)
                                                                                                                                                                                                                                                                                                                                                                                          int REGISTER;
default:
        0167
                                                    0110
                                                                                                                                                                                           0180
                                                                                             0173
                                                                                                            0174
                                                                                                                        0175
                                                                                                                                     0176
                                                                                                                                                  0177
                                                                                                                                                                0178
                                                                                                                                                                                                                       0182
                                                                                                                                                                                                                                    0183
                                                                                                                                                                                                                                                  0184
                                                                                                                                                                                                                                                              0185
                                                                                                                                                                                                                                                                            0186
                                                                                                                                                                                                                                                                                                        0188
                                                                                                                                                                                                                                                                                                                      0189
                                                                                                                                                                                                                                                                                                                                                               0192
                                                                                                                                                                                                                                                                                                                                                                             0193
                                                                                                                                                                                                                                                                                                                                                                                         0194
                                                                                                                                                                                                                                                                                                                                                                                                       0195
                         0168
                                       0169
                                                                  0171
                                                                                0172
                                                                                                                                                                              0179
                                                                                                                                                                                                        0181
                                                                                                                                                                                                                                                                                           0187
                                                                                                                                                                                                                                                                                                                                     0190
                                                                                                                                                                                                                                                                                                                                                  0191
                                                                                                                                                                                                                                                                                                                                                                                                                     0196
                                                                                                                                                                                                                                                                                                                                                                                                                                 0197
```

Page 6

Driver Source File /sys/dev/vg.c

Dec 20 02:56 1981

```
Page
                                                                                                                                                                                                                                                                                                 /* disable interrupts */
                                                                                                                                                                                                                                                                                                                                                                        /* enable interrupts */
                                                                 while ((PIN(rbustc) & rb mask) i= rb mask) /* wait */
                                                                                                                                                                                                                                                                                                          while (getc(\&vgunit[1].io) >= 0); /* flush buffer */
  Driver Source File /sys/dev/vg.c
                                                                                                                                                                                                                                                                                                                                                               extern struct cdevsw vgdev[];
                                                                                                                                                                                                                                                                                      extern struct cdevsw vgdev[];
                                                                                                                                                      VG data tablet handler
                                                       POUT(rbustc, reset);
                                                                                                                                                                                                                                                                                                                                                                         01);
                                                                                                                                                                                                dtintmask=017;
                                                                                                                                                                                                                                                                                               Pour(dtb, 0);
                                                                                                                                                                                                            dtstart();
                                                                                                                                                                                                                                                                                                                                                                        POUT (dtb,
Dec 20 03:07 198i
                                                                                                                                                                                                                                                                            dtclose()
                                                                                                                                                                                                                                                                                                                                                     dtstart()
                                  RBURSET()
                                                                                                                                                                                        dtopen()
                                                                                                                                                      */
                                                                                                                                                                                                                      0216
                                                                                                                                                                                                                                                     0219
                                                                                                                                                                                                                                                               0220
                                                                                                                                                                                                                                                                                    0222
                                                                                                                                                                                                                                                                                                                                                   0228
                                                                                                                                                                                                                                                                                                                                                                        0230
                                   0199
                                            0200
                                                                           0203
                                                                                      0204
                                                                                                 0205
                                                                                                           0206
                                                                                                                                0208
                                                                                                                                                      0210
                                                                                                                                                                                     0213
                                                                                                                                                                                                 0214
                                                                                                                                                                                                          0215
                                                                                                                                                                                                                                          0218
                                                                                                                                                                                                                                                                                               0223
                                                                                                                                                                                                                                                                                                           0224
                                                                                                                                                                                                                                                                                                                              0226
                                                       0201
                                                                  0202
                                                                                                                      0207
                                                                                                                                            0209
                                                                                                                                                                 0211
                                                                                                                                                                            0212
                                                                                                                                                                                                                               0217
                                                                                                                                                                                                                                                                          0221
                                                                                                                                                                                                                                                                                                                    0225
                                                                                                                                                                                                                                                                                                                                         0227
```

THE PARTY OF THE P


œ

Page

The second secon

```
Page 9
                                                                                                                                                         while(getc(&vgunit[2].io) >= 0) ;/*flush buffer */
                                                                                                                                                                                                                                           /* enable interrupts */
Driver Source File /sys/dev/vg.c
                                                                                                                                       extern struct cdevsw vgdev[];
                                                                                                                                                                                                                                 extern struct cdevsw vgdev[];
POUT(kbd,040000);
                          VG keyboard handler
                                                                                                                                                                                                                                                                                                                   u.u_error = EIO;
                                                                                                                                               POUT(kbd,0);
                                                                       kbstart();
                                                                                                                              kbclose()
                                                                                                                                                                                                              kbstart()
                                                                                                                                                                                                                                                                                               kbwr1te()
                                                              kbopen()
                                 0266
                                                    0268
                                                             0269
                                                                              0271
                                                                                                0273
                                          0267
                                                                      0270
                                                                                                          0274
                                                                                                                  0275
                                                                                                                           0276
                                                                                                                                                       0279
                                                                                                                                                                0280
                                                                                                                                     0277
                                                                                                                                              0278
                                                                                                                                                                                  0282
                                                                                                                                                                                                                                                                           0292
                                                                                                                                                                          0281
                                                                                                                                                                                           0283
                                                                                                                                                                                                            0285
                                                                                                                                                                                                                      0286
                                                                                                                                                                                                                                        0288
                                                                                                                                                                                                    0284
                                                                                                                                                                                                                              0287
                                                                                                                                                                                                                                                 0289
                                                                                                                                                                                                                                                         0290
                                                                                                                                                                                                                                                                   0291
                                                                                                                                                                                                                                                                                              0294
                                                                                                                                                                                                                                                                                                      0295
```

Dec 20 04:13 1981



```
while (u.u_count){
    while (u.u_count && (C = getc(&vgunit[2].10)) != -1){
        if (C == '\015') C = '\n';
                                                                                                                                                                                                                          extern struct cdevsw vgdev[]; C = PIN(kbd) & 0377;
                                                                         switch (C)
                                                                                                    case 7\0047:
                                                                                                                return;
                                                                                            case '\n':
                                                                 passc(C);
                                                                                                                       default:
                                                                                                                                                                                                                                            putc(C,&vgunit[2].10);
kbstart();
          register int C;
                                                                                                                                                                                                                    register int C;
                  sp10();
                                                                                                                                                                                                         kbintr()
 kbread()
0298
                  0300
                                                                                                     0309
                                                                                                              0310
                                                                                                                                                                                                0319
                                                                                                                                                                                                         0320
                                                                                                                                                                                                                                    0323
                                                                                                                                                                                                                                              0324
                                                                                                                                                                                                                                                     0325
                                                                                                                                                                                                                                                                0326
                                                                                                                                                                                                                                                                                  0328
                           0301
                                    0302
                                              0303
                                                      0304
                                                                0305
                                                                         0306
                                                                                            0308
                                                                                                                                0312
                                                                                                                                         0313
                                                                                                                                                   0314
                                                                                                                                                           0315
                                                                                                                                                                     0316
                                                                                                                                                                             0317
                                                                                                                                                                                       0318
                                                                                                                                                                                                                  0321
                                                                                                                                                                                                                           0322
                                                                                   0307
                                                                                                                       0311
                                                                                                                                                                                                                                                                         0327
```

```
Page 11
                                                                                                                                                                   while(getc(\deltavgunit[3].io) >= 0); /* flush buffer */
  Driver Source File /sys/dev/vg.c
                                           * this is the function switch box input device
                                                                                                                                                                                                                             Pour(fss+2,05005);
                                                                                                                                                          Pout(fss+2,0);
                                                                                                                                                                                                                                                                                        u.u_error=EIO;
                                                                                               fsstart();
                                     fss device
                                                                                                                                                                                                             sstart()
                                                                                                                                          fsclose()
Dec 20 04:13 198i
                                                                                                                                                                                                                                                                        fswrite()
                                                                               fsopen()
                                                                                                                                                                                                   0351
0352
0353
                                                                             0337
                                                                                                       0340
                                                                                                                                                 0345
                                                                                                                                                                                                                                     0355
                                                                                                                                                                                                                                                                               0360
                                                                                                                       0342
                                                                                                                                                                                           0350
                          0331
0332
0333
                                                            0335
                                                                    0336
                                                                                                                                                         0346
                                                                                                                                                                 0347
                                                                                                                                                                         0348
                                                                                                                                                                                   0349
                                                                                                                                                                                                                             0354
                                                                                                                                                                                                                                                     0357
                                                                                                                                                                                                                                                               0358
                                                                                                                                                                                                                                                                      0359
                                                                                                                                                                                                                                                                                                0362
                                                   0334
                                                                                              0339
                                                                                                                                        0344
                                                                                                                                                                                                                                                                                        0361
```

```
putc(Q.lobyte,&vgunit[3].10); /* flag for upper or lower range */
putc(C.lobyte,&vgunit[3].10);
putc(C.hibyte,&vgunit[3].10);
     Page 13
    Driver Source File /sys/dev/vg.c
                                                                     1f (PIN(fss+2) & 01000)
                                                                                             - PIN(fss+1);
                                                                             C = PIN(f88); .
                                                                                                                                              fsstart();
                                   int C,Q;
                                                                                              ပ
Dec 20 03:49 1981
                                                     .:
0
                            fsintr()
                                                                                     else{
                                                     0
                                                                                                                                                     0412
                           0397
0398
0399
                                                            0401
                                                                           0403
0404
0405
                                                                                                    0406
                                                                                                                                     0410
                                                                                                                                                                                      0416
                                                                                                                                                                                                              0419
0420
                                                                                                                             0409
                                                                                                                                                                              0415
                                                                                                                                                                                                                                      0422
                                                                                                                                                                                                                                                                                       0428
                                                    0400
                                                                                                                     0408
                                                                                                                                             1150
                                                                                                                                                                      0414
                                                                                                                                                                                                      0418
                                                                                                                                                                                                                              0421
                                                                                                                                                                                                                                               0423
                                                                                                                                                                                                                                                       0424
                                                                                                                                                                                                                                                                0425
                                                                                                                                                                                                                                                                       0426
                                                                                                                                                                                                                                                                               0427
```

```
/* set up base address register #/
                                                                                                                                                                                                                                                                                                                                                                                   /* then we don't want the zeroth
                                                                                                                                                                                                                                                                                                                                                                                                     page of memory which may not
                                                                                                                                                                                                                                                                                                                                                                                                                  be contiguous in space with
                                                                                          system dependencies are mainly the way to lock a process into core
                                                                                                                      * NOTE: process must be locked in core and be contiguous in memory
      Page 14
                                                                                                                                                                                                                                                                           lock the process into core in order to prevent swapping st/
                                                                                                                                                                                                                                                                                                                                                                                                                               * the rest of process
                                                                                                                                                                                                                                                                                                                                     VG_CONT->reg= 020000; /* initialize whenever GPU opened */
   Driver Source File /sys/dev/vg.c
                                                                                                                                                                                                                                                                                                                                                                                   = u.u_procp->p_textp) != NULL)
                                                                             this handles the gpu portion of the VG
                                                                                                                                                                                                                                                                                                       u.u_procp->p_flag |= (SSYS|SLOCK);
                                                                                                                                                                                                                                                                                                                                                                                                                                                            ap += ((Text+127)>>7)-1;
                                                                                                                                                                                                                                                                                                                                                                                                                                                                                        VG_BAR->reg = *ap;
                                                                                                                                                                                                                gpopen(dev,flag)
                                                                                                                                                                                                                                              int Text, *ap;
                                                           GPU device
                                                                                                                                                                                                                                                                                                                                                                   ap = APR;
if(( Text =
Dec 20 03:49 1981
                                                                                                                                     0436
                                                                                                                                                                 0438
                                                                                                                                                                                               0440
                                                                                        0433
                                                                                                      0434
                                                                                                                      0435
                                                                                                                                                                                                                                                                                                                                                 0450
                                                                                                                                                   0437
                                                                                                                                                                                                              0441
                                                                                                                                                                                                                           0442
                                                                                                                                                                                                                                            0443
                                                                                                                                                                                                                                                           7770
                                                                                                                                                                                                                                                                        0445
                                                                                                                                                                                                                                                                                        9470
                                                                                                                                                                                                                                                                                                       0447
                                                                                                                                                                                                                                                                                                                    0448
                                                                                                                                                                                                                                                                                                                                   0449
                                                                                                                                                                                                                                                                                                                                                                               0452
                                                                                                                                                                                                                                                                                                                                                                                                                            0455
                                                                                                                                                                                                                                                                                                                                                                                                                                           0456
                                                                                                                                                                                                                                                                                                                                                                                                                                                         0457
                                                                                                                                                                                                                                                                                                                                                                                                                                                                        0458
                                                                                                                                                                                                                                                                                                                                                                                                                                                                                        0459
                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                      0970
                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                    0461
                                                                                                                                                                                                                                                                                                                                                                 0451
                                                                                                                                                                                                                                                                                                                                                                                              0453
                                                                                                                                                                                                                                                                                                                                                                                                            0454
```

```
Page 15
 Driver Source File /sys/dev/vg.c
                                                                                                                                                                                                                                                                               u.u_procp->p_flag &= "(SSYS|SLOCK);
                                                                      while (u.u_count){
POUT(rbumar,u.u_offset);
                                           (u.u_base &1) u.u_base --;
                                                                                        DATA = PIN(rbudat);
                                                                                                 passc(DATA.lobyte);
passc(DATA.hibyte);
                                                                                                                                                                                                                                                              POUT(cmd,0000000);
POUT(dct1,040000);
                                                                                                                                                                                         u.u_error=EIO;
                                                                                                                  u.u_offset++;
                                   int DATA;
Dec 20 03:58 1981
                                                                                                                                                                                                                                            gpclose()
                                                                                                                                                                       gpwrite()
                           rbread()
                                           0465
                                                                                                                                  0475
                                                                                                                                                    0477
0478
0479
                                  0464
                                                     9970
                                                                                       0410
                                                                                                                                                                                               0482
0483
0484
0485
                                                                                                                                                                                                                                   9870
                                                             0467
                                                                      0468
                                                                              0469
                                                                                               0471
0472
0473
0474
                                                                                                                                                                               0480
                                                                                                                                                                                       0481
                                                                                                                                                                                                                                                    0488
                                                                                                                                                                                                                                                             0489
                                                                                                                                                                                                                                            0487
                                                                                                                                                                                                                                                                     0490
                                                                                                                                                                                                                                                                               0491
                                                                                                                                                                                                                                                                                       0492
                                                                                                                                                                                                                                                                                                0493
                                                                                                                                                                                                                                                                                                        7670
                                                                                                                                                                                                                                                                                                                 0495
```

break;

0526

```
dminor = dev.d minor;
(*vgdev[dminor].d write)();
VG_CONT->reg |= intenable;
                                                                                                                                                                                                                                           dmInor = dev.d minor;
(*vgdev[dminor].d close)();
VG CONT->reg |= intenable;
vgunit[dminor].status = 0;
                              dminor = dev.d minor;
(*vgdev[dminor].d read)();
VG_CONT->reg |= intenable;
                                                                                                                       register int dminor;
                                                                                                                                                                                                                                   register int dminor;
           register int dminor;
                                                                                                             vgwrite(dev)
                                                                                                                                                                                                                        vgclose(dev)
vgread(dev)
                   sp10();
                                                                                                                                sp10();
                                                                                                                                                                                0580
0562
0563
                                                                                                                               0575
                                                                                                                                         0576
0577
0578
                                                                                                                                                                       0579
                                                                                                                                                                                                                                           0586
                                                                                                                                                                                                                                                               0588
                                                                                                                                                                                                                                                                                   0590
                   0564
                             0565
                                         0566
                                                           0568
                                                                      0569
                                                                                0570
                                                                                                            0573
                                                                                                                     0574
                                                                                                                                                                                                              0583
                                                                                                                                                                                                                        0584
                                                                                                                                                                                                                                 0585
                                                  0567
                                                                                         0571
                                                                                                   0572
                                                                                                                                                                                                     0582
                                                                                                                                                                                                                                                                        0589
                                                                                                                                                                                                                                                                                                                0593
                                                                                                                                                                                                                                                                                            0591
                                                                                                                                                                                                                                                                                                       0592
```

SAME OF THE PARTY OF THE PARTY

```
: %o %o\n",whichone,PIN(stat),PIN(dcust));
; /* clear the bad condition*/
                                                                           \prime^* find which device interrupted me */
    Page 19
   Driver Source File /sys/dev/vg.c
                                                                                                                                                                                                                                                                                                                                                 VG_CONT->reg | _ intenable|intack; sp10();
                                                     whichone - VG_STAT->reg >> 1;
                                                                                                                                                                                                                                                                                                                   printf("VGERR - [20]
VG_CONT->reg = 020000;
                                           register int whichone;
                                                                          switch (whichone)
                                                                                                                              case DATABLET:
                                                                                                                                        dtintr();
                                                                                                                                                                                                                                                      case GPU_UNIT:
gpIntr();
                                                                                                                                                                                kbintr();
                                                                                                                                                                                                                         fsintr();
                                                                                                                                                                    case KEYBOARD:
                                                                                                                                                                                                              FUNCTION:
                                                                                               case GP_BUS:
break;
                                                                                                                                                                                                                                   break;
                                                                                                                                                  break;
                                                                                                                                                                                           break;
                                                                                                                                                                                                                                                                            break;
                                 vgint (dev)
                                                                                                                                                                                                                                                                                                           default:
Dec 20 04:13 1981
                                                               sp17();
                                                                                                                                                                                                                 case
                                0595
                                                                                                                                                                                      0610
                                                                                                                                                                    0608
                                                                                                                                                                                                                                                                                    0619
0620
                                                                                                                                                                                                                                                                                                                                       0624
                                                               0598
                                                                         0599
                                                                                   0090
                                                                                                        0602
                                                                                                                            0604
                                                                                                                                      0605
                                                                                                                                                9090
                                                                                                                                                                              6090
                                                                                                                                                                                                                                                      9190
                                                                                                                                                                                                                                                                                                                   0622
                                                                                                                                                                                                                                                                                                                                                           0626
0627
                                                    0597
                                                                                             0601
                                                                                                                  0603
                                                                                                                                                          0607
                                                                                                                                                                                                   0611
                                                                                                                                                                                                             0612
                                                                                                                                                                                                                       0613
                                                                                                                                                                                                                                 0614
                                                                                                                                                                                                                                           0615
                                                                                                                                                                                                                                                                0617
                                                                                                                                                                                                                                                                          0618
                                                                                                                                                                                                                                                                                                         0621
                                                                                                                                                                                                                                                                                                                             0623
                                                                                                                                                                                                                                                                                                                                                 0625
```

The second secon

Appendix E: Listing of File /sys/conf/makefile

The file /sys/conf/makefile is used to regenerate the system during execution of the command "make unix60".

Line 57 specifies the maximum allowable size (in bytes) of the system.

```
1.0 mch_1d.0 c.0 ../sys/LIB1_id ../dev/LIB2_id
                                                1d -o unix_id -x -1 1.0 mch_id.o c.o ../sys/LIB1_id ../dev/LIB2_id
                       "The output file will be named unix_id !!!!!"
                                                                                                                                                                                                                                                                                 decho "If not super user, this will not work !!!!"
                                                                       echo "Size of unix_id is TEXT+DATA+BSS = TOTAL"
                                                                                                                                                                                     *
                                                                                                                                                                                        r
E
                                                                                                                                                                    cp ../h/param_id.h ../h/param.h
cd ../sys; cc -c -0 *.c; mklib_id;
cd ../dev; cc -c -0 *.c; mklib_id;
                                                                                                                                                                                                                                 as "o mch id.o mcho.s mch id.s
                                                                                                                                                                                                                      mch0.s mch 1d.s
                                                                                                                                                                                                                                                                                                                               mv unix_i /hptmunix_i
                                                                                                                                                                                                                                                                                                                                                                    mv unix_i /rptmunix_i
unix unix44 unix45 unix70:
                                                                                                                                                                                                                                                                                                                                                                               mkconf Chktsconf
                                                                                                                                                                                                                                                                                                         mkconf <hptmconf
                                                                                                                                                                                                                                                                                                                                         mkconf Krptmconf
                                                                                                 size unix_id
                                                                                                                                   al140 al170
                                                                                                                                                                                                                                                                                                                                                        make unix40
                                                                                                                                                                                                                                                                                                                      make unix40
                                                                                                                                                                                                                                                                                                                                                                                           make unix40
                                                                                                                                                           al145 al170:
                                   Gecho ""
            Gecho ""
                                                                                  "" Gecho
                                                                                                                                                                                                                                                                                            :
                                                                                                                                                                                                                                                                    @echo ""
                                                                                                             ra *.o
                        0echo
                                                            decho
                                                                                                                                                                                                                                                                                            0echo
                                                                                                                                                                                                                                                         allsystems:
                                                                                                                                                                                                                      mch_1d.o:
                                                                                                                                                          a1144
                                                                                                                                    a11:
                                                                                                                                                                                                                               020
                                                                                                           010
011
                                                                                                                                             013
                                                                                                                                                                    015
                                  04
                                             0.5
                                                          90
                                                                                                                                 012
                                                                                                                                                                                016
                                                                                                                                                                                                        018
                                                                                                                                                                                                                    019
                                                                                                                                                                                                                                           021
                                                                                                                                                                                                                                                        022
                                                                                                                                                                                                                                                                   023
                                                                                                                                                                                                                                                                                            025
                                                                                                                                                                                                                                                                                                                                                     030
                                                                     0
                                                                                                                                                                                                                                                                                                      026
                                                                                                                                                                                                                                                                                                                              028
                                                                                                                                                                                                                                                                                                                                         029
                                                                                                                                                                                                                                                                                                                                                                  031
```

```
1_1.0 mch_1.0 c_1.0 ../8ys/LIB1_1 ../dev/LIB2_1
                                                                                                                                                                                                                                                                       ld -o unix_1 -x 1_1.0 mch_1.0 c_1.0 ../sys/LIB1_1 ../dev/LIB2_1
                                                                                                                                                                                                                                                                                                Qecho "If size of unix_i > 49152 bytes, UNIX IS TOO BIG !!!!!"
                                                                                                                                                                                                                                             Gecho "The output file will be named unix_1 !!!!"
                                                                                                                                                                                                                                                                                                                           echo "Size of unix_i is TEXT+DATA+BSS = TOTAL"
                                                                                                                                                                                                                                                                                                                                                                                         mch0.s mch_1.s
as -o mch_1.o mch0.s mch_1.s
                                                                           mv unix_id /hphtunix_id
mkconf 
                                                                                                                mv unix_id /rptmunix_id mkconf <a href="httsconf">hktsconf</a>
                                                                                                                                                       mv unix 1d /hktsunix 1d
                                                                                                                                                                                             mv unix_id /rltsunix_id
mv unix i /hktsunix i mkconf <rr>
                                     unix34 unix40 unix60:
                                                                                                                                                                mkconf Trltsconf
                                                              make unix70
                                                                                                    make unix70
                         make unix40
                                                                                                                                                                              make unix70
                                                                                                                                         make unix70
                                                                                                                                                                                                                                                                                                                                                    size unix_i
                                                                                                                                                                                                                                                        Gecho ""
                                                                                                                                                                                                                                                                                  @echo ""
                                                                                                                                                                                                                                                                                                            Gecho ""
                                                                                                                                                                                                                                 echo
                                                                                                                                                                                                                                                                                                                                                                                         mch_1.0:
                                                                                                                                                                                                                    un1x23
                                                                                                                                                                                                                                                                                                                         059
                       036
                                                038
                                                                           040
                                                                                                                                                                                                      050
                                                                                                                                                                                                                                                                     055
                                                                                                                                                                                                                                                                                  056
                                                                                                                                                                                                                                                                                                            058
                                                                                                                                                                                                                                                                                                                                      090
                                                                                                                                                                                                                                                                                                                                                                           063
                                                             039
                                                                                                   042
                                                                                                                                        045
                                                                                                                                                      970
                                                                                                                                                                              048
                                                                                                                                                                                           049
                                                                                                                                                                                                                   051
                                                                                                                                                                                                                               052
                                                                                                                                                                                                                                           053
                                                                                                                                                                                                                                                        054
                                                                                                                                                                                                                                                                                                                                                               062
                                                                                                                                                                                                                                                                                                                                                                                        990
                                    037
                                                                                       041
                                                                                                                043
                                                                                                                           044
                                                                                                                                                                                                                                                                                               057
                                                                                                                                                                                                                                                                                                                                                   190
                                                                                                                                                                 047
```

067 al123 al134 al140 al160;
068 cp ../h/param 1.h ../h/param.h
069 cd ../sys; cc -c -0 *.c; mklib_i; rm *.o
070 cd ../dev; cc -c -0 *.c; mklib_i; rm *.o
071 cp ../h/param 1.h ../h/param.h
074 cc -c -0 c.c
075 mv c.o c_i.o
076 l_i.s
077 convert l.s l_i.s
077 as -o l_i.o l_i.s
078 as -o l_i.o l_i.s
080 c.o: c.c
081 cp ../h/param.id.h ../h/param.h

THE WAY

Appendix F: Creation of Special Files for the VG Graphics Device

Before	Create Special Files	After
# 1s /dev console kmem 1p mskefile mem mk_rk07b mt0 mt1 nrmt0 nrmt1 nul1 r,t1 rmt0 rmt1 rp0 rp10 rp13 rp17 rp3 rrp0 rrp10 rtp13 rtp17 rtp3 swap tty tty00 tty01 tty02 tty03 tty04 tty05 tty06 tty07 tty08 tty07 tty08 tty09 tty10 tty11 tty12 tty13 tty14 tty15 vp0	# cd /dev # /etc/mknod gpu c 22 0 # /etc/mknod dtb c 22 1 # /etc/mknod kbd c 22 2 # /etc/mknod fss c 22 3 #	# 18 /dev console dtb fss gpu kmem lp makefile mem ro mtl nrmtl nrmtl nrmtl rrmtl rpl rpl rpl rppl rppl rrpp rrpp rrpp
	···.	ttyl5 vp0

Appendix G: Major System Directories

```
# ls /sys/conf
                                                    # ls /sys/sys
                   # 1s /sys/dev
                                    # 1s /sys/h
 c.c
                                                    LIB1 1
                  LIB2 1
                                    acct.h
 c.c.lp
                                                    LIB1 1d
                                    buf.h
                  LIB2 1.save
 c.c.save
                                                    acct.c
                  LIB2 i.vg
                                    callo.h
 c.c.vg
                                                    alloc.c
                  LIB2 1d
                                    conf.h
 conf.afit
                                                    clock.c
                  bio.c
                                    dir.h
 conf.afit.lp
                                                    fakemx.c
                                    dumprestor.h
                  cat.c
 conf.asd
                                                   fio.c
                   dc.c
                                    fblk.h
 convert
                                                   iget.c
                   dh.c
                                    file.h
 dtb.c
                                                    machdep.c
                  dhdm.c
                                    filsys.h
 fss.c
                                                    main.c
                  dhdm.c.orig
                                    ino.h
 hkhtconf
                                                    malloc.c
                  dhdm.c.v7m
                                    inode.h
 hktmconf
                                                   mklib i
                  dhfdm.c
                                    map.h
 hktsconf
                                                    mklib id
                  dkleave.c
                                    mount.h
 hphtconf
                                                    nami.c
                  dn.c
                                    mpx.h
 hptmconf
                                                    pipe.c
                  dsort.c
                                    mx.h
 hptsconf
                                                    prf.c
                  du.c
                                    pack.h
 kbd.c
                                                    prim.c
                  dz.c
                                    param.h
                  hk.c
                                                    rdwri.c
                                    param i.h
 1.s.auto
                                                    sig.c
                                    param_i.h.v7m
                  hp.c
 1.s.good
                                                    slp.c
                  ht.c
                                    param id.h
 1.s.1p
                                                    subr.c
                  kl.c
                                   pk.h
 1.s.save
                                                    sysl.c
                  lp.c
                                    pk.p
 1.s.vg
                                                    sys2.c
                  mem.c
                                    prim.h
 1 1.5
                  mklib i
                                                    sys3.c
                                    proc.h
 makefile
                                                    sys4.c
                  mklib id
                                   pwd.h
 mch0.s
                                                    sysent.c
                  mx1.c
                                   reg.h
 mch i.s
                  mx2.c
                                                    text.c
                                    seg.h
 mch_i.s.save
                                                    trap.c
                  partab.c
                                   smallparam.h
 mch id.s
                                                    ureg.c
                  pk0.c
                                   stat.h
 mkconf
                  pkl.c
                                    stdio.h
 mkconf.c
                  pk2.c
                                   systm.h
 mkdev i
                  pk3.c
                                   term.h
 mkdev id
                  rf.c
                                   text.h
 mksys_i
                  rk.c
                                   timeb.h
 mksys id
                  rl.c
                                   tty.h
 rlhtconf
                  rl.c.orig
                                   types.h
 rltmconf
                                   user.h
                  rp.c
 rltsconf
                  rx2.c.v7m
                                   vg.h
 rphtconf
                  sys.c
rptmconf
                  tc.c
 rptsconf
                  tm.c
 unix i
                  ts.c
 unix i.save
                  ts.c.old
 unix id
                  tty.c
 unixconf
                  vg.c
vg_conf.load
                  vp.c
 vg_conf.unload
                  V8 . C
 vgtest.c
```

Appendix H: Rebooting the System from UNIX Object File /unix.vg

This appendix contains a listing of the commands executed to reboot the system from UNIX object file /unix.vg.

This rebooting session was accomplished from the system console. When the session was begun the system was in multiuser mode with the system console logged in as the "root" user executing a monitoring loop.

In this example, all commands typed by the systems programmer are under scored.

```
5316 (r=5088,d=228,b=0,c=0)
50757 (1=1211,11=37,111=0,d=49472)
                                                                                                                                                                                                                                 1622 (r=1434,d=188,b=0,c=0
18378 (1=508,11=5,111=0,d=17860)
15460
                                                                                                               621 (r=551,d=26,b=8,c=36)
8652 (1=231,11=8,111=0,d=8405)
570
                                                                                         Check root file system, drive 0
                                                                                                                                                                                                         Check home file system, drive 0
                                                                                                                                                                                                                                                                                                  Check /usr file system, drive l
                      root console Dec 18 21:11 # kill -1 1
                                                                           Fr1 Dec 18 21:11:49 EST 1981
                                                                                                                                                                                entries link cnt
12 13
type a control D
                                                                                                                                                                                                                                                                                                              /dev/rrp17:
                                                                                                                                                                                                                                                                                                                                                                             /dev/rrp17:
                                                                                                                                                                    /dev/rrp0:
                                                                                                                                                                                                                                                                                      /dev/rrp3:
                                                                                                      /dev/rrp0:
                                                                                                                                                                                                                      /dev/rrp3:
                                                                                                                                                                                                                                                                         missing
                                                                                                                                                                                                                                                                                                                                                                missing
                                                                                                                                                        missing
                                                                                                                                                                                                                                                                                                                                                                                                                     sync
             who
                                                                                                                                                                                                                                   files
                                                                                                                                                                                                                                                                                                                            files
                                                                                                                   files
                                                                                                                                                                                                                                                nsed
                                                                                                                                                                                                                                                                                                                                        nsed
                                                                                                                                used
                                                                                                                                                                                                                                                              free
                                                                                                                                            free
                                                                                                                                                                                                                                                                                                                                                      free
```

boot Boot: hk(0,0)unix.vg mem = 203968 # date 12180918 Fri Dec 18 09:18:00 EST 1981

Vita

Bradley Ray Stewart was born on 5 August 1955 in San Luis Obispo, California. Bradley graduated with academic honors from East Union High School, Manteca, California in 1973. He attended Brigham Young University from which he received a Bachelor of Science degree in Computer Technology in June 1980. Upon graduation, he received a commission in the USAF through the ROTC program. He then entered the School of Engineering, Air Force Institute of Technology, in June 1980.

Permanent address: 1026 Lewis Oak Road
Gridley, California 95948

UNCLASSIFIED
SECURITY CLASSIFICATION OF THIS PAGE (When Date Entered)

REPORT DOCUMENTATION PAGE	READ INSTRUCTIONS BEFORE COMPLETING FORM		
	N NO. 3. PECIPIENT'S CATALOG NUMBER		
AFIT/GCS/MA/81D-6 MO-A/15 So			
4. TITLE (and Subtitle)	5. TYPE OF REPORT & PERIOD COVERED		
A UNIX BASED DEVICE DRIVER FOR THE VECTOR GENERAL 3404 GRAPHICS DISPLAY SYSTEM	MS Thesis		
	6. PERFORMING ORG. REPORT NUMBER		
7. AUTHOR(e)	B. CONTRACT OR GRANT NUMBER(#)		
Readley D. Stowart			
Bradley R. Stewart	•		
9. PERFORMING ORGANIZATION NAME AND ADDRESS	10. PPOGRAM ELEMENT, PROJECT, TASK APEA A WORK UNIT NUMBERS		
Air Force Institute of Technology (AFIT/EN) Wright-Patterson AFB, Ohio 45433			
Wright-racterson Arb, onto 40400			
11. CONTROLLING OFFICE NAME AND ADDRESS	12. REPORT DATE		
	March, 1982		
	213		
14. MONITORING AGENCY NAME & ADDRESS(If different from Controlling Off			
	Unclassified		
	15a. DECLASSIFICATION/DOWNGRADING SCHEDULE		
16. DISTRIBUTION STATEMENT (of this Report)			
TO STATE WELL TO THE REPORT			
Approved for public release; distribution unlimited			
	·		
17. DISTRIBUTION STATEMENT (of the abetract entered in Block 20, if different from Report)			
1 5 APR 1982	Dean for Research and Professional Development		
15 APR 1982	Air Force Institute of Technology (ATC)		
Ty & Wolan	Wright-Patterson AFB, OH 45433		
Approved for public release; IAW AFR 190-17			
P-0-1 MICH - M-2-1 MC 4 P			
F . C. LYNCH, Major, U SAF D irector of Inf ormati on			
19. KEY WORDS (Continue on reverse side if necessary and identify by block nu	ember)		
UNIX Vector General 3404 Computer Graphics PDP11/60			
Peripheral Device I/O			
Device Driver			
Device Handler 20. ABSTRACT (Continue on reverse side if necessary and identify by block num	mher)		
A device driver for the Vector General 3404 Graphics Display System was			
installed under the UNIX version seven operating system on a PDP11/60 computer.			
This was accomplished by modifying an existing d to run under version six of the UNIX operating s			

The major topics addressed in this report are the C programming language, peripheral device I/O processing under UNIX, the hardware interface between the PDP11/60 and the graphics display system, the graphics display system

DO 1 JAN 73 1473 EDITION OF ! NOV 65 IS OBSOLETE

UNCLASSIFIED

Structure charts were used to document the design of the UNIX peripheral device I/O processing software and the design of the device driver software.

Modifications to the original device driver were easily accomplished due to the top-down modular design of the original software. UNIX provided a straight-forward interface for adding the device driver software to the system.

UNCLASSIFIED

